



Clavinova[®]

CSP-295GP

CSP-295

CSP-275

CSP-255

Data List

Daten-Liste

Liste des données

Lista de datos

This data list describes the parameters that can be selected on the instrument and the Smart Pianist app.



Table of Contents

Piano Types in the Piano Room Klaviermodelle im Piano Room Types de piano dans Piano Room Tipos de pianos de Piano Room	3
Voice List Voice-Liste Liste des sonorités Lista de voces	4
Drum/key Assignment List Liste der Tastenzuordnungen der Schlaginstrumente Liste des affectations d'instrument de batterie/touche de clavier Lista de asignación de teclas/batería.....	18
Song List Liste der Song Liste des morceaux Lista de canciones	28
Style List Liste der Styles Liste des styles Lista de estilos	32
Chord Types for Style Playback Akkordtypen für die Style-Wiedergabe Types d'accords pour la reproduction de style Tipos de acordes para reproducción de estilos	37
Effect Type List Liste der Effekttypen Liste des types d'effet Lista de tipos de efecto	38
Vocal Harmony Parameter List Liste der Vokalharmonie-Parameter Liste des paramètres liés à l'harmonie vocale Lista de parámetros de armonía vocal	39
Parameter Chart Parametertabelle Tableau des paramètres Gráfico de parámetros	41
MIDI Implementation Chart MIDI-Implementierungstabelle Tableau d'implémentation MIDI Gráfico de implementación MIDI	44

Piano Types in the Piano Room / Klaviermodelle im Piano Room / Types de piano dans Piano Room / Tipos de pianos de Piano Room

Voice Name
CFX Grand
Bösendorfer
Studio Grand
Concert Upright
Honky Tonk Upright

Voice List / Voice-Liste / Liste des sonorités / Lista de voces

CSP-295GP, CSP-295

Main Category: Piano

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Grand Piano	*1 CFX Grand	108	0	1	VRM	
	*1 Bösendorfer	108	6	1	VRM	
	Stage Piano	108	31	1	VRM	
	Pop Grand	108	17	2	VRM	
	Studio Grand	108	30	1	VRM	
	Rock Piano	108	16	3	VRM	
	Themic Grand	108	6	2	VRM	
	CFX 1Octave	108	22	2	VRM	
	Ambient Piano	108	27	4	VRM	
	CFX 2Octaves	108	23	2	VRM	
	Mellow Piano	108	18	1	VRM	
	Bright Piano	108	16	2	VRM	
	CFX Cocktail Piano	108	28	4	VRM	
	Upright Piano	*1 Concert Upright	108	5	3	VRM
		Honky Tonk Upright	104	13	4	Natural!
School Upright		104	13	1	Natural!	
Saloon Upright		104	14	2	Natural!	
Pop Upright		104	13	2	Natural!	
Upright 1Octave		104	14	4	Natural!	
70s Ballad Upright		104	14	1	Natural!	
Upright 2Octaves		104	15	4	Natural!	
Chillout Upright		104	15	1	Natural!	
Piano Layer	CFX Superstar Grand	108	25	5	Natural!	
	Imperial Cosmos	104	42	1	Natural!	
	CFX Fat Pad	104	43	1	Natural!	
	Imperial Ballad	108	26	5	Natural!	
	CFX DX Layer	108	33	3	Natural!	
	Bösendorfer DX Layer	108	34	3	Natural!	
	CFX & Strings	108	23	1	Natural!	
	Upright Synthetics	104	21	4	Natural!	
	Piano & EP 1	108	25	3	Natural!	
	Piano & EP 2	108	26	3	Natural!	
	MIDI Grand	104	2	3	Natural!	
	MIDI Grand Pad	104	3	3	Natural!	
	Electric Piano	Suitcase Hard	104	16	5	Cool!
Suitcase Warmth		104	14	5	Cool!	
Suitcase Soft		104	7	5	Cool!	
Suitcase Phaser		104	10	5	Cool!	
Suitcase Ballad		104	9	5	Cool!	
Suitcase Tremolo		104	12	5	Cool!	
Suitcase Drive		104	11	5	Cool!	
*1 Vintage EP		104	8	5	Cool!	
*1 Suitcase Jazz		104	13	5	Cool!	
Vintage EP Drive		104	15	5	Cool!	
CP80 Studio		0	123	3	Natural!	
Suitcase Sweep Swell		104	33	5	Cool!	
CP80 Stage		0	113	3	Regular	
Suitcase String Machine		104	34	5	Cool!	
CP80 Honky Tonk		104	15	3	Cool!	
Ballad Epic EP		104	35	5	Cool!	
FM E.Piano		DX Sweet	104	0	6	Cool!
	TX Bright	104	10	6	Cool!	
	*1 DX Dynamic	0	123	6	Cool!	
	TX Mellow	104	11	6	Cool!	
	DX Ballad	0	124	6	Cool!	
	TX Warm	104	12	6	Cool!	
	DX Ballad Bells	104	2	6	Cool!	
	DX Dream	104	3	6	Cool!	
	DX Midnight	104	1	6	Cool!	
	Studio Ballad DX	104	9	6	Regular	
	Clavi	Clavi SW	8	33	21	S.Art!
Clavi Funk SW		8	34	21	S.Art!	
Clavi Bright		0	112	8	Regular	
Wah Clavi		0	113	8	Regular	
Clavi Warm		0	122	8	Natural!	
Clavi Funk		0	123	8	Natural!	
Clavi Drive SW		8	36	21	S.Art!	
Clavi Phase		0	115	8	Regular	

Voices marked with "*1" can be selected from the instrument.

Main Category: Piano

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Harpischord	*1 Harpischord 1	0	122	7	Natural!
	Grand Harpischord	0	113	7	Live!
	Harpischord 2 SW	8	32	113	S.Art!
	Harpischord Coupler	0	123	7	Natural!
	Harpischord 3	0	125	7	Natural!
	Harpischord & Strings	0	124	7	Natural!

Main Category: Organ

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Tonewheel Organ	*1 Jazz Rotary SW	8	32	114	S.Art!
	Curved Bars	0	121	17	Cool!
	Whiter Bars SW	8	32	30	S.Art!
	Even Bars	0	111	17	Cool!
	Classic Bars SW	8	34	30	S.Art!
	Hollow Bars	0	127	17	Cool!
	Rock Organ SW	8	33	114	S.Art!
	Classic Scanner	0	118	19	Cool!
	All Bars Out SW	8	32	31	S.Art!
	Organ A Go Go	104	0	17	Cool!
	Classic Jazz	0	117	17	Cool!
	Vintage Accomp 1	0	108	18	Regular
	Hold It Fast	0	111	18	Cool!
	Vintage Accomp 2	0	107	18	Regular
	R&B Tremolo Organ	0	111	19	Cool!
	Vintage Accomp 3	0	106	18	Regular
	Prog Rock Organ SW	8	33	30	S.Art!
	Vintage Accomp 4	0	105	18	Regular
	Full Rocker	0	115	19	Cool!
	Vintage Accomp 5	0	104	18	Regular
	Whiter Bars Slow	104	1	18	Cool!
	Whiter Bars Fast	104	0	18	Cool!
	Jazz Organ Slow	0	126	18	Cool!
	Jazz Organ Fast	0	127	18	Cool!
	All Bars Out Slow	104	1	19	Cool!
	All Bars Out Fast	104	0	19	Cool!
	All Bars Phase	104	2	19	Cool!
	Rotary Organ	0	117	19	Cool!
	Mellow Vintage	0	115	18	Regular
Two Channels Organ	0	109	18	Cool!	
Transistor Organ	60s Combo Organ 1	104	32	17	Cool!
	Euro Accomp 1	104	33	18	Regular
	60s Combo Organ 2	104	33	17	Cool!
	Euro Accomp 2	104	34	18	Regular
	60s Combo Organ 3	104	34	17	Cool!
	Euro Accomp 3	104	35	18	Regular
	60s Combo Organ 4	104	35	17	Cool!
	Home Accomp 1	104	37	19	Regular
	Home Organ Clarinet	104	20	19	Regular
	Home Accomp 2	104	38	19	Regular
	Home Organ Cello	104	21	19	Regular
	Home Organ E.Horn	104	22	19	Regular
	Home Organ Cornet	104	23	19	Regular
	Home Organ Violin	104	24	19	Regular
Home Organ Kinura	104	25	19	Regular	
Home Organ Trombone	104	19	19	Regular	
Classical Pipe	Lieblich Gedackt	104	6	20	Regular
	Fonds Et Anches	104	2	20	Live!
	Diapason	104	4	20	Regular
	Organo Pleno	104	3	20	Live!
	Claribel & Flute	104	5	20	Regular
	Concert Organ Tutti	104	0	20	Live!
	Soft Reeds	104	7	20	Regular
	Chapel Organ 1	0	113	20	Regular
	Grand Jeu	104	1	20	Live!
	Chapel Organ 2	0	115	20	Regular
	*1 Pipe Organ Principal	0	123	20	Natural!
Pipe Organ Tutti 1	0	126	20	Natural!	

CSP-295GP, CSP-295

Main Category: Organ

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Classical Pipe	Pipe Organ 8'	0	124	20	Natural!
	Pipe Organ Tutti 2	0	122	20	Natural!
	Pipe Organ Twelfth	0	125	20	Natural!
	Full Organ	0	112	20	Regular
Theatre Pipe	Theatre Tibia & Vox	104	28	19	Regular
	Theatre Gamba Celeste	104	30	19	Regular
	Theatre Open Tibias	104	29	19	Regular
	Theatre Seaside	104	26	19	Regular
	Theatre Organ Mix 1	104	31	19	Regular
	Theatre Flute Accomp	104	34	19	Regular
	Theatre Organ Mix 2	104	32	19	Regular
	Theatre Strings Accomp	104	35	19	Regular
	Theatre Organ Mix 3	104	33	19	Regular
	Theatre Chrys Accomp	104	36	19	Regular
	Theatre Chrysoglott	104	28	18	Regular
	Theatre Organ Chimes	104	31	18	Regular
	Theatre Xylophone	104	30	18	Regular
	Theatre Wooden Harp	104	32	18	Regular
	Theatre Glockenspiel	104	29	18	Regular
	Theatre Pedal 1	104	16	19	Regular
	Theatre Trumpet	0	124	17	Regular
	Theatre Pedal 2	104	17	19	Regular
Organ Flutes	Jazz Standard	10	0	1	OrganFlutes
	Rock Organ	10	3	1	OrganFlutes
	Jazz Squabble	10	7	1	OrganFlutes
	Gospel Organ	10	4	1	OrganFlutes
	Upside Down Smile	10	1	1	OrganFlutes
	Organ Pops	10	2	1	OrganFlutes
	Ballad Organ	10	5	1	OrganFlutes
	Euro Percussion	10	0	3	OrganFlutes
	Organ Clarinet	10	6	1	OrganFlutes
	Euro Pops	10	5	3	OrganFlutes
	Euro Reeds	10	2	3	OrganFlutes
	Euro Bright	10	4	3	OrganFlutes
	Euro Melodic	10	7	3	OrganFlutes
	Home Organ Jazz	10	3	2	OrganFlutes
	Euro Full	10	6	3	OrganFlutes
	Home Hollow Tibias	10	4	2	OrganFlutes
	Euro Ballad	10	1	3	OrganFlutes
	Home Theatre Organ	10	2	2	OrganFlutes
	Euro Even Warmth	10	3	3	OrganFlutes
	Home 16 & Odds	10	1	2	OrganFlutes
Home Organ Ballad	10	0	2	OrganFlutes	
Home Organ Warmth	10	6	2	OrganFlutes	
Home Organ Evens	10	5	2	OrganFlutes	
Home Organ Full	10	7	2	OrganFlutes	
Harmonica	Harmonica	0	112	23	Sweet!
	Modern Harp	0	113	23	Regular
	Blues Harp	0	114	23	Regular
Accordion	Full Register	104	2	22	Regular
	Accordion Clarinet	104	1	22	Regular
	French Musette Acc.	0	119	22	Regular
	Tango Accordion	0	114	24	Regular
	Master Accordion	0	118	22	Regular
	Cajun Accordion	104	3	22	Regular
	Jazz Accordion	0	120	22	Regular
	Steirische	0	117	22	Regular
	Cassotto	104	0	22	Regular
	Bandoneon	0	113	24	Regular
	Full Register Bass	104	5	22	Regular
	Accordion Bass	0	121	22	Regular
	Musette Bass	0	123	22	Regular
	Tango Accordion Bass	0	115	24	Regular
	Master Bass	0	122	22	Regular
	Cajun Accordion Bass	104	6	22	Regular

Main Category: Guitar & Bass

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Nylon Acoustic	Flamenco Guitar	8	35	2	S.Art!	
	Spanish Guitar	8	34	2	S.Art!	
	Spanish Electro	8	36	2	S.Art!	
	Spanish Guitar Slide	104	9	26	Live!	
	Concert Guitar	8	32	1	S.Art!	
	Dynamic Nylon Guitar	0	116	25	Live!	
	Hard Flamenco	0	118	25	Live!	
	Nylon Guitar SW	8	34	1	S.Art!	
	Classical Guitar	0	115	25	Live!	
	Nylon Guitar Slide	0	117	25	Live!	
	Nylon Mute	0	119	25	Live!	
	Electro Acoustic Guitar	8	35	1	S.Art!	
	Steel Acoustic	Steel Acoustic Pick	8	37	2	S.Art!
		Steel Acoustic Strum	104	10	26	Live!
Steel Guitar Twin 1		104	12	26	Live!	
Steel Guitar Twin 2		104	13	26	Live!	
Chicken Pick Guitar		104	11	26	Live!	
12String Picked		8	39	2	S.Art!	
Chicken Pick SW		8	38	2	S.Art!	
12String Strumming SW		8	40	2	S.Art!	
Steel Guitar		8	32	2	S.Art!	
Steel Guitar Slide		0	118	26	Live!	
Folk Gt Harmonics SW		8	33	2	S.Art!	
Dynamic Steel Guitar		0	116	26	Live!	
Clean Solid	Steel Guitar Strum	0	117	26	Live!	
	Steel Guitar Mute	0	120	26	Live!	
	12String Guitar	0	113	26	Live!	
	Shadowed Guitar	8	56	4	S.Art!	
	Oldies Guitar	8	52	6	S.Art!	
	50s Vintage Delay	8	48	6	S.Art!	
	Finger Slap Slide SW	8	51	4	S.Art!	
	Rough Fingers	8	39	5	S.Art!	
	Clean Fingers	8	38	5	S.Art!	
	Country Pick Drive	8	40	5	S.Art!	
	Country Pick Vintage	8	41	5	S.Art!	
	50s Vintage Pure	8	42	6	S.Art!	
	Bluesy Fingers	8	37	5	S.Art!	
	70s Jazz Combo	8	54	6	S.Art!	
	Finger Chorus	8	42	4	S.Art!	
	Warm Solid	8	33	4	S.Art!	
	Single Coil Clean	8	39	4	S.Art!	
	Clean Solid	8	34	4	S.Art!	
	Bright Chorus	8	45	4	S.Art!	
	Vintage Slap	8	48	4	S.Art!	
	Ballad Delay	8	46	4	S.Art!	
	Vintage Pure	8	47	4	S.Art!	
	Jazz Guitar Amp	8	38	7	S.Art!	
	Jazz Artist Guitar	8	39	7	S.Art!	
	Finger Bright	8	50	4	S.Art!	
	Slide Clean	0	117	29	Cool!	
	Warm Electric SW	8	32	4	S.Art!	
	Slide Warm	104	6	28	Cool!	
	Clean Electric SW	8	35	4	S.Art!	
	Slide Pick	104	7	28	Cool!	
	Jazz Guitar Clean	8	32	7	S.Art!	
	Country Pick	8	44	4	S.Art!	
Jazz Solo Guitar	0	116	27	Cool!		
Semi Acoustic	8	33	7	S.Art!		
Electric Guitar	0	114	29	Cool!		
Chorus Solid	0	107	28	Cool!		
Dynamic Mute	0	118	29	Cool!		
Slide Solid	0	110	28	Cool!		
Cool Wah Guitar	104	4	28	Regular		
Slap Solid	0	108	28	Cool!		
Slapback	104	0	28	Cool!		
Light Chorus	8	53	4	S.Art!		
Funk Slap	8	49	4	S.Art!		
Jazz Guitar Smooth SW	8	35	7	S.Art!		
Slide Finger	104	5	28	Cool!		
Lounge Guitar	104	1	27	Regular		

CSP-295GP, CSP-295

Main Category: Guitar & Bass

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Clean Solid	Vintage Muted Guitar	104	0	29	Cool!	
	50s Vintage Spring	8	54	4	S.Art!	
	50s Vintage Mute	0	115	29	Regular	
	Vintage Open	0	123	28	Regular	
	Vintage Strum	0	126	28	Regular	
	Funk Guitar	0	116	29	Cool!	
	70s Solid Guitar	8	38	4	S.Art!	
	Slide Jazz	104	0	27	Cool!	
	Jazz Guitar	0	115	27	Cool!	
	Clean Guitar	0	112	28	Cool!	
	60s Clean	0	117	28	Regular	
	Tremolo Solid	0	111	28	Cool!	
	Muted Guitar	0	119	29	Cool!	
	Ballad Solid	0	109	28	Cool!	
	Octave Guitar	0	113	27	Regular	
	Distortion Solid	Solo King	8	50	6	S.Art!
		Rhythm King	8	53	6	S.Art!
50s Vintage Full		8	43	6	S.Art!	
50s Vintage Solo		8	44	6	S.Art!	
50s Vintage Stage		8	45	6	S.Art!	
50s Heavy Rock		8	47	6	S.Art!	
50s Drive Wah Wah		8	46	6	S.Art!	
Rock Hero		8	35	6	S.Art!	
Stage Lead		8	38	6	S.Art!	
Grunge Guitar		8	40	6	S.Art!	
Big Amp Combo		8	51	6	S.Art!	
50s Vintage Warm		8	49	6	S.Art!	
Overdrive Wah Wah		8	39	6	S.Art!	
50s Vintage Amp		8	41	4	S.Art!	
Rock Legend		8	34	6	S.Art!	
Finger Amp		8	43	4	S.Art!	
50s Vintage Rock		8	36	6	S.Art!	
Slide Pick Amp		104	8	28	Cool!	
Guitar Hero		8	32	6	S.Art!	
Half Drive		8	37	4	S.Art!	
Bluesy Slap Slide SW		8	36	5	S.Art!	
Classic Amp Stack		8	41	6	S.Art!	
50s Vintage Blues		8	37	6	S.Art!	
Crunch Guitar		8	33	6	S.Art!	
Warm Blues		8	34	5	S.Art!	
Heavy Rock Guitar		8	32	5	S.Art!	
Bluesy Night		8	55	4	S.Art!	
Stereo Rock Guitar		104	2	31	Cool!	
Bright Blues		8	35	5	S.Art!	
Feedbacker SW		8	33	5	S.Art!	
Power Lead		0	115	31	Cool!	
Vintage Amp		0	115	30	Regular	
Metal Master		0	120	31	Regular	
Vintage Lead		0	125	28	Cool!	
Crunch Guitar		0	113	31	Regular	
Blues Guitar		0	117	30	Cool!	
Heavy Stack		0	114	31	Regular	
World		Pedal Steel Amp	8	52	4	S.Art!
		Mandolin	0	114	26	Sweet!
		Pedal Steel Guitar	8	36	4	S.Art!
	Zither 1	104	1	16	Regular	
	Banjo	104	0	106	Regular	
	Zither 2	104	0	16	Regular	
	Shamisen	0	112	107	Regular	
	Dulcimer	0	112	16	Regular	
	Koto	0	112	108	Regular	
	Hackbrett	104	2	47	Regular	
Bass	Aloha Guitar	0	118	27	Regular	
	Sitar	104	0	105	Regular	
	Vintage Round Bass	8	32	18	S.Art!	
	Acoustic Bass	8	32	17	S.Art!	
	Vintage Flatwound Bass	8	33	18	S.Art!	
	Soft Acoustic Bass	8	33	17	S.Art!	
Vintage Mute Bass	8	32	19	S.Art!		
Acoustic Bass & Cymbal	0	114	33	Regular		

Main Category: Guitar & Bass

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Bass	Vintage Pick Bass	104	1	35	Regular
	Fusion Bass	0	113	37	Regular
	Fretless Bass	8	32	20	S.Art!
	Slap Bass	0	112	37	Regular
	Vintage Round Bass	104	1	34	Cool!
	Acoustic Bass 2	104	1	33	Regular
	Vintage Flatwound Bass	104	2	34	Cool!
	Soft Acoustic Bass	104	2	33	Regular
	Vintage Mute Bass	104	3	34	Cool!
	Ballroom Bass	104	0	33	Regular
	Vintage Pick Mute Bass	104	0	35	Cool!
	Half Mute Bass	0	115	34	Cool!
	Fretless Bass	0	112	36	Cool!
	Vintage Dyno Bass	104	2	35	Cool!
	Rock Bass	0	114	35	Regular
	Electric Bass	0	114	34	Cool!
	Pick Dyno Bass	0	113	35	Cool!
	Mellow Finger Bass	0	112	34	Regular
	Super Fretless Bass	0	113	36	Regular
	Synth Bass	Pick Bass	0	112	35
Funk Bass		0	112	38	Regular
BPF Buzz SW		8	32	123	S.Art!
Wobble SW		8	33	123	S.Art!
Ramp Bass SW		8	34	123	S.Art!
Square Pluck SW		8	35	123	S.Art!
Deep Sub		104	18	88	Regular
Modern Pop		104	19	88	Regular
Multi Saw Bass		104	20	88	Regular
Brite Dub Bass		104	21	88	Regular
Pulse & Saw		104	22	88	Regular
Twenty Five		104	23	88	Regular
Punchy Square		104	24	88	Regular
Softwood		104	25	88	Regular
Punchy DX		104	26	88	Regular
Dark Sequence Bass		104	27	88	Regular
Pumping Saw		104	28	88	Regular
Pumping Square		104	29	88	Regular
Lo Bass		104	0	40	Regular
Fat Pulse		104	2	40	Regular
Dark Bass		104	1	40	Regular
Wazzo Saw		104	3	81	Regular
Moon Bass		104	0	39	Regular
Deep Point		104	3	39	Regular
Kick Bass		104	1	39	Regular
Tight Bass		104	3	40	Regular
Club Bass		104	2	39	Regular
Competitor		104	4	39	Regular
1o1 Sub		104	5	39	Regular
Trance Bass		104	9	39	Regular
Little Bass Synth	104	6	39	Regular	
Sub Cut Bass	104	5	40	Regular	
Tekno Bass	104	7	39	Regular	
Dyno Acid Bass	104	10	39	Regular	
Perc Punch	104	8	39	Regular	
Mini Sub	104	6	40	Regular	
Square Bass	104	4	40	Regular	
Fat Sine Resonance	104	11	39	Regular	
Ballad Bass	104	7	40	Regular	
House Bass	0	116	39	Regular	
Velo Master	104	17	82	Regular	
Big Drone	0	118	39	Regular	
Sub Bass	0	114	40	Regular	
Hard Bass	0	114	39	Regular	
Resonance Bass	0	112	39	Regular	
TB Bass	0	117	40	Regular	

CSP-295GP, CSP-295

Main Category: Strings & Vocal

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
String Solo	Orchestral 1st Violin	8	33	44	S.Art!
	Hoedown Violin	0	113	41	Sweet!
	Orchestral 2nd Violin	8	33	45	S.Art!
	Country Fiddle	0	112	111	Regular
	Orchestral Viola	8	33	46	S.Art!
	Viola	0	112	42	Regular
	Orchestral Cello	8	33	47	S.Art!
	Cello	0	122	43	Natural!
	Seattle Quartet	8	34	48	S.Art!
Contrabass	0	112	44	Regular	
String Ensemble	Seattle Romance	8	43	50	S.Art!
	Pizzicato Strings	0	113	46	Live!
	Concert Strings	8	32	50	S.Art!
	Seattle Tremolo Strings	104	0	45	Live!
	Broadway Strings	8	38	49	S.Art!
	Seattle Spiccato	104	6	49	Live!
	Seattle Chamber	8	42	49	S.Art!
	Seattle String Pad	8	43	49	S.Art!
	Seattle Strings	8	33	50	S.Art!
	Seattle Classical	8	36	49	S.Art!
	Seattle 1st Violins	8	32	44	S.Art!
	Classic 1st Violins	8	34	44	S.Art!
	Seattle 2nd Violins	8	32	45	S.Art!
	Classic 2nd Violins	8	34	45	S.Art!
	Seattle Violas	8	32	46	S.Art!
	Classic Violas	8	34	46	S.Art!
	Seattle Cellos	8	32	47	S.Art!
	Classic Cellos	8	34	47	S.Art!
	Seattle Basses	8	32	48	S.Art!
	Spiccato	0	120	49	Live!
	Theatre Strings	8	37	49	S.Art!
	Seattle Lush Strings	8	41	49	S.Art!
	Seattle Slow Strings	8	35	50	S.Art!
	Studio Strings	8	32	49	S.Art!
	Strings	0	122	49	Natural!
	Movie Strings	0	123	49	Live!
	Disco Strings 1	0	123	50	Live!
	Ballad Strings	8	34	50	S.Art!
	Disco Strings 2	0	124	50	Live!
	Seattle Warm	8	39	49	S.Art!
	Tremolo Strings	0	113	45	Live!
	Big Strings	8	40	49	S.Art!
	Spiccato	8	33	49	S.Art!
	Strings Pad	0	117	50	Live!
	Seattle Strings f	8	40	50	S.Art!
	Allegro	0	122	50	Live!
	Seattle Strings mf	8	41	50	S.Art!
	Dynamic Strings	0	124	49	Live!
	Seattle Strings p	8	42	50	S.Art!
	Chamber Strings	0	112	50	Regular
	Seattle Tremolo Storzando	104	1	45	Live!
	Tremolo Bowing SW	8	34	49	S.Art!
	Strings f	0	119	49	Live!
	Seattle Strings f	104	4	50	Live!
	Strings mf	0	118	49	Live!
	Seattle Strings mf	104	5	50	Live!
	Strings p	0	117	49	Live!
Seattle Strings p	104	6	50	Live!	
Orchestral Layers	Horns & Strings	8	38	50	S.Art!
	Symphonic Unison	104	0	50	Regular
	Orchestra Tutti	0	120	50	Regular
	Theatre Orchestra	104	1	50	Regular
	Pizzicato Glocken	0	115	46	Live!
Pop Vocals	Haa	8	32	40	S.Art!
	Doo	8	38	41	S.Art!
	Wah	8	38	40	S.Art!
	Yoo	8	42	41	S.Art!
	Baa	8	41	40	S.Art!
	Boys Ooh	8	34	41	S.Art!
	Daa	8	45	40	S.Art!

Main Category: Strings & Vocal

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Pop Vocals	Girls Ooh	8	36	41	S.Art!	
	Ooh	8	32	41	S.Art!	
	Pop Vocals	8	40	56	S.Art!	
	Boys Haa Vibrato	8	33	40	S.Art!	
	Doo Vibrato	8	39	41	S.Art!	
	Wah Vibrato	8	39	40	S.Art!	
	Yoo Vibrato	8	43	41	S.Art!	
	Baa Vibrato	8	42	40	S.Art!	
	Boys Ooh Vibrato	8	35	41	S.Art!	
	Daa Vibrato	8	46	40	S.Art!	
	Girls Ooh Vibrato	8	37	41	S.Art!	
	Ooh Vibrato	8	33	41	S.Art!	
	Bee Vibrato	104	4	53	Live!	
	Haa	104	9	53	Live!	
	Doo	104	16	54	Live!	
	Wah	104	10	53	Live!	
	Yoo	104	18	54	Live!	
	Baa	104	12	53	Live!	
	Boys Doo	8	40	41	S.Art!	
	Daa	104	13	53	Live!	
	Girls Doo	8	41	41	S.Art!	
	Ooh	104	17	54	Live!	
	Hoo-Wah	8	39	56	S.Art!	
	Aah-Ooh Auto	8	49	41	S.Art!	
	Soft Wah	8	40	40	S.Art!	
	Accomp Aah	104	15	53	Live!	
	Boys Haa	8	34	40	S.Art!	
	Accomp Ooh	104	15	54	Live!	
	Girls Haa	8	35	40	S.Art!	
	Mmh	0	117	53	Live!	
	Hoo-Wee Auto	8	56	56	S.Art!	
	Jazz Vocals	Shoo-Bee-Doo-Bah 1	8	32	56	S.Art!
		Do-Be-Do-Be	8	48	56	S.Art!
Shoo-Bee-Doo-Bah 2		8	47	56	S.Art!	
Ya-Ba-Da-Ba		8	51	56	S.Art!	
Ba-Da-Yah		8	36	56	S.Art!	
Who-Are-You		8	54	56	S.Art!	
What-Should-We-Do		8	53	56	S.Art!	
Do-We-Yo-Be		8	52	56	S.Art!	
Shoo-Bee Dynamic		8	35	56	S.Art!	
Shoo-Ba-Doo-Ba		8	55	56	S.Art!	
Jazz Scat Vocals		8	42	56	S.Art!	
Latin Vocals		8	41	56	S.Art!	
Jazz Scat Shoo		8	45	56	S.Art!	
Baroque Scat		8	43	56	S.Art!	
Jazz Scat Dwee		8	46	56	S.Art!	
Jazz Scat Legato	8	50	56	S.Art!		
Gospel Choir	Gospel Vocals Hmm	8	32	55	S.Art!	
	Gospel Wow-Hey-Hmm	8	35	55	S.Art!	
	Gospel Vocals Wow	8	33	55	S.Art!	
	Gospel Vocals Hmm	104	12	54	Live!	
	Gospel Vocals Hey	8	34	55	S.Art!	
	Gospel Vocals Wow	104	13	54	Live!	
	Gospel Hmm-Aah SW	8	36	55	S.Art!	
	Gospel Vocals Hey	104	7	53	Live!	
	Gospel Wow-Hey SW	8	37	55	S.Art!	
Classical Choir	Boys Choir Ooh	8	32	52	S.Art!	
	Boys Choir Aah	8	33	52	S.Art!	
	Boys Choir Ooh f	8	37	52	S.Art!	
	Boys Choir Aah f	8	38	52	S.Art!	
	Boys Choir Ooh p	8	35	52	S.Art!	
	Boys Choir Aah p	8	36	52	S.Art!	
	Boys Choir Oh-Ah SW	8	34	52	S.Art!	
Boys Choir Oh-Ah	8	49	56	S.Art!		

CSP-295GP, CSP-295

Main Category: Brass & Woodwind

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Brass Solo	Bright Trumpet	8	32	65	S.Art!	
	Cornet	0	119	57	Sweet!	
	Silver Trumpet	8	33	65	S.Art!	
	Muted Trumpet	0	114	60	Sweet!	
	Golden Trumpet	8	34	65	S.Art!	
	Flugelhorn	0	118	57	Sweet!	
	Big Band Trumpet	8	37	65	S.Art!	
	Sweet Trombone	0	117	58	Sweet!	
	Trumpet Fall SW	8	38	65	S.Art!	
	Trumpet	0	115	57	Sweet!	
	Trumpet Shake SW	8	35	65	S.Art!	
	Mellow Trumpet	0	120	57	Sweet!	
	Silver Trumpet	0	121	57	Sweet!	
	Muted Cornet	104	0	60	Sweet!	
	Golden Trumpet	0	122	57	Sweet!	
	Baritone Horn	0	113	59	Regular	
	Tuba	104	0	59	Regular	
	Bright Trombone	104	0	58	Sweet!	
	Baritone Hit	0	114	59	Regular	
	Alp Bass	0	113	34	Regular	
	Brass Ensemble	Pop Horns Cresc SW	8	45	57	S.Art!
		Pop Horns Swell SW	8	48	57	S.Art!
		Orchestral Trumpets	104	3	57	Live!
		Orchestral Trombones	104	3	58	Live!
		Trumpets & Trombones	104	9	62	Live!
		Trumpets & Trombones Oct	104	10	62	Live!
		Symphony Horns	104	1	61	Live!
		Orch Brass Octave	104	12	62	Live!
		Symphony Horns Octave	104	2	61	Live!
		Warm Orch Horns	8	33	61	S.Art!
		Symphony Brass	104	8	62	Live!
		Stopped Orch Horns	104	3	61	Live!
		Pop Horns Dynamic	104	0	62	Live!
Pop Horns Dynamic Shake		104	4	62	Live!	
Pop Horns Mellow		8	43	57	S.Art!	
Pop Horns Bright		8	44	57	S.Art!	
Pop Horns Accent		104	3	62	Live!	
Pop Horns Cresc		104	5	62	Live!	
Pop Horns Doit SW		8	46	57	S.Art!	
Pop Horns Fall SW		8	47	57	S.Art!	
Warm Swing Horns		104	1	62	Live!	
Mute Swing Horns		104	2	62	Live!	
Orch Trumpets Fast		104	4	57	Live!	
Orch Trombones Fast		104	4	58	Live!	
Orch Horns Fast		104	4	61	Live!	
Orch Horns & Trombones		104	13	62	Live!	
Symphony Horns Fast		104	15	62	Live!	
Orch Horns Pad		104	11	62	Live!	
Warm Pop Horns		8	41	57	S.Art!	
Bright Horn Section		8	42	57	S.Art!	
Ballad Brass		104	6	62	Live!	
Brass Band		104	14	62	Live!	
Orchestral Horns		104	0	61	Live!	
Big Band Brass SW		8	37	57	S.Art!	
Soft Orch Horns		8	32	61	S.Art!	
Smooth Brass		8	36	57	S.Art!	
Dynamic Brass		0	127	62	Live!	
Power Brass		0	121	63	Live!	
Accent Brass		0	109	62	Live!	
Brass Falls & Doits SW		8	34	57	S.Art!	
Muted Horns		8	34	61	S.Art!	
Brass Falls mf SW		8	35	57	S.Art!	
Brass f		0	108	62	Live!	
Brass Band 2		0	123	57	Live!	
Brass mf		0	110	62	Live!	
Soft Horns		0	117	61	Live!	
Brass p		0	111	62	Live!	
Soft Trombones		0	118	61	Live!	
Brass Shake SW		8	32	57	S.Art!	
Pop Brass		0	117	63	Live!	

Main Category: Brass & Woodwind

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Brass Ensemble	Accent Falls SW	8	38	57	S.Art!	
	Hyper Brass	0	118	63	Live!	
	Sforzando	0	105	62	Live!	
	Small Brass	0	120	61	Live!	
	Sforzando Fall	0	107	62	Live!	
	Ballroom Brass	0	113	60	Regular	
	Brass Dynamics	0	106	62	Live!	
	Octave Brass	0	116	63	Live!	
Sax Solo	Saxophone	8	32	83	S.Art!	
	Clean Alto Sax	8	32	67	S.Art!	
	Big Band Sax	8	35	83	S.Art!	
	Soft Alto Sax	8	34	67	S.Art!	
	Rock Sax SW	8	33	83	S.Art!	
	Growl Sax	0	111	67	Sweet!	
	Soprano Sax	0	113	65	Sweet!	
	Pop Tenor Sax	0	127	67	Sweet!	
	Pop Alto Sax	104	0	66	Sweet!	
	Ballad Tenor Sax	0	126	67	Sweet!	
	Breathy Tenor Sax	0	117	67	Sweet!	
	Sweet Tenor Sax	0	125	67	Sweet!	
	Baritone Sax 1	104	0	68	Regular	
	Sax Ensemble	Sax Section	0	116	67	Live!
		Big Band Octave	0	108	67	Live!
Smooth Saxes 1		8	38	83	S.Art!	
Big Band Horns 1		0	110	67	Live!	
Smooth Saxes 2		8	36	83	S.Art!	
Big Band Horns 2		0	109	67	Live!	
Sax Section Octave		8	37	83	S.Art!	
Ballad Section		0	119	67	Regular	
Mellow Saxes		8	39	83	S.Art!	
Sax Appeal		0	123	67	Live!	
Sax Section Hard		0	122	67	Live!	
Moonlight		0	115	72	Regular	
Sax Section Soft		0	121	67	Live!	
Woodwind Solo	Orchestral Flute	8	32	74	S.Art!	
	Jazz Flute	0	114	74	Sweet!	
	MOR Oboe	8	32	69	S.Art!	
	Orchestral Clarinet	104	0	72	Live!	
	Jazz Clarinet	0	114	72	Sweet!	
	German Clarinet	104	2	72	Regular	
	Orchestral Bassoon	104	0	71	Sweet!	
	Classical Flute	0	115	74	Sweet!	
	Classical Oboe	0	113	69	Sweet!	
	Piccolo	0	112	73	Regular	
	English Horn	0	112	70	Regular	
	Woodwind Ens	Flutes & Oboes	104	2	74	Regular
Orchestral Woodwind		104	1	71	Regular	
Clarinet & Flutes		104	1	72	Regular	
Flute Section		104	1	74	Regular	
Clarinet & Oboe		104	1	69	Regular	
Flute Ensemble		0	116	74	Regular	
Woodwind World	Oboe & Bassoon	104	2	69	Regular	
	Pan Pipes	0	113	76	Sweet!	
	Ocarina	0	112	80	Regular	
	Celtic Duo	0	120	74	Regular	
	Shakuhachi	0	112	78	Regular	
	Bagpipe	0	112	110	Regular	
	Recorder	0	112	75	Regular	
	Whistle	0	112	79	Regular	
	Chiff Pan Flute	0	113	74	Regular	

CSP-295GP, CSP-295

Main Category: Perc & Drums

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Chromatic Perc	*1 Vibraphone	104	1	12	Sweet!	
	Xylophone	104	0	14	Regular	
	Jazz Vibraphone	0	113	12	Regular	
	Marimba	104	0	13	Regular	
	Tremolo Vibraphone	0	124	12	Natural!	
	Orchestral Marimba	0	122	13	Natural!	
	Vibraphone & Jazz Guitar	8	33	12	S.Art!	
	Glockenspiel	104	0	10	Regular	
	Vibraphone & Flutes	0	114	12	Regular	
	Steel Drums	0	112	115	Regular	
	Concert Vibraphone	0	122	12	Natural!	
	Steel Drums	0	122	115	Natural!	
	Music Box	0	112	11	Regular	
	Kalimba	0	112	109	Regular	
	Orchestral Harp	104	1	47	Regular	
	Tubular Bells	0	112	15	Regular	
	Mellow Harp	104	0	47	Regular	
	Timpani	0	112	48	Regular	
	Celesta	0	112	9	Regular	
	Orchestra Hit	0	112	56	Regular	
Concert Celesta	0	122	9	Natural!		
Drum Kits	Rock Drum Kit	127	0	18	Live!Drums	
	Real Brushes Kit	127	0	42	Live!Drums	
	Pop Drum Kit	127	0	74	Live!Drums	
	Jazz Kit	127	0	33	Drums	
	Real Drum Kit	127	0	92	Live!Drums	
	Rock Kit	127	0	91	Live!Drums	
	Acoustic Kit	127	0	90	Live!Drums	
	Studio Kit	127	0	87	Live!Drums	
	Jazz Brush Kit Comp	127	0	76	Live!Drums	
	Symphony Kit	127	0	49	Live!Drums	
	House Kit	127	0	61	Drums	
	EDM Kit	127	0	70	Drums	
	Hit Kit	127	0	5	Drums	
	Dubstep Kit	127	0	69	Drums	
	Electro Kit	127	0	71	Drums	
	Trap Kit	127	0	72	Drums	
	Schlager Kit	127	0	73	Drums	
	Power Kit 1	127	0	88	Live!Drums	
	Room Kit	127	0	9	Drums	
	Power Kit 2	127	0	89	Live!Drums	
	Drum Machine	127	0	62	Drums	
	Dance Kit	127	0	28	Drums	
	Analog T8 Kit	127	0	59	Drums	
	Electro Kit 2	127	0	25	Drums	
	Analog T9 Kit	127	0	60	Drums	
	Analog Kit	127	0	26	Drums	
	Break Kit	127	0	58	Drums	
	Bass Drum Kit	126	0	21	SFX	
	Hip Hop Kit	127	0	57	Drums	
	Reverse Bass Drum Kit	126	0	22	SFX	
	Cymbal Kit	126	0	50	Live!SFX	
	World Perc Kits	Pop Percussion Kit	126	0	46	Live!SFX
		Turkish Kit	126	0	68	Live!SFX
Pop Latin Kit 1		126	0	44	Live!SFX	
Cuban Kit		126	0	41	Live!SFX	
Vocal Effects	Pop Latin Kit 2	126	0	45	Live!SFX	
	Vocal Beatbox	126	0	107	Live!SFX	
	Gospel AdLibs	126	0	111	Live!SFX	
SFX	Vocal Effects Kit	126	0	110	Live!SFX	
	New SFX Kit 1	126	0	3	Live!SFX	
	Helicopter	104	0	126	Live!	
	New SFX Kit 2	126	0	4	Live!SFX	
	Applause 1	104	0	127	Live!	
	Noises Kit	126	0	9	SFX	
	Applause 2	104	1	127	Live!	
	Sea Shore	104	0	123	Live!	
Gun Shot	104	0	128	Live!		

Voices marked with "*1" can be selected from the instrument.

Main Category: Synth

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Synth Lead	Square Stack SW	8	32	124	S.Art!
	Nasty Saw	104	10	91	Regular
	Growling Hook	104	11	91	Regular
	Loony Lead	104	15	91	Regular
	Ten Percent	104	18	91	Regular
	Cool HiPa SW	8	34	124	S.Art!
	Wheel Tech SW	8	36	124	S.Art!
	Redoubling SW	8	37	124	S.Art!
	Hard Teeth	104	16	91	Regular
	Cyclist	104	17	91	Regular
	Crowds	104	19	91	Regular
	Gemini	104	20	91	Regular
	Hands Up!	104	21	91	Regular
	Straight Raver	104	22	91	Regular
	Trance Artist	104	23	91	Regular
	Punchy Chordz	104	24	91	Regular
	Trancy Chordz	104	25	91	Regular
	Trancy Noise	104	1	123	Regular
	Unison Strings	104	9	51	Regular
	Med Det Strings	104	10	51	Regular
	Four Stack SW	8	33	124	S.Art!
	Nu Line SW	8	35	124	S.Art!
	Yipping	104	12	91	Regular
	Unstable Lead	104	13	91	Regular
	Persecutor	104	14	91	Regular
	Short Unison	104	4	85	Regular
	Brite Decay	104	5	85	Regular
	Tekk Tune	104	6	85	Regular
	Staccato Melody	104	7	85	Regular
	Pitchy Patch	104	8	85	Regular
	Soft Chord Synth	104	9	85	Regular
	Chord Buddy	104	10	85	Regular
	Tune Comp	104	11	85	Regular
	Arpeggio Line	104	12	85	Regular
	Soft Stepper	104	24	89	Regular
	PWM Picks	104	25	89	Regular
	Square Stepz	104	26	89	Regular
	Dyna Sequence	104	27	89	Regular
	Lektro Codes	104	2	85	Regular
	Cracky	104	29	89	Regular
	Sub Lead	104	0	81	Regular
	Wire Lead	0	120	82	Regular
	Soft Saw	104	16	82	Regular
Soft R&B	0	119	81	Regular	
Fusion Lead	104	15	82	Regular	
Early Lead	0	118	82	Regular	
Synth Perc	New Heaven	104	10	89	Regular
	Heaven Pad	104	3	92	Regular
	Fantasy Bells	104	11	89	Regular
	Breath Bells	104	15	89	Regular
	ltopia Bells	104	13	89	Regular
	Next Generation	104	9	52	Regular
	Sinesphere	104	18	89	Regular
	Organ Bells	104	12	89	Regular
	Spectrum Theme	104	14	89	Regular
	Sky Bells	104	16	89	Regular
	Flying Harmonics	104	1	100	Regular
	Perc Pad	104	0	102	Regular
	Nylon Heaven	104	2	100	Regular
	Mediterrain	0	114	100	Regular
	Nylon Pad	104	0	100	Regular
	Tri Picks	104	28	89	Regular
	Airy Harp	104	17	89	Regular
	Simple Comp	104	12	82	Regular
	Bellsphere	104	5	89	Regular
	Ballad Comp	104	6	89	Regular
Heaven Bell	104	0	101	Regular	
Digital Sequenced	104	2	88	Regular	
Bright Pad Bell	104	7	89	Regular	
Analog Sequenced	104	3	88	Regular	

CSP-295GP, CSP-295

Main Category: Synth

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Synth Perc	PWM Wild	104	4	81	Regular	
	Perc Sequence FS	104	6	88	Regular	
	Resonant Clavi	104	2	91	Regular	
	Perc Sequence FM 1	104	7	88	Regular	
	Resonance Comp	104	4	63	Regular	
	Perc Sequence FM 2	104	8	88	Regular	
Synth Strings	Synth Strings 1	0	112	51	Regular	
	Butter Strings	104	2	51	Regular	
	Synth Strings 2	0	113	51	Regular	
	Bright Saw Pad	0	113	91	Regular	
	Ober Strings	0	113	52	Regular	
	Soft Ensemble	104	1	51	Regular	
	Hipa Strings	0	114	96	Regular	
	80s Pad	104	1	52	Regular	
	Octave Strings	104	4	51	Regular	
	Bright Pop Pad	104	3	51	Regular	
	Doux Flange	104	3	96	Regular	
	Premium Pad	104	0	52	Regular	
	Light Pad	104	2	52	Regular	
	Bright Pad Classic	104	3	91	Regular	
	Medium Tune Pad	104	0	51	Regular	
	Synth Brass	Analog Brass	0	112	64	Regular
		1984 Synth	104	20	82	Regular
		Fat Synth Brass	0	116	64	Regular
80s Brass		0	113	63	Regular	
80s Synth Brass Thin		104	0	63	Regular	
Funky Analog		0	115	63	Regular	
80s Synth Brass Prof		104	1	63	Regular	
Techno Brass		0	114	63	Regular	
Ober Brass		0	113	64	Regular	
Ober Horns		0	115	64	Regular	
Slow PWM Brass		104	2	63	Regular	
Soft Velocity Brass		0	120	63	Regular	
Fast PWM Brass		104	6	63	Regular	
Soft Analog		0	114	64	Regular	
Synth Pad		All or Nothing	104	6	102	Regular
	Whisper Gallery	104	0	93	Regular	
	Digisweeper	104	7	102	Regular	
	Hybrid Lines	104	4	92	Regular	
	Spectrum Pad	104	5	95	Regular	
	Midnight Special	104	3	102	Regular	
	Hybrid Pad	104	22	89	Regular	
	Atmosphere 5th	104	6	90	Regular	
	Deep Motion	104	4	96	Regular	
	Pad Voices	104	6	96	Live!	
	Skydiver	0	112	102	Regular	
	Aerosphere	104	1	95	Regular	
	Cross Phase	104	1	102	Regular	
	New Atmosphere	104	4	90	Regular	
	Galaxy Pad	104	3	89	Regular	
	VP Soft	104	0	90	Regular	
	Night Motion	104	4	89	Regular	
	Hot Swell	104	2	96	Regular	
	Morning Dew	104	0	95	Regular	
	Dark Fat Saw	104	2	90	Regular	
	Vapor Pad	104	1	90	Regular	
	Dark Light	104	3	90	Regular	
	Space Rider	104	1	96	Regular	
	Ambient Pad	104	0	89	Regular	
	Pearls Pad	104	2	89	Regular	
	Bright Fat Saw	104	5	91	Regular	
	Breath Pad	104	0	92	Regular	
	Early Digital	104	0	94	Regular	
	Noble Man	104	1	89	Regular	
	Super Dark Pad	0	119	90	Regular	
	Analog Pad	0	120	90	Regular	
	Analog Swell	0	119	96	Regular	
	Dark Angel Pad	0	121	90	Regular	
	Big Octave Pad	0	115	91	Regular	
	Lite Pad	0	122	90	Regular	

Main Category: Synth

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Synth Pad	Golden Age	0	115	89	Regular
	Pop Pad	0	112	91	Regular
	Solaris	0	114	95	Regular
	Glorious Phase	0	114	91	Regular
	Insomnia	0	113	95	Regular
Synth Dance	Ana Dayz	104	3	52	Regular
	HPF Dance	104	0	91	Regular
	Bright Pad Trance	104	4	91	Regular
	Detuned Saw Octave	104	8	82	Regular
	Chillin Chords	104	6	52	Regular
	Dancy Hook	104	9	82	Regular
	Trance	104	0	96	Regular
	Vinalog Saw	104	3	82	Regular
	Club Lead	104	3	63	Regular
	Talk Mod Lead	104	0	88	Regular
	Trance Perc	104	5	82	Regular
	Chorus Saw Lead	104	10	82	Regular
	Chordmaster	104	13	82	Regular
	Faat Comp	104	4	52	Regular
	Trance Sequence 1	104	4	88	Regular
	Fat Saw Hook	104	7	52	Regular
	Trance Sequence 2	104	5	88	Regular
	Synth Effects	Tech Glide	104	14	82
Trance Sequence 3		104	1	91	Regular
Dance Chords		104	5	52	Regular
Dance Hook		0	112	87	Regular
Trance Lead		0	121	81	Regular
Octave Hook		0	113	87	Regular
Water Games		104	4	102	Regular
Spectralis		104	4	95	Regular
My Generation		104	5	102	Regular
Metallic Rain		104	8	102	Regular
Rainy Day		104	5	90	Regular
Ambient Theme		104	20	89	Regular
Warped Waves		104	2	95	Regular
Reflecting Zone		104	21	89	Regular
Sound Pictures		104	3	95	Regular
The Fog	104	9	102	Regular	
Mystic Pad	104	6	95	Regular	
Sixth Sense	104	2	102	Regular	
Randomizer	104	10	102	Regular	
Pitch Fall	104	0	104	Regular	
Atlantis	104	11	102	Regular	
Perc Sequence Hipa	104	9	88	Regular	
Tric-Trac	104	2	98	Regular	

CSP-275, CSP-255

Main Category: Piano

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Grand Piano	*1 CFX Grand	108	0	1	VRM	
	*1 Bösendorfer	108	6	1	VRM	
	Stage Piano	108	31	1	VRM	
	Pop Grand	108	17	2	VRM	
	Studio Grand	108	30	1	VRM	
	Rock Piano	108	16	3	VRM	
	Themic Grand	108	6	2	VRM	
	CFX 1Octave	108	22	2	VRM	
	Ambient Piano	108	27	4	VRM	
	CFX 2Octaves	108	23	2	VRM	
	Mellow Piano	108	18	1	VRM	
	Bright Piano	108	16	2	VRM	
	CFX Cocktail Piano	108	28	4	VRM	
	Upright Piano	*1 Concert Upright	108	5	3	VRM
		Honky Tonk Upright	104	13	4	Natural!
School Upright		104	13	1	Natural!	
Saloon Upright		104	14	2	Natural!	
Pop Upright		104	13	2	Natural!	
Upright 1Octave		104	14	4	Natural!	
70s Ballad Upright		104	14	1	Natural!	
Upright 2Octaves		104	15	4	Natural!	
Chillout Upright		104	15	1	Natural!	
Piano Layer	CFX Superstar Grand	108	25	5	Natural!	
	Imperial Cosmos	104	42	1	Natural!	
	CFX Fat Pad	104	43	1	Natural!	
	Imperial Ballad	108	26	5	Natural!	
	CFX DX Layer	108	33	3	Natural!	
	Bösendorfer DX Layer	108	34	3	Natural!	
	CFX & Strings	108	23	1	Natural!	
	Upright Synthetics	104	21	4	Natural!	
	Piano & EP 1	108	25	3	Natural!	
	Piano & EP 2	108	26	3	Natural!	
	MIDI Grand	104	2	3	Natural!	
	MIDI Grand Pad	104	3	3	Natural!	
	Electric Piano	Suitcase Hard	104	16	5	Cool!
Suitcase Warmth		104	14	5	Cool!	
Suitcase Soft		104	7	5	Cool!	
Suitcase Phaser		104	10	5	Cool!	
Suitcase Ballad		104	9	5	Cool!	
Suitcase Tremolo		104	12	5	Cool!	
Suitcase Drive		104	11	5	Cool!	
*1 Vintage EP		104	8	5	Cool!	
*1 Suitcase Jazz		104	13	5	Cool!	
Vintage EP Drive		104	15	5	Cool!	
CP80 Studio		0	123	3	Natural!	
Suitcase Sweep Swell		104	33	5	Cool!	
Suitcase String Machine		104	34	5	Cool!	
CP80 Honky Tonk		104	15	3	Cool!	
Ballad Epic EP		104	35	5	Cool!	
FM E.Piano		DX Sweet	104	0	6	Cool!
		TX Bright	104	10	6	Cool!
	*1 DX Dynamic	0	123	6	Cool!	
	TX Mellow	104	11	6	Cool!	
	DX Ballad	0	124	6	Cool!	
	TX Warm	104	12	6	Cool!	
	DX Ballad Bells	104	2	6	Cool!	
	DX Dream	104	3	6	Cool!	
	DX Midnight	104	1	6	Cool!	
	Studio Ballad DX	104	9	6	Regular	
	Clavi	Clavi SW	8	33	21	S.Art!
Clavi Funk SW		8	34	21	S.Art!	
Clavi Bright		0	112	8	Regular	
Wah Clavi		0	113	8	Regular	
Clavi Warm		0	122	8	Natural!	
Clavi Funk		0	123	8	Natural!	
Clavi Drive SW		8	36	21	S.Art!	
Clavi Phase		0	115	8	Regular	

Voices marked with "*1" can be selected from the instrument.

Main Category: Piano

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Harpichord	*1 Harpichord 1	0	122	7	Natural!
	Grand Harpichord	0	113	7	Live!
	Harpichord 2 SW	8	32	113	S.Art!
	Harpichord Coupler	0	123	7	Natural!
	Harpichord 3	0	125	7	Natural!
	Harpichord & Strings	0	124	7	Natural!

Main Category: Organ

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Tonewheel Organ	*1 Jazz Rotary SW	8	32	114	S.Art!
	Curved Bars	0	121	17	Cool!
	Whiter Bars SW	8	32	30	S.Art!
	Even Bars	0	111	17	Cool!
	Classic Bars SW	8	34	30	S.Art!
	Hollow Bars	0	127	17	Cool!
	Rock Organ SW	8	33	114	S.Art!
	Classic Scanner	0	118	19	Cool!
	All Bars Out SW	8	32	31	S.Art!
	Organ A Go Go	104	0	17	Cool!
	Classic Jazz	0	117	17	Cool!
	Vintage Accomp 1	0	108	18	Regular
	Hold It Fast	0	111	18	Cool!
	Vintage Accomp 2	0	107	18	Regular
	R&B Tremolo Organ	0	111	19	Cool!
	Vintage Accomp 3	0	106	18	Regular
	Prog Rock Organ SW	8	33	30	S.Art!
	Vintage Accomp 4	0	105	18	Regular
	Full Rocker	0	115	19	Cool!
	Vintage Accomp 5	0	104	18	Regular
	Whiter Bars Slow	104	1	18	Cool!
	Whiter Bars Fast	104	0	18	Cool!
	Jazz Organ Slow	0	126	18	Cool!
	Jazz Organ Fast	0	127	18	Cool!
	All Bars Out Slow	104	1	19	Cool!
	All Bars Out Fast	104	0	19	Cool!
	All Bars Phase	104	2	19	Cool!
	Rotary Organ	0	117	19	Cool!
	Mellow Vintage	0	115	18	Regular
	Two Channels Organ	0	109	18	Cool!
Transistor Organ	60s Combo Organ 1	104	32	17	Cool!
	Euro Accomp 1	104	33	18	Regular
	60s Combo Organ 2	104	33	17	Cool!
	Euro Accomp 2	104	34	18	Regular
	60s Combo Organ 3	104	34	17	Cool!
	Euro Accomp 3	104	35	18	Regular
	60s Combo Organ 4	104	35	17	Cool!
	Home Accomp 1	104	37	19	Regular
	Home Organ Clarinet	104	20	19	Regular
	Home Accomp 2	104	38	19	Regular
Classical Pipe	Home Organ Cello	104	21	19	Regular
	Home Organ E.Horn	104	22	19	Regular
	Home Organ Cornet	104	23	19	Regular
	Home Organ Violin	104	24	19	Regular
	Home Organ Kinura	104	25	19	Regular
	Home Organ Trombone	104	19	19	Regular
	Lieblich Gedackt	104	6	20	Regular
	Fonds Et Anches	104	2	20	Live!
	Diapason	104	4	20	Regular
	Organo Pleno	104	3	20	Live!
Classical Pipe	Claribel & Flute	104	5	20	Regular
	Concert Organ Tutti	104	0	20	Live!
	Soft Reeds	104	7	20	Regular
	Chapel Organ 1	0	113	20	Regular
	Grand Jeu	104	1	20	Live!
	Chapel Organ 2	0	115	20	Regular
	*1 Pipe Organ Principal	0	123	20	Natural!
	Pipe Organ Tutti 1	0	126	20	Natural!

CSP-275, CSP-255

Main Category: Organ

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Classical Pipe	Pipe Organ 8'	0	124	20	Natural!
	Pipe Organ Tutti 2	0	122	20	Natural!
	Pipe Organ Twelfth	0	125	20	Natural!
	Full Organ	0	112	20	Regular
Theatre Pipe	Theatre Tibia & Vox	104	28	19	Regular
	Theatre Gamba Celeste	104	30	19	Regular
	Theatre Open Tibias	104	29	19	Regular
	Theatre Seaside	104	26	19	Regular
	Theatre Organ Mix 1	104	31	19	Regular
	Theatre Flute Accomp	104	34	19	Regular
	Theatre Organ Mix 2	104	32	19	Regular
	Theatre Strings Accomp	104	35	19	Regular
	Theatre Organ Mix 3	104	33	19	Regular
	Theatre Chrys Accomp	104	36	19	Regular
	Theatre Chrysoglott	104	28	18	Regular
	Theatre Organ Chimes	104	31	18	Regular
	Theatre Xylophone	104	30	18	Regular
	Theatre Wooden Harp	104	32	18	Regular
	Theatre Glockenspiel	104	29	18	Regular
	Theatre Pedal 1	104	16	19	Regular
	Theatre Trumpet	0	124	17	Regular
	Theatre Pedal 2	104	17	19	Regular
Organ Flutes	Jazz Standard	10	0	1	OrganFlutes
	Rock Organ	10	3	1	OrganFlutes
	Jazz Squabble	10	7	1	OrganFlutes
	Gospel Organ	10	4	1	OrganFlutes
	Upside Down Smile	10	1	1	OrganFlutes
	Organ Pops	10	2	1	OrganFlutes
	Ballad Organ	10	5	1	OrganFlutes
	Euro Percussion	10	0	3	OrganFlutes
	Organ Clarinet	10	6	1	OrganFlutes
	Euro Pops	10	5	3	OrganFlutes
	Euro Reeds	10	2	3	OrganFlutes
	Euro Bright	10	4	3	OrganFlutes
	Euro Melodic	10	7	3	OrganFlutes
	Home Organ Jazz	10	3	2	OrganFlutes
	Euro Full	10	6	3	OrganFlutes
	Home Hollow Tibias	10	4	2	OrganFlutes
	Euro Ballad	10	1	3	OrganFlutes
	Home Theatre Organ	10	2	2	OrganFlutes
	Euro Even Warmth	10	3	3	OrganFlutes
	Home 16 & Odds	10	1	2	OrganFlutes
Home Organ Ballad	10	0	2	OrganFlutes	
Home Organ Warmth	10	6	2	OrganFlutes	
Home Organ Evens	10	5	2	OrganFlutes	
Home Organ Full	10	7	2	OrganFlutes	
Harmonica	Harmonica	0	112	23	Sweet!
	Modern Harp	0	113	23	Regular
	Blues Harp	0	114	23	Regular
Accordion	Full Register	104	2	22	Regular
	Accordion Clarinet	104	1	22	Regular
	French Musette Acc.	0	119	22	Regular
	Tango Accordion	0	114	24	Regular
	Master Accordion	0	118	22	Regular
	Cajun Accordion	104	3	22	Regular
	Jazz Accordion	0	120	22	Regular
	Steirische	0	117	22	Regular
	Cassotto	104	0	22	Regular
	Bandoneon	0	113	24	Regular
	Full Register Bass	104	5	22	Regular
	Accordion Bass	0	121	22	Regular
	Musette Bass	0	123	22	Regular
	Tango Accordion Bass	0	115	24	Regular
	Master Bass	0	122	22	Regular
	Cajun Accordion Bass	104	6	22	Regular

Main Category: Guitar & Bass

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Nylon Acoustic	Flamenco Guitar	8	35	2	S.Art!	
	Spanish Guitar	8	34	2	S.Art!	
	Spanish Electro	8	36	2	S.Art!	
	Spanish Guitar Slide	104	9	26	Live!	
	Concert Guitar	8	32	1	S.Art!	
	Dynamic Nylon Guitar	0	116	25	Live!	
	Hard Flamenco	0	118	25	Live!	
	Nylon Guitar SW	8	34	1	S.Art!	
	Classical Guitar	0	115	25	Live!	
	Nylon Guitar Slide	0	117	25	Live!	
	Nylon Mute	0	119	25	Live!	
	Electro Acoustic Guitar	8	35	1	S.Art!	
	Steel Acoustic	Steel Acoustic Pick	8	37	2	S.Art!
		Steel Acoustic Strum	104	10	26	Live!
		Steel Guitar Twin 1	104	12	26	Live!
Steel Guitar Twin 2		104	13	26	Live!	
Chicken Pick Guitar		104	11	26	Live!	
12String Picked		8	39	2	S.Art!	
Steel Guitar		8	32	2	S.Art!	
Steel Guitar Slide		0	118	26	Live!	
Folk Gt Harmonics SW		8	33	2	S.Art!	
Dynamic Steel Guitar		0	116	26	Live!	
Steel Guitar Strum		0	117	26	Live!	
Steel Guitar Mute		0	120	26	Live!	
12String Guitar	0	113	26	Live!		
Clean Solid	Shadowed Guitar	8	56	4	S.Art!	
	Oldies Guitar	8	52	6	S.Art!	
	Finger Slap Slide SW	8	51	4	S.Art!	
	Rough Fingers	8	39	5	S.Art!	
	Clean Fingers	8	38	5	S.Art!	
	Country Pick Drive	8	40	5	S.Art!	
	Country Pick Vintage	8	41	5	S.Art!	
	Bluesy Fingers	8	37	5	S.Art!	
	70s Jazz Combo	8	54	6	S.Art!	
	Warm Solid	8	33	4	S.Art!	
	Single Coil Clean	8	39	4	S.Art!	
	Clean Solid	8	34	4	S.Art!	
	Vintage Slap	8	48	4	S.Art!	
	Ballad Delay	8	46	4	S.Art!	
	Jazz Guitar Amp	8	38	7	S.Art!	
	Jazz Artist Guitar	8	39	7	S.Art!	
	Slide Clean	0	117	29	Cool!	
	Slide Warm	104	6	28	Cool!	
	Slide Pick	104	7	28	Cool!	
	Jazz Guitar Clean	8	32	7	S.Art!	
	Country Pick	8	44	4	S.Art!	
	Jazz Solo Guitar	0	116	27	Cool!	
	Semi Acoustic	8	33	7	S.Art!	
	Electric Guitar	0	114	29	Cool!	
	Chorus Solid	0	107	28	Cool!	
	Dynamic Mute	0	118	29	Cool!	
	Cool Wah Guitar	104	4	28	Regular	
Slap Solid	0	108	28	Cool!		
Slapback	104	0	28	Cool!		
Jazz Guitar Smooth SW	8	35	7	S.Art!		
Lounge Guitar	104	1	27	Regular		
Vintage Muted Guitar	104	0	29	Cool!		
50s Vintage Mute	0	115	29	Regular		
Vintage Open	0	123	28	Regular		
Vintage Strum	0	126	28	Regular		
Funk Guitar	0	116	29	Cool!		
Slide Jazz	104	0	27	Cool!		
Jazz Guitar	0	115	27	Cool!		
60s Clean	0	117	28	Regular		
Distortion Solid	Solo King	8	50	6	S.Art!	
	Rhythm King	8	53	6	S.Art!	
	50s Vintage Full	8	43	6	S.Art!	
	50s Heavy Rock	8	47	6	S.Art!	
	50s Drive Wah Wah	8	46	6	S.Art!	
	Rock Hero	8	35	6	S.Art!	

CSP-275, CSP-255

Main Category: Guitar & Bass

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Distortion Solid	Stage Lead	8	38	6	S.Art!	
	Grunge Guitar	8	40	6	S.Art!	
	Big Amp Combo	8	51	6	S.Art!	
	50s Vintage Warm	8	49	6	S.Art!	
	Overdrive Wah Wah	8	39	6	S.Art!	
	50s Vintage Amp	8	41	4	S.Art!	
	Rock Legend	8	34	6	S.Art!	
	Finger Amp	8	43	4	S.Art!	
	50s Vintage Rock	8	36	6	S.Art!	
	Guitar Hero	8	32	6	S.Art!	
	Half Drive	8	37	4	S.Art!	
	Classic Amp Stack	8	41	6	S.Art!	
	Crunch Guitar	8	33	6	S.Art!	
	Heavy Rock Guitar	8	32	5	S.Art!	
	Bluesy Night	8	55	4	S.Art!	
	Stereo Rock Guitar	104	2	31	Cool!	
	Bright Blues	8	35	5	S.Art!	
	Feedbacker SW	8	33	5	S.Art!	
	Power Lead	0	115	31	Cool!	
	Vintage Amp	0	115	30	Regular	
	Vintage Lead	0	125	28	Cool!	
	Crunch Guitar	0	113	31	Regular	
	World	Pedal Steel Amp	8	52	4	S.Art!
		Mandolin	0	114	26	Sweet!
		Pedal Steel Guitar	8	36	4	S.Art!
Zither 1		104	1	16	Regular	
Banjo		104	0	106	Regular	
Zither 2		104	0	16	Regular	
Shamisen		0	112	107	Regular	
Dulcimer		0	112	16	Regular	
Koto		0	112	108	Regular	
Hackbrett		104	2	47	Regular	
Aloha Guitar		0	118	27	Regular	
Sitar		104	0	105	Regular	
Bass		Vintage Round Bass	8	32	18	S.Art!
	Acoustic Bass	8	32	17	S.Art!	
	Vintage Flatwound Bass	8	33	18	S.Art!	
	Soft Acoustic Bass	8	33	17	S.Art!	
	Vintage Mute Bass	8	32	19	S.Art!	
	Acoustic Bass & Cymbal	0	114	33	Regular	
	Vintage Pick Bass	104	1	35	Regular	
	Fusion Bass	0	113	37	Regular	
	Fretless Bass	8	32	20	S.Art!	
	Slap Bass	0	112	37	Regular	
	Vintage Round Bass	104	1	34	Cool!	
	Acoustic Bass 2	104	1	33	Regular	
	Vintage Flatwound Bass	104	2	34	Cool!	
	Soft Acoustic Bass	104	2	33	Regular	
	Vintage Mute Bass	104	3	34	Cool!	
	Ballroom Bass	104	0	33	Regular	
	Vintage Pick Mute Bass	104	0	35	Cool!	
	Half Mute Bass	0	115	34	Cool!	
	Fretless Bass	0	112	36	Cool!	
	Vintage Dyno Bass	104	2	35	Cool!	
	Rock Bass	0	114	35	Regular	
	Electric Bass	0	114	34	Cool!	
	Pick Dyno Bass	0	113	35	Cool!	
	Mellow Finger Bass	0	112	34	Regular	
	Super Fretless Bass	0	113	36	Regular	
	Pick Bass	0	112	35	Regular	
	Funk Bass	0	112	38	Regular	
	Synth Bass	BPF Buzz SW	8	32	123	S.Art!
		Wobble SW	8	33	123	S.Art!
		Ramp Bass SW	8	34	123	S.Art!
		Square Pluck SW	8	35	123	S.Art!
		Deep Sub	104	18	88	Regular
		Modern Pop	104	19	88	Regular
Multi Saw Bass		104	20	88	Regular	
Brite Dub Bass		104	21	88	Regular	
Twenty Five		104	23	88	Regular	

Main Category: Guitar & Bass

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Synth Bass	Punchy Square	104	24	88	Regular
	Punchy DX	104	26	88	Regular
	Dark Sequence Bass	104	27	88	Regular
	Pumping Saw	104	28	88	Regular
	Pumping Square	104	29	88	Regular
	Lo Bass	104	0	40	Regular
	Fat Pulse	104	2	40	Regular
	Dark Bass	104	1	40	Regular
	Wazzo Saw	104	3	81	Regular
	Moon Bass	104	0	39	Regular
	Kick Bass	104	1	39	Regular
	Tight Bass	104	3	40	Regular
	Competitor	104	4	39	Regular
	Trance Bass	104	9	39	Regular
	Little Bass Synth	104	6	39	Regular
	Sub Cut Bass	104	5	40	Regular
	Tekno Bass	104	7	39	Regular
	Dyno Acid Bass	104	10	39	Regular
	Perc Punch	104	8	39	Regular
	Square Bass	104	4	40	Regular
	Fat Sine Resonance	104	11	39	Regular
	Ballad Bass	104	7	40	Regular
	House Bass	0	116	39	Regular
	Velo Master	104	17	82	Regular
	Big Drone	0	118	39	Regular
Sub Bass	0	114	40	Regular	
Resonance Bass	0	112	39	Regular	
TB Bass	0	117	40	Regular	

Main Category: Strings & Vocal

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
String Solo	Orchestral 1st Violin	8	33	44	S.Art!	
	Hoedown Violin	0	113	41	Sweet!	
	Orchestral 2nd Violin	8	33	45	S.Art!	
	Country Fiddle	0	112	111	Regular	
	Orchestral Viola	8	33	46	S.Art!	
	Viola	0	112	42	Regular	
	Orchestral Cello	8	33	47	S.Art!	
	Cello	0	122	43	Natural!	
	Seattle Quartet	8	34	48	S.Art!	
	Contrabass	0	112	44	Regular	
	String Ensemble	Seattle Romance	8	43	50	S.Art!
		Pizzicato Strings	0	113	46	Live!
		Concert Strings	8	32	50	S.Art!
Seattle Tremolo Strings		104	0	45	Live!	
Seattle Spiccato		104	6	49	Live!	
Seattle String Pad		8	43	49	S.Art!	
Classic 1st Violins		8	34	44	S.Art!	
Classic 2nd Violins		8	34	45	S.Art!	
Classic Violas		8	34	46	S.Art!	
Classic Cellos		8	34	47	S.Art!	
Theatre Strings		8	37	49	S.Art!	
Seattle Lush Strings		8	41	49	S.Art!	
Seattle Slow Strings		8	35	50	S.Art!	
Studio Strings		8	32	49	S.Art!	
Strings		0	122	49	Natural!	
Movie Strings		0	123	49	Live!	
Disco Strings 1		0	123	50	Live!	
Disco Strings 2		0	124	50	Live!	
Seattle Warm		8	39	49	S.Art!	
Tremolo Strings		0	113	45	Live!	
Big Strings	8	40	49	S.Art!		
Spiccato	8	33	49	S.Art!		
Seattle Strings f	8	40	50	S.Art!		
Seattle Strings mf	8	41	50	S.Art!		
Dynamic Strings	0	124	49	Live!		
Seattle Strings p	8	42	50	S.Art!		

CSP-275, CSP-255

Main Category: Strings & Vocal

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
String Ensemble	Chamber Strings	0	112	50	Regular	
	Seattle Tremolo Sforzando	104	1	45	Live!	
	Strings f	0	119	49	Live!	
	Strings mf	0	118	49	Live!	
	Strings p	0	117	49	Live!	
Orchestral Layers	Horns & Strings	8	38	50	S.Art!	
	Symphonic Unison	104	0	50	Regular	
	Orchestra Tutti	0	120	50	Regular	
	Theatre Orchestra	104	1	50	Regular	
	Pizzicato Glocken	0	115	46	Live!	
Pop Vocals	Haa	8	32	40	S.Art!	
	Doo	8	38	41	S.Art!	
	Wah	8	38	40	S.Art!	
	Yoo	8	42	41	S.Art!	
	Baa	8	41	40	S.Art!	
	Boys Ooh	8	34	41	S.Art!	
	Daa	8	45	40	S.Art!	
	Girls Ooh	8	36	41	S.Art!	
	Ooh	8	32	41	S.Art!	
	Pop Vocals	8	40	56	S.Art!	
	Boys Haa Vibrato	8	33	40	S.Art!	
	Girls Doo	8	41	41	S.Art!	
	Hoo-Wah	8	39	56	S.Art!	
	Aah-Ooh Auto	8	49	41	S.Art!	
	Soft Wah	8	40	40	S.Art!	
	Accomp Aah	104	15	53	Live!	
	Boys Haa	8	34	40	S.Art!	
	Accomp Ooh	104	15	54	Live!	
	Girls Haa	8	35	40	S.Art!	
	Mmh	0	117	53	Live!	
	Hoo-Wee Auto	8	56	56	S.Art!	
	Jazz Vocals	Shoo-Bee-Doo-Bah 1	8	32	56	S.Art!
		Do-Be-Do-Be	8	48	56	S.Art!
		Shoo-Bee-Doo-Bah 2	8	47	56	S.Art!
		Ya-Ba-Da-Ba	8	51	56	S.Art!
		Ba-Da-Yah	8	36	56	S.Art!
		Who-Are-You	8	54	56	S.Art!
		What-Should-We-Do	8	53	56	S.Art!
Do-We-Yo-Be		8	52	56	S.Art!	
Shoo-Bee Dynamic		8	35	56	S.Art!	
Shoo-Ba-Doo-Ba		8	55	56	S.Art!	
Jazz Scat Vocals		8	42	56	S.Art!	
Latin Vocals		8	41	56	S.Art!	
Jazz Scat Shoo		8	45	56	S.Art!	
Baroque Scat		8	43	56	S.Art!	
Jazz Scat Dwee		8	46	56	S.Art!	
Jazz Scat Legato		8	50	56	S.Art!	
Gospel Choir		Gospel Vocals Hmm	8	32	55	S.Art!
		Gospel Wow-Hey-Hmm	8	35	55	S.Art!
	Gospel Vocals Wow	8	33	55	S.Art!	
	Gospel Vocals Hmm	104	12	54	Live!	
	Gospel Vocals Hey	8	34	55	S.Art!	
	Gospel Vocals Wow	104	13	54	Live!	
	Gospel Vocals Hey	104	7	53	Live!	
Classical Choir	Boys Choir Ooh	8	32	52	S.Art!	
	Boys Choir Aah	8	33	52	S.Art!	
	Boys Choir Ooh f	8	37	52	S.Art!	
	Boys Choir Aah f	8	38	52	S.Art!	
	Boys Choir Ooh p	8	35	52	S.Art!	
	Boys Choir Aah p	8	36	52	S.Art!	
	Boys Choir Oh-Ah	8	49	56	S.Art!	

Main Category: Brass & Woodwind

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Brass Solo	Bright Trumpet	8	32	65	S.Art!	
	Cornet	0	119	57	Sweet!	
	Silver Trumpet	8	33	65	S.Art!	
	Muted Trumpet	0	114	60	Sweet!	
	Golden Trumpet	8	34	65	S.Art!	
	Flugelhorn	0	118	57	Sweet!	
	Big Band Trumpet	8	37	65	S.Art!	
	Sweet Trombone	0	117	58	Sweet!	
	Trumpet Fall SW	8	38	65	S.Art!	
	Trumpet	0	115	57	Sweet!	
	Trumpet Shake SW	8	35	65	S.Art!	
	Mellow Trumpet	0	120	57	Sweet!	
	Silver Trumpet	0	121	57	Sweet!	
	Muted Cornet	104	0	60	Sweet!	
	Golden Trumpet	0	122	57	Sweet!	
	Baritone Horn	0	113	59	Regular	
	Tuba	104	0	59	Regular	
	Bright Trombone	104	0	58	Sweet!	
	Baritone Hit	0	114	59	Regular	
	Alp Bass	0	113	34	Regular	
	Brass Ensemble	Pop Horns Cresc SW	8	45	57	S.Art!
		Pop Horns Swell SW	8	48	57	S.Art!
		Orchestral Trumpets	104	3	57	Live!
		Orchestral Trombones	104	3	58	Live!
		Trumpets & Trombones	104	9	62	Live!
Trumpets & Trombones Oct		104	10	62	Live!	
Symphony Horns		104	1	61	Live!	
Orch Brass Octave		104	12	62	Live!	
Symphony Horns Octave		104	2	61	Live!	
Stopped Orch Horns		104	3	61	Live!	
Pop Horns Dynamic		104	0	62	Live!	
Pop Horns Dynamic Shake		104	4	62	Live!	
Pop Horns Cresc		104	5	62	Live!	
Warm Swing Horns		104	1	62	Live!	
Mute Swing Horns		104	2	62	Live!	
Orch Trumpets Fast		104	4	57	Live!	
Orch Trombones Fast		104	4	58	Live!	
Orch Horns Fast		104	4	61	Live!	
Orch Horns & Trombones		104	13	62	Live!	
Symphony Horns Fast		104	15	62	Live!	
Orch Horns Pad		104	11	62	Live!	
Ballad Brass		104	6	62	Live!	
Orchestral Horns		104	0	61	Live!	
Accent Brass		0	109	62	Live!	
Muted Horns		8	34	61	S.Art!	
Brass f		0	108	62	Live!	
Brass mf		0	110	62	Live!	
Soft Horns		0	117	61	Live!	
Brass p		0	111	62	Live!	
Soft Trombones		0	118	61	Live!	
Pop Brass		0	117	63	Live!	
Hyper Brass		0	118	63	Live!	
Sforzando	0	105	62	Live!		
Small Brass	0	120	61	Live!		
Sforzando Fall	0	107	62	Live!		
Ballroom Brass	0	113	60	Regular		
Brass Dynamics	0	106	62	Live!		
Octave Brass	0	116	63	Live!		
Sax Solo	Saxophone	8	32	83	S.Art!	
	Clean Alto Sax	8	32	67	S.Art!	
	Big Band Sax	8	35	83	S.Art!	
	Soft Alto Sax	8	34	67	S.Art!	
	Rock Sax SW	8	33	83	S.Art!	
	Growl Sax	0	111	67	Sweet!	
	Soprano Sax	0	113	65	Sweet!	
	Pop Tenor Sax	0	127	67	Sweet!	
	Pop Alto Sax	104	0	66	Sweet!	
	Ballad Tenor Sax	0	126	67	Sweet!	
	Breathy Tenor Sax	0	117	67	Sweet!	
	Sweet Tenor Sax	0	125	67	Sweet!	
	Baritone Sax 1	104	0	68	Regular	

CSP-275, CSP-255

Main Category: Brass & Woodwind

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Sax Ensemble	Sax Section	0	116	67	Live!
	Big Band Octave	0	108	67	Live!
	Smooth Saxes 1	8	38	83	S.Art!
	Big Band Horns 1	0	110	67	Live!
	Smooth Saxes 2	8	36	83	S.Art!
	Big Band Horns 2	0	109	67	Live!
	Sax Section Octave	8	37	83	S.Art!
	Ballad Section	0	119	67	Regular
	Mellow Saxes	8	39	83	S.Art!
	Sax Appeal	0	123	67	Live!
	Sax Section Hard	0	122	67	Live!
	Moonlight	0	115	72	Regular
	Sax Section Soft	0	121	67	Live!
Woodwind Solo	Orchestral Flute	8	32	74	S.Art!
	Jazz Flute	0	114	74	Sweet!
	MOR Oboe	8	32	69	S.Art!
	Orchestral Clarinet	104	0	72	Live!
	Jazz Clarinet	0	114	72	Sweet!
	German Clarinet	104	2	72	Regular
	Orchestral Bassoon	104	0	71	Sweet!
	Classical Flute	0	115	74	Sweet!
	Classical Oboe	0	113	69	Sweet!
	Piccolo	0	112	73	Regular
Woodwind Ens	English Horn	0	112	70	Regular
	Flutes & Oboes	104	2	74	Regular
	Orchestral Woodwind	104	1	71	Regular
	Clarinet & Flutes	104	1	72	Regular
	Flute Section	104	1	74	Regular
	Clarinet & Oboe	104	1	69	Regular
	Flute Ensemble	0	116	74	Regular
Woodwind World	Oboe & Bassoon	104	2	69	Regular
	Pan Pipes	0	113	76	Sweet!
	Ocarina	0	112	80	Regular
	Celtic Duo	0	120	74	Regular
	Shakuhachi	0	112	78	Regular
	Bagpipe	0	112	110	Regular
	Recorder	0	112	75	Regular
	Whistle	0	112	79	Regular
Chiff Pan Flute	0	113	74	Regular	

Main Category: Perc & Drums

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Chromatic Perc	*1 Vibraphone	104	1	12	Sweet!
	Xylophone	104	0	14	Regular
	Jazz Vibraphone	0	113	12	Regular
	Marimba	104	0	13	Regular
	Tremolo Vibraphone	0	124	12	Natural!
	Orchestral Marimba	0	122	13	Natural!
	Vibraphone & Jazz Guitar	8	33	12	S.Art!
	Glockenspiel	104	0	10	Regular
	Vibraphone & Flutes	0	114	12	Regular
	Steel Drums	0	112	115	Regular
	Concert Vibraphone	0	122	12	Natural!
	Steel Drums	0	122	115	Natural!
	Music Box	0	112	11	Regular
	Kalimba	0	112	109	Regular
	Orchestral Harp	104	1	47	Regular
	Tubular Bells	0	112	15	Regular
	Mellow Harp	104	0	47	Regular
	Timpani	0	112	48	Regular
	Celesta	0	112	9	Regular
	Orchestra Hit	0	112	56	Regular
Concert Celesta	0	122	9	Natural!	

Voices marked with "*1" can be selected from the instrument.

Main Category: Perc & Drums

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Drum Kits	Rock Drum Kit	127	0	18	Live!Drums	
	Real Brushes Kit	127	0	42	Live!Drums	
	Pop Drum Kit	127	0	74	Live!Drums	
	Jazz Kit	127	0	33	Drums	
	Real Drum Kit	127	0	92	Live!Drums	
	Rock Kit	127	0	91	Live!Drums	
	Acoustic Kit	127	0	90	Live!Drums	
	Studio Kit	127	0	87	Live!Drums	
	Jazz Brush Kit Comp	127	0	76	Live!Drums	
	Symphony Kit	127	0	49	Live!Drums	
	House Kit	127	0	61	Drums	
	EDM Kit	127	0	70	Drums	
	Hit Kit	127	0	5	Drums	
	Dubstep Kit	127	0	69	Drums	
	Electro Kit	127	0	71	Drums	
	Trap Kit	127	0	72	Drums	
	Schlager Kit	127	0	73	Drums	
	Power Kit 1	127	0	88	Live!Drums	
	Room Kit	127	0	9	Drums	
	Power Kit 2	127	0	89	Live!Drums	
	Drum Machine	127	0	62	Drums	
	Dance Kit	127	0	28	Drums	
	Analog T8 Kit	127	0	59	Drums	
	Electro Kit 2	127	0	25	Drums	
	Analog T9 Kit	127	0	60	Drums	
	Analog Kit	127	0	26	Drums	
	Break Kit	127	0	58	Drums	
	Bass Drum Kit	126	0	21	SFX	
	Hip Hop Kit	127	0	57	Drums	
	Reverse Bass Drum Kit	126	0	22	SFX	
	Cymbal Kit	126	0	50	Live!SFX	
	World Perc Kits	Pop Percussion Kit	126	0	46	Live!SFX
		Turkish Kit	126	0	68	Live!SFX
		Pop Latin Kit 1	126	0	44	Live!SFX
		Cuban Kit	126	0	41	Live!SFX
	Vocal Effects	Pop Latin Kit 2	126	0	45	Live!SFX
		Vocal Beatbox	126	0	107	Live!SFX
		Gospel AdLibs	126	0	111	Live!SFX
	SFX	Vocal Effects Kit	126	0	110	Live!SFX
		New SFX Kit 1	126	0	3	Live!SFX
Helicopter		104	0	126	Live!	
New SFX Kit 2		126	0	4	Live!SFX	
Applause 1		104	0	127	Live!	
Noises Kit		126	0	9	SFX	
Applause 2		104	1	127	Live!	
Sea Shore		104	0	123	Live!	
Gun Shot		104	0	128	Live!	

Main Category: Synth

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Synth Lead	Square Stack SW	8	32	124	S.Art!
	Nasty Saw	104	10	91	Regular
	Growling Hook	104	11	91	Regular
	Loony Lead	104	15	91	Regular
	Ten Percent	104	18	91	Regular
	Cool HiPa SW	8	34	124	S.Art!
	Wheel Tech SW	8	36	124	S.Art!
	Redoubling SW	8	37	124	S.Art!
	Hard Teeth	104	16	91	Regular
	Cyclist	104	17	91	Regular
	Crowds	104	19	91	Regular
	Gemini	104	20	91	Regular
	Hands Up!	104	21	91	Regular
	Straight Raver	104	22	91	Regular
	Trance Artist	104	23	91	Regular
	Punchy Chordz	104	24	91	Regular
	Trancy Chordz	104	25	91	Regular

CSP-275, CSP-255

Main Category: Synth

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	PC# (1-128)		
Synth Lead	Trancy Noise	104	1	123	Regular	
	Unison Strings	104	9	51	Regular	
	Med Det Strings	104	10	51	Regular	
	Yipping	104	12	91	Regular	
	Unstable Lead	104	13	91	Regular	
	Persecutor	104	14	91	Regular	
	Short Unison	104	4	85	Regular	
	Brite Decay	104	5	85	Regular	
	Tekk Tune	104	6	85	Regular	
	Staccato Melody	104	7	85	Regular	
	Pitchy Patch	104	8	85	Regular	
	Soft Chord Synth	104	9	85	Regular	
	Chord Buddy	104	10	85	Regular	
	Tune Comp	104	11	85	Regular	
	Arpeggio Line	104	12	85	Regular	
	Soft Stepper	104	24	89	Regular	
	PWM Picks	104	25	89	Regular	
	Square Stepz	104	26	89	Regular	
	Dyna Sequence	104	27	89	Regular	
	Lektro Codes	104	2	85	Regular	
	Cracky	104	29	89	Regular	
	Sub Lead	104	0	81	Regular	
	Wire Lead	0	120	82	Regular	
	Soft Saw	104	16	82	Regular	
	Soft R&B	0	119	81	Regular	
	Fusion Lead	104	15	82	Regular	
	Early Lead	0	118	82	Regular	
	Synth Perc	New Heaven	104	10	89	Regular
		Heaven Pad	104	3	92	Regular
		Fantasy Bells	104	11	89	Regular
		Breath Bells	104	15	89	Regular
		Itopia Bells	104	13	89	Regular
		Next Generation	104	9	52	Regular
Sinesphere		104	18	89	Regular	
Organ Bells		104	12	89	Regular	
Spectrum Theme		104	14	89	Regular	
Sky Bells		104	16	89	Regular	
Flying Harmonics		104	1	100	Regular	
Perc Pad		104	0	102	Regular	
Nylon Heaven		104	2	100	Regular	
Mediterrain		0	114	100	Regular	
Nylon Pad		104	0	100	Regular	
Tri Picks		104	28	89	Regular	
Airy Harp		104	17	89	Regular	
Simple Comp		104	12	82	Regular	
Bellsphere		104	5	89	Regular	
Ballad Comp		104	6	89	Regular	
Heaven Bell		104	0	101	Regular	
Digital Sequenced		104	2	88	Regular	
Bright Pad Bell		104	7	89	Regular	
Analog Sequenced		104	3	88	Regular	
PWM Wild		104	4	81	Regular	
Perc Sequence FS		104	6	88	Regular	
Resonant Clavi		104	2	91	Regular	
Perc Sequence FM 1		104	7	88	Regular	
Resonance Comp		104	4	63	Regular	
Perc Sequence FM 2		104	8	88	Regular	
Synth Strings		Synth Strings 1	0	112	51	Regular
		Butter Strings	104	2	51	Regular
		Synth Strings 2	0	113	51	Regular
	Bright Saw Pad	0	113	91	Regular	
	Ober Strings	0	113	52	Regular	
	Soft Ensemble	104	1	51	Regular	
	Hipa Strings	0	114	96	Regular	
	80s Pad	104	1	52	Regular	
	Octave Strings	104	4	51	Regular	
	Bright Pop Pad	104	3	51	Regular	
	Doux Flange	104	3	96	Regular	
	Premium Pad	104	0	52	Regular	
	Light Pad	104	2	52	Regular	

Main Category: Synth

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Synth Strings	Bright Pad Classic	104	3	91	Regular
	Medium Tune Pad	104	0	51	Regular
Synth Brass	Analog Brass	0	112	64	Regular
	1984 Synth	104	20	82	Regular
	Fat Synth Brass	0	116	64	Regular
	80s Brass	0	113	63	Regular
	80s Synth Brass Thin	104	0	63	Regular
	Funky Analog	0	115	63	Regular
	80s Synth Brass Prof	104	1	63	Regular
	Techno Brass	0	114	63	Regular
	Ober Brass	0	113	64	Regular
	Ober Horns	0	115	64	Regular
	Slow PWM Brass	104	2	63	Regular
	Soft Velocity Brass	0	120	63	Regular
	Fast PWM Brass	104	6	63	Regular
	Soft Analog	0	114	64	Regular
	Synth Pad	All or Nothing	104	6	102
Whisper Gallery		104	0	93	Regular
Digisweeper		104	7	102	Regular
Hybrid Lines		104	4	92	Regular
Spectrum Pad		104	5	95	Regular
Midnight Special		104	3	102	Regular
Hybrid Pad		104	22	89	Regular
Atmosphere 5th		104	6	90	Regular
Deep Motion		104	4	96	Regular
Pad Voices		104	6	96	Live!
Skydiver		0	112	102	Regular
Aerosphere		104	1	95	Regular
Cross Phase		104	1	102	Regular
New Atmosphere		104	4	90	Regular
Galaxy Pad		104	3	89	Regular
VP Soft		104	0	90	Regular
Night Motion		104	4	89	Regular
Hot Swell		104	2	96	Regular
Morning Dew		104	0	95	Regular
Dark Fat Saw		104	2	90	Regular
Dark Light		104	3	90	Regular
Space Rider		104	1	96	Regular
Ambient Pad		104	0	89	Regular
Pearls Pad		104	2	89	Regular
Bright Fat Saw		104	5	91	Regular
Breath Pad	104	0	92	Regular	
Early Digital	104	0	94	Regular	
Noble Man	104	1	89	Regular	
Synth Dance	Super Dark Pad	0	119	90	Regular
	Analog Swell	0	119	96	Regular
	Dark Angel Pad	0	121	90	Regular
	Big Octave Pad	0	115	91	Regular
	Lite Pad	0	122	90	Regular
	Golden Age	0	115	89	Regular
	Pop Pad	0	112	91	Regular
	Glorious Phase	0	114	91	Regular
	Insomnia	0	113	95	Regular
	Ana Dayz	104	3	52	Regular
	HPF Dance	104	0	91	Regular
	Bright Pad Trance	104	4	91	Regular
	Detuned Saw Octave	104	8	82	Regular
	Chillin Chords	104	6	52	Regular
	Dancy Hook	104	9	82	Regular
	Trance	104	0	96	Regular
	Vinalog Saw	104	3	82	Regular
	Club Lead	104	3	63	Regular
	Talk Mod Lead	104	0	88	Regular
	Trance Perc	104	5	82	Regular
Chorus Saw Lead	104	10	82	Regular	
Chordmaster	104	13	82	Regular	
Faaat Comp	104	4	52	Regular	
Trance Sequence 1	104	4	88	Regular	
Fat Saw Hook	104	7	52	Regular	
Trance Sequence 2	104	5	88	Regular	

CSP-275, CSP-255**Main Category: Synth**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	PC# (1-128)	
Synth Dance	Tech Glide	104	14	82	Regular
	Trance Sequence 3	104	1	91	Regular
	Dance Chords	104	5	52	Regular
	Dance Hook	0	112	87	Regular
	Trance Lead	0	121	81	Regular
	Octave Hook	0	113	87	Regular
Synth Effects	Water Games	104	4	102	Regular
	Spectralis	104	4	95	Regular
	My Generation	104	5	102	Regular
	Metallic Rain	104	8	102	Regular
	Rainy Day	104	5	90	Regular
	Ambient Theme	104	20	89	Regular
	Warped Waves	104	2	95	Regular
	Reflecting Zone	104	21	89	Regular
	Sound Pictures	104	3	95	Regular
	The Fog	104	9	102	Regular
	Mystic Pad	104	6	95	Regular
	Sixth Sense	104	2	102	Regular
	Randomizer	104	10	102	Regular
	Pitch Fall	104	0	104	Regular
	Atlantis	104	11	102	Regular
	Perc Sequence Hipa	104	9	88	Regular
Tric-Trac	104	2	98	Regular	

Drum/key Assignment List / Liste der Tastenzuordnungen der Schlaginstrumente / Liste des affectations d'instrument de batterie/touche de clavier / Lista de asignación de teclas/batería

Voice Name			Standard Kit 1			Hit Kit			Room Kit			Rock Drum Kit			Electro Kit 2		
MSB-LSB-PC# (1-128)			127-0-1			127-0-5			127-0-9			127-0-18			127-0-25		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Surdo Mute	3		Surdo Mute	3		Surdo Mute	3		Hi-Hat Tip 00 RD	64		Surdo Mute	3	
14	D-1	D0	Surdo Open	3		Surdo Open	3		Surdo Open	3		Hi-Hat Edge 00 RD	64		Surdo Open	3	
15	D#-1	D#0	Hi Q			Hi Q			Hi Q			Hi-Hat Tip 10 RD	64		Hi Q		
16	E-1	E0	Whip Slap			Whip Slap			Whip Slap			Hi-Hat Edge 10 RD	64		Whip Slap		
17	F-1	F0	Scratch H	4		Scratch H	4		Scratch H	4		Hi-Hat Edge 25 RD	96		Scratch H	4	
18	F#-1	F#0	Scratch L	4		Scratch L	4		Scratch L	4		Hi-Hat Edge 50 RD	96		Scratch L	4	
19	G-1	G0	Finger Snap			Finger Snap			Finger Snap			Hi-Hat Edge 75 RD	96		Finger Snap		
20	G#-1	G#0	Click Noise			Click Noise			Click Noise			Hi-Hat Edge 99 RD	96		Click Noise		
21	A-1	A0	Metronome Click			Metronome Click			Metronome Click			Hi-Hat Pedal Closed RD	64		Metronome Click		
22	A#-1	A#0	Metronome Bell			Metronome Bell			Metronome Bell			Hi-Hat Pedal Splash	96		Metronome Bell		
23	B-1	B0	Seq Click L			Seq Click L			Seq Click L			Seq Click L			Seq Click L		
24	C0	C1	Seq Click H			Seq Click H			Seq Click H			Seq Click H			Seq Click H		
25	C#0	C#1	Brush Tap			Brush Tap			Brush Tap			Snare Brush Mute Snappy Off Edge Pressed JB			Brush Tap		
26	D0	D1	Brush Swirl		●	Brush Swirl		●	Brush Swirl		●	Snare 2 no-Rim RD			Brush Swirl		●
27	D#0	D#1	Brush Slap			Brush Slap			Brush Slap			Snare 4 no-Rim RD			Brush Slap		
28	E0	E1	Brush Tap Swirl		●	Brush Tap Swirl		●	Brush Tap Swirl		●	Snare 3 no-Rim RD			Reverse Cymbal		●
29	F0	F1	Snare Roll		●	Snare Roll		●	Snare Roll		●	Snare Roll RD			● Snare Roll		●
30	F#0	F#1	Castanet			Castanet			Castanet			Snare 2 RD			Hi Q 2		
31	G0	G1	Snare Soft			Snare Electro			Snare Soft			Snare 4 RD			Snare Snappy Electro		
32	G#0	G#1	Sticks			Sticks			Sticks			Stick Count VO			Sticks		
33	A0	A1	Kick Soft			Kick Tight L			Kick Soft			Kick 4 RD			Kick 3		
34	A#0	A#1	Open Rim Shot			Snare Pitched			Open Rim Shot			Snare 1 Open Rim RD			Open Rim Shot		
35	B0	B1	Kick Tight			Kick Wet			Kick Tight			Kick 2 RD			Kick Gate		
36	C1	C2	Kick			Kick Tight H			Kick			Kick 1 RD			Kick Gate Heavy		
37	C#1	C#2	Side Stick			Stick Ambient			Side Stick			Snare 1 Side-Stick RD			Side Stick		
38	D1	D2	Snare			Snare Ambient			Snare Snappy			Snare 1 RD			Snare Noisy 2		
39	D#1	D#2	Hand Clap			Hand Clap			Hand Clap			Clap Power			Hand Clap		
40	E1	E2	Snare Tight			Snare Tight 2			Snare Tight Snappy			Snare 3 RD			Snare Noisy 3		
41	F1	F2	Floor Tom L			Hybrid Tom 1			Tom Room 1			Tom RD 1			Tom Electro 1		
42	F#1	F#2	Hi-Hat Closed	1		Hi-Hat Closed 2	1		Hi-Hat Closed	1		Hi-Hat Edge 00 RD	1		Hi-Hat Closed	1	
43	G1	G2	Floor Tom H			Hybrid Tom 2			Tom Room 2			Tom RD 2			Tom Electro 2		
44	G#1	G#2	Hi-Hat Pedal	1		Hi-Hat Pedal 2	1		Hi-Hat Pedal	1		Hi-Hat Pedal Closed RD	1		Hi-Hat Pedal	1	
45	A1	A2	Low Tom			Hybrid Tom 3			Tom Room 3			Tom RD 3			Tom Electro 3		
46	A#1	A#2	Hi-Hat Open	1		Hi-Hat Open 2	1		Hi-Hat Open	1		Hi-Hat Edge 75 RD	1		Hi-Hat Open	1	
47	B1	B2	Mid Tom L			Hybrid Tom 4			Tom Room 4			Tom RD 4			Tom Electro 4		
48	C2	C3	Mid Tom H			Hybrid Tom 5			Tom Room 5			Tom RD 5			Tom Electro 5		
49	C#2	C#3	Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal 1			Crash Cymbal RD 1			Crash Cymbal 1		
50	D2	D3	High Tom			Hybrid Tom 6			Tom Room 6			Tom RD 6			Tom Electro 6		
51	D#2	D#3	Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal Tip RD			Ride Cymbal 1		
52	E2	E3	Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			China Cymbal RD			Chinese Cymbal		
53	F2	F3	Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup RD			Ride Cymbal Cup		
54	F#2	F#3	Tambourine			Tambourine Light			Tambourine			Tambourine			Tambourine		
55	G2	G3	Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal RD			Splash Cymbal		
56	G#2	G#3	Cowbell			Cowbell			Cowbell			Cowbell RD			Cowbell		
57	A2	A3	Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal RD 2			Crash Cymbal 2		
58	A#2	A#3	Vibraslap			Vibraslap			Vibraslap			Vibraslap			Vibraslap		
59	B2	B3	Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal 2			Ride Cymbal Real 2			Ride Cymbal 2		
60	C3	C4	Bongo H			Bongo H			Bongo H			Bongo H			Bongo H		
61	C#3	C#4	Bongo L			Bongo L			Bongo L			Bongo L			Bongo L		
62	D3	D4	Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute		
63	D#3	D#4	Conga H Open			Conga H Open			Conga H Open			Conga H Open			Conga H Open		
64	E3	E4	Conga L			Conga L			Conga L			Conga L			Conga L		
65	F3	F4	Timbale H			Timbale H			Timbale H			Timbale H			Timbale H		
66	F#3	F#4	Timbale L			Timbale L			Timbale L			Timbale L			Timbale L		
67	G3	G4	Agogo H			Agogo H			Agogo H			Agogo H			Agogo H		
68	G#3	G#4	Agogo L			Agogo L			Agogo L			Agogo L			Agogo L		
69	A3	A4	Cabasa			Cabasa			Cabasa			Cabasa			Cabasa		
70	A#3	A#4	Maracas			Maracas			Maracas			Maracas			Maracas		
71	B3	B4	Samba Whistle H		●	Samba Whistle H		●	Samba Whistle H		●	Samba Whistle H		●	● Samba Whistle H		●
72	C4	C5	Samba Whistle L		●	Samba Whistle L		●	Samba Whistle L		●	Samba Whistle L		●	● Samba Whistle L		●
73	C#4	C#5	Guiro Short			Guiro Short			Guiro Short			Guiro Short			Guiro Short		
74	D4	D5	Guiro Long		●	Guiro Long		●	Guiro Long		●	Guiro Long		●	● Guiro Long		●
75	D#4	D#5	Claves			Claves			Claves			Claves			Claves		
76	E4	E5	Wood Block H			Wood Block H			Wood Block H			Wood Block H			Wood Block H		
77	F4	F5	Wood Block L			Wood Block L			Wood Block L			Wood Block L			Wood Block L		
78	F#4	F#5	Cuica Mute			Cuica Mute			Cuica Mute			Cuica Mute			Scratch H 2		
79	G4	G5	Cuica Open			Cuica Open			Cuica Open			Cuica Open			Scratch L 2		
80	G#4	G#5	Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2	
81	A4	A5	Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2	
82	A#4	A#5	Shaker			Shaker			Shaker			Shaker			Shaker		
83	B4	B5	Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells		
84	C5	C6	Bell Tree			Bell Tree			Bell Tree			Wind Chime			Bell Tree		
85	C#5	C#6															
86	D5	D6															
87	D#5	D#6															
88	E5	E6															
89	F5	F6															
90	F#5	F#6															
91	G5	G6															

NOTE: Standard Kit 1 cannot be selected from the Smart Pianist app.

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.
*2 Key Off: Keys marked ● stop sounding the instant they are released.

*3 Revol: Keys marked ● sound different each time the same key is played, so that the sound is more natural.

Voice Name			Analog Kit			Dance Kit			Jazz Kit			Real Brushes Kit			Symphony Kit		
MSB-LSB-PC# (1-128)			127-0-26			127-0-28			127-0-33			127-0-42			127-0-49		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Surdo Mute	3		Kick Dance 1			Surdo Mute	3		Surdo Mute	3		Surdo Mute	3	
14	D-1	D0	Surdo Open	3		Kick Dance 2			Surdo Open	3		Surdo Open	3		Surdo Open	3	
15	D#-1	D#0	Hi Q			Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	E0	Whip Slap			Whip Slap			Whip Slap			Whip Slap			Whip Slap		
17	F-1	F0	Scratch H	4		Scratch Dance 1			Scratch H	4		Scratch H	4		Scratch H	4	
18	F#-1	F#0	Scratch L	4		Scratch Dance 2			Scratch L	4		Scratch L	4		Scratch L	4	
19	G-1	G0	Finger Snap			Finger Snap			Finger Snap			Finger Snap			Finger Snap		
20	G#-1	G#0	Click Noise			Click Noise			Click Noise			Click Noise			Click Noise		
21	A-1	A0	Metronome Click			Dance Perc 1			Metronome Click			Metronome Click			Metronome Click		
22	A#-1	A#0	Metronome Bell			Reverse Dance 1			Metronome Bell			Metronome Bell			Metronome Bell		
23	B-1	B0	Seq Click L			Dance Perc 2			Seq Click L			Vintage Tip			Seq Click L		
24	C0	C1	Seq Click H			Hi Q Dance 1			Seq Click H			Vintage Swirl 1			Seq Click H		
25	C#0	C#1	Brush Tap			Snare Analog 3			Brush Tap			Vintage Slap 1			Brush Tap		
26	D0	D1	Brush Swirl			Vinyl Noise			Brush Swirl			Vintage Swirl 2			Brush Swirl		
27	D#0	D#1	Brush Slap			Snare Analog 4			Brush Slap			Vintage Slap 2			Brush Slap		
28	E0	E1	Reverse Cymbal			Reverse Cymbal			Reverse Tap Swirl			Vintage Tap Swirl			Reverse Tap Swirl		
29	F0	F1	Snare Roll			Reverse Dance 2			Snare Roll			Vintage Slap Swirl			Snare Roll		
30	F#0	F#1	Hi Q 2			Hi Q 2			Castanet			Vintage Swirl 3			Castanet		
31	G0	G1	Snare Noisy 4			Snare Techno			Snare Jazz H			Vintage Slap 3			Snare Soft		
32	G#0	G#1	Sticks			Snare Dance 1			Sticks			Sticks			Sticks		
33	A0	A1	Kick 3			Kick Techno Q			Kick Soft			Kick Soft L			Kick Soft 2		
34	A#0	A#1	Open Rim Shot			Open Rim Shot			Open Rim Shot			Open Rim Shot Real Brushes			Open Rim Shot		
35	B0	B1	Kick Analog Short			Kick Techno L			Kick Tight			Kick Soft H			Gran Cassa		
36	C1	C2	Kick Analog			Kick Techno			Kick Jazz			Kick Jazz Ambience			Gran Cassa Mute		
37	C#1	C#2	Side Stick Analog			Side Stick Analog			Side Stick Light			Side Stick Real Brushes			Side Stick		
38	D1	D2	Snare Analog			Snare Clap			Snare Jazz L			Vintage Slap 4			Band Snare		
39	D#1	D#2	Hand Clap			Dance Clap			Hand Clap			Clap Power			Hand Clap		
40	E1	E2	Snare Analog 2			Snare Dry			Snare Jazz M			Vintage Slap 5			Band Snare 2		
41	F1	F2	Tom Analog 1			Tom Dance 1			Floor Tom L			Tom Real Brushes 1			Floor Tom L		
42	F#1	F#2	Hi-Hat Closed Analog	1		Hi-Hat Closed 3	1		Hi-Hat Closed	1		Hi-Hat Closed Real Brushes	1		Hi-Hat Closed	1	
43	G1	G2	Tom Analog 2			Tom Dance 2			Floor Tom H			Tom Real Brushes 2			Floor Tom H		
44	G#1	G#2	Hi-Hat Closed Analog 2	1		Hi-Hat Closed Analog 3	1		Hi-Hat Pedal	1		Hi-Hat Pedal Real Brushes	1		Hi-Hat Pedal	1	
45	A1	A2	Tom Analog 3			Tom Dance 3			Low Tom			Tom Real Brushes 3			Low Tom		
46	A#1	A#2	Hi-Hat Open Analog	1		Hi-Hat Open 3	1		Hi-Hat Open	1		Hi-Hat Open Real Brushes	1		Hi-Hat Open	1	
47	B1	B2	Tom Analog 4			Tom Dance 4			Mid Tom L			Tom Real Brushes 4			Mid Tom L		
48	C2	C3	Tom Analog 5			Tom Dance 5			Mid Tom H			Tom Real Brushes 5			Mid Tom H		
49	C#2	C#3	Crash Analog			Crash Analog			Crash Cymbal 1			Crash Cymbal Real Brushes 1			Hand Cymbal		
50	D2	D3	Tom Analog 6			Tom Dance 6			High Tom			Tom Real Brushes 6			High Tom		
51	D#2	D#3	Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal 1			Ride Cymbal Real Brushes			Hand Cymbal Short		
52	E2	E3	Chinese Cymbal			Chinese Cymbal			Chinese Cymbal			China Cymbal Real Brushes			Chinese Cymbal		
53	F2	F3	Ride Cymbal Cup			Ride Cymbal Cup			Ride Cymbal Cup			Ride Cup Real Brushes 1			Ride Cymbal Cup		
54	F#2	F#3	Tambourine			Tambourine Analog			Tambourine			Tambourine			Tambourine		
55	G2	G3	Splash Cymbal			Splash Cymbal			Splash Cymbal			Splash Cymbal Real Brushes			Splash Cymbal		
56	G#2	G#3	Cowbell Analog			Cowbell Dance			Cowbell			Cowbell			Cowbell		
57	A2	A3	Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal Real Brushes 2			Hand Cymbal 2		
58	A#2	A#3	Vibraslap			Vibraslap Analog			Vibraslap			Vibraslap			Vibraslap		
59	B2	B3	Ride Cymbal 2			Ride Analog			Ride Cymbal 2			Ride Cup Real Brushes 2			Hand Cymbal Short 2		
60	C3	C4	Bongo H			Bongo Analog H			Bongo H			Bongo H			Bongo H		
61	C#3	C#4	Bongo L			Bongo L			Bongo L			Bongo L			Bongo L		
62	D3	D4	Conga Analog H			Conga Analog H			Conga H Mute			Conga H Mute			Conga H Mute		
63	D#3	D#4	Conga Analog M			Conga Analog M			Conga H Open			Conga H Open			Conga H Open		
64	E3	E4	Conga Analog L			Conga Analog L			Conga L			Conga L			Conga L		
65	F3	F4	Timbale H			Timbale H			Timbale H			Timbale H			Timbale H		
66	F#3	F#4	Timbale L			Timbale L			Timbale L			Timbale L			Timbale L		
67	G3	G4	Agogo H			Agogo H			Agogo H			Agogo H			Agogo H		
68	G#3	G#4	Agogo L			Agogo L			Agogo L			Agogo L			Agogo L		
69	A3	A4	Cabasa			Cabasa			Cabasa			Cabasa			Cabasa		
70	A#3	A#4	Maracas 2			Maracas 2			Maracas			Maracas			Maracas		
71	B3	B4	Samba Whistle H			Samba Whistle H			Samba Whistle H			Samba Whistle H			Samba Whistle H		
72	C4	C5	Samba Whistle L			Samba Whistle L			Samba Whistle L			Samba Whistle L			Samba Whistle L		
73	C#4	C#5	Guiro Short			Guiro Short			Guiro Short			Guiro Short			Guiro Short		
74	D4	D5	Guiro Long			Guiro Long			Guiro Long			Guiro Long			Guiro Long		
75	D#4	D#5	Claves 2			Claves 2			Claves			Claves			Claves		
76	E4	E5	Wood Block H			Dance Perc 3			Wood Block H			Wood Block H			Wood Block H		
77	F4	F5	Wood Block L			Dance Perc 4			Wood Block L			Wood Block L			Wood Block L		
78	F#4	F#5	Scratch H 2			Dance Breath 1			Cuica Mute			Cuica Mute			Cuica Mute		
79	G4	G5	Scratch L 2			Dance Breath 2			Cuica Open			Cuica Open			Cuica Open		
80	G#4	G#5	Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2	
81	A4	A5	Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2	
82	A#4	A#5	Shaker			Shaker			Shaker			Shaker			Shaker		
83	B4	B5	Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells		
84	C5	C6	Bell Tree			Bell Tree			Bell Tree			Wind Chime			Bell Tree		
85	C#5	C#6															
86	D5	D6															
87	D#5	D#6															
88	E5	E6															
89	F5	F6															
90	F#5	F#6															
91	G5	G6															

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Voice Name			Hip Hop Kit			Break Kit			Analog T8 Kit			Analog T9 Kit		
MSB-LSB-PC# (1-128)			127-0-57			127-0-58			127-0-59			127-0-60		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Surdo Mute	5		Surdo Mute	3		Surdo Mute	3		Surdo Mute	3	
14	D-1	D0	Surdo Open	5		Surdo Open	3		Surdo Open	3		Surdo Open	3	
15	D#-1	D#0	Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	E0	Whip Slap			Whip Slap			Whip Slap			Whip Slap		
17	F-1	F0	Scratch H	6		Scratch H	4		Scratch H	4		Scratch H	4	
18	F#-1	F#0	Scratch L	6		Scratch L	4		Scratch L	4		Scratch L	4	
19	G-1	G0	Hi-Hat Closed T8 2	4		Finger Snap			Snare Hammer			Snare Drum&Bass 1		
20	G#-1	G#0	Tom T8 3			Snare Break 8			Kick Zap Hard			Kick Break 2		
21	A-1	A0	Hi-Hat Open T8 2	4		Snare Break 9			Snare Garg L			Snare Distortion		
22	A#-1	A#0	Tom T8 6			Hi-Hat Closed Break 1		●	Kick Tek Power			Kick Tek Power		
23	B-1	B0	Crash T8			Hi-Hat Closed Break 2		●	Kick Slimy			Kick Distortion RM		
24	C0	C1	Triangle Mute	1		Kick Break Deep			Kick T8 4			Kick T9 2		
25	C#0	C#1	Triangle Open	1		Snare Hip			Snare Analog CR			Snare Analog CR		
26	D0	D1	Wind Chime			Snare Lo-Fi			Snare T8 7			Snare T9 5		
27	D#0	D#1	Tambourine Light 2			Snare Clappy			Snare Clap Analog			Clap Analog Sm		
28	E0	E1	Tambourine Light 1			Snare LdwH Mono			Snare T8 6			Snare T9 Gate 1		
29	F0	F1	Kick HipHop 9			Snare Rock Roll		●	Tom T8 5			Snare Rock Roll		●
30	F#0	F#1	Hi-Hat Closed Tek	3		Snare Gate 1			Snare T8 5			Snare T9 3		
31	G0	G1	Kick Gate			Snare Mid			Kick T8 3			Snare T9 4		
32	G#0	G#1	Hi-Hat Open Lo-Fi	3		Snare Break Rim			Snare T8 4			Snare T9 Gate 2		
33	A0	A1	Kick Gran Casa Open			Kick Break Heavy			Kick T8 2			Kick T9 4		
34	A#0	A#1	Hi-Hat Reverse Drum&Bass			Snare Hip Rim 4			Snare T8 3			Snare T9 6		
35	B0	B1	Kick HipHop 1			Kick Break 2			T8 Kick Bass			Kick T9 1		
36	C1	C2	Kick Analog CR			Kick Break 1			Kick T8 1			Kick T9 3		
37	C#1	C#2	Snare Analog Sm Rim			Snare Hip Rim 1			Snare T8 Rim			Snare T9 Rim		
38	D1	D2	Snare HipHop 1			Snare Break 3			Snare T8 2			Snare T9 1		
39	D#1	D#2	Snare Clappy			Snare Break 1			Clap T9			Clap T9		
40	E1	E2	Snare HipHop 2			Snare Break 2			Snare T8 1			Snare T9 2		
41	F1	F2	Floor Tom L			Tom Break 1			Tom T8 1			Tom T9 1		
42	F#1	F#2	Hi-Hat Closed HipHop	2		Hi-Hat Closed Rock Soft	1		Hi-Hat Closed T8	1		Hi-Hat Closed T9	1	
43	G1	G2	Low Tom			Tom Break 2			Tom T8 2			Tom T9 2		
44	G#1	G#2	Hi-Hat Pedal HipHop	2		Hi-Hat Pedal Rock	1		Hi-Hat Pedal T8	1		Hi-Hat Pedal T9	1	
45	A1	A2	Mid Tom L			Tom Break 3			Tom T8 3			Tom T9 3		
46	A#1	A#2	Hi-Hat Open HipHop	2		Hi-Hat Half Open Rock	1		Hi-Hat Open T8	1		Hi-Hat Open T9	1	
47	B1	B2	High Tom			Tom Break 4			Tom T8 4			Tom T9 4		
48	C2	C3	Ride Cymbal 3			Tom Break 5			Tom T8 6			Tom T9 5		
49	C#2	C#3	Crash Cymbal 3			Crash Cymbal 1			Crash Cymbal T8			Crash Cymbal T9		
50	D2	D3	Shaker 2			Tom Break 6			Tom T8 7			Tom T9 6		
51	D#2	D#3	Scratch Bass Drum Forward			Ride Cymbal 3			Ride Cymbal T9			Ride Cymbal T9		
52	E2	E3	Scratch Bass Drum Reverse			China Cymbal 2			China Cymbal 2			China Cymbal 2		
53	F2	F3	Kick HipHop 2			Ride Cymbal Cup 2			Ride Cymbal Cup 2			Ride Cymbal Cup 2		
54	F#2	F#3	Snare HipHop Rim 2			Tambourine 1 Hit			Tambourine RX5			Tambourine RX5		
55	G2	G3	HipHop Clap 2			Splash Cymbal 2			Splash Cymbal 2			Splash Cymbal 2		
56	G#2	G#3	HipHop Snap 1			Cowbell 1			Cowbell T8			Cowbell 1		
57	A2	A3	Snare HipHop 3			Crash Cymbal 2			Crash Cymbal 4			Crash Cymbal 4		
58	A#2	A#3	Electric Clap 2			Cowbell RX11			Vibraslap			Cowbell T8		
59	B2	B3	Kick Hip Deep			Ride Cymbal 2			Ride Cymbal 3			Ride Cymbal 3		
60	C3	C4	Kick HipHop 3			Bongo H			Conga T8 5			Conga T8 5		
61	C#3	C#4	Snare HipHop Rim 3			Bongo L			Conga T8 4			Conga T8 4		
62	D3	D4	Snare HipHop 5			Conga H Tip			Conga T8 3			Conga Tip		
63	D#3	D#4	Electric Clap 1			Conga H Open Slap			Conga T8 2			Conga Open Slap		
64	E3	E4	Handbell H			Conga H Open			Conga T8 1			Conga Open		
65	F3	F4	Kick HipHop 4			Bongo 2 H			Timbale H			Timbale H		
66	F#3	F#4	HipHop Clap 3			Bongo 2 L			Timbale L			Timbale L		
67	G3	G4	HipHop Snap 2			Conga Open			Glass H			Analog Click		
68	G#3	G#4	Snare HipHop Rim 5			Agogo L			Glass L			Conga T8 1		
69	A3	A4	HipHop Flex 1			Cabasa			Cabasa			Cabasa		
70	A#3	A#4	HipHop Flex 2			Maracas Slur			Maracas T8			Maracas Slur 2		
71	B3	B4	Shaker 2			Timbale H			Fx Gun 2		●	Fx Gun 2		●
72	C4	C5	Kick HipHop 5			Timbale L			Fx Gun 1			Fx Gun 1		●
73	C#4	C#5	Snare HipHop Rim 4			Scratch H 3		●	Analog Shaker H		●	Scratch H 3		●
74	D4	D5	Snare HipHop 6			Scratch Down		●	Analog Shaker L		●	Scratch Down		●
75	D#4	D#5	Snare HipHop 11			Claves			Claves T8			Hi Q 3		
76	E4	E5	Kick HipHop 10			Wood Block H			Hi Q 1			Hi Q 1		
77	F4	F5	Snare HipHop 7			Wood Block L			Hi Q 2			Hi Q 2		
78	F#4	F#5	HipHop Clap 5			Scratch H 2			Scratch H 2			Scratch H 2		
79	G4	G5	Conga H Tip			Scratch L 2			Scratch L 2			Scratch L 2		
80	G#4	G#5	Conga H Heel			Triangle Mute	2		Triangle Mute	2		Triangle Mute	2	
81	A4	A5	Conga H Open			Triangle Open	2		Triangle Open	2		Triangle Open	2	
82	A#4	A#5	Conga L Open 1			Kick Break 3			Analog Shaker			Analog Shaker		
83	B4	B5	Conga L Open 2			Kick Break 4			Sleigh Bells			Jingle Bells		
84	C5	C6	Kick HipHop 8			Kick Break 5		●	Wind Chime			Wind Chime		
85	C#5	C#6	HipHop Clap 6			Kick Break 6			Snare Hip 1			Snare Piccolo		
86	D5	D6	Snare T8 1			Kick Break 7			Snare Hip 2			Snare T8 7		
87	D#5	D#6	Snare T8 1H			Hi-Hat Closed Break 3			Snare Hip Gate			SnareRckRollDist		
88	E5	E6	HipHop Clap 7			Snare Break 4			Snare Break 1			Snare Brush Mute		
89	F5	F6	Tom T8 1			Snare Break 5			Kick Blip			Kick Blip Hard		
90	F#5	F#6	Hi-Hat Closed T8 2			Snare Break 6			Snare Fx 1			Snare Jungle 1		
91	G5	G6	Tom T8 2			Snare Break 7			Kick Fx Hammer			Kick Sustain		

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Voice Name			House Kit			Drum Machine			Dubstep Kit			EDM Kit			Electro Kit		
MSB-LSB-PC# (1-128)			127-0-61			127-0-62			127-0-69			127-0-70			127-0-71		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	W Kick		●	Surdo Mute	3		Kick 4 DS			Kick 3 EDM			Kick 7 EK		
14	D-1	D0	Disco Fx		●	Surdo Open	3		Kick 5 DS			Kick 4 EDM			Kick 8 EK		
15	D#-1	D#0	White Noise Down 1		●	Hi Q			Digital DS		●	Glitch 4 EDM		●	SFX 13 EK		●
16	E-1	E0	Pink Noise Down 1		●	Whip Slap			Pink Noise Down 1		●	Snare 12 EDM			SFX 14 EK		●
17	F-1	F0	White Noise Down 2	4	●	Scratch H	4		White Noise Down 2		●	Snare 3 EDM			Kick 5 EK		
18	F#-1	F#0	Pink Noise Down 2	4	●	Scratch L	4		Pink Noise Down 2		●	Snare 4 EDM			Kick 6 EK		
19	G-1	G0	White Noise Up 2		●	Snare Drum&Bass 1			Boomer DS		●	White Noise Up 2		●	SFX 12 EK		●
20	G#-1	G#0	White Noise Up 1		●	Kick Break 2			Synth Scratch DS		●	Glitch 3 EDM			SFX 11 EK		●
21	A-1	A0	Pink Noise Up		●	Snare Distortion			Bouncer DS		●	Bump EDM			SFX 10 EK		●
22	A#-1	A#0	White Noise Up Release		●	Kick Tek Power			Tin Cowbell DS		●	Reverse Shot EDM		●	SFX 9 EK		●
23	B-1	B0	Pink Noise Up Release		●	Kick Distortion RM			Reverse Flanger Snare DS		●	Glitch 5 EDM		●	SFX 8 EK		●
24	C0	C1	Kick T9 4			Bass Drum Hard Long			Kick 13 DS			Kick 15 EDM			Kick 2 EK		
25	C#0	C#1	Snare T8 Rim			Bass Drum Tek Power			Snare 3 DS			Snare 7 EDM			Snare 2 EK		
26	D0	D1	Snare T8 5			Bass Drum Distortion 5			Clap 4 DS			Snare 14 EDM			Snare 3 EK		
27	D#0	D#1	Hand Clap			Bass Drum Distortion 3			Snare 4 DS			Snare 5 EDM			Clap 6 EK		
28	E0	E1	Snare Garg L			Bass Drum Distortion 1		●	Snare 11 DS		●	Snare 15 EDM			Snare 1 EK		
29	F0	F1	Snare Roll		●	Bass Drum Drum&Bass 1			Snare 5 DS			Reverse Hit EDM		●	Snare 4 EK		●
30	F#0	F#1	Snare T9 3			Bass Drum Blip			Snare T9 3			Snare 17 EDM			Snare 10 EK		
31	G0	G1	Snare T8 1			Bass Drum Analog Sm			Snare 6 DS			Snare 2 EDM			Snare 5 EK		
32	G#0	G#1	Snare T9 5			Kick T8 2			Clap 3 DS			Snare 1 EDM			Clap 5 EK		
33	A0	A1	Kick T9 1			Kick T8 3			Kick 2 DS		●	Kick 8 EDM			Kick 14 EK		
34	A#0	A#1	Snare T9 Gate			Kick T9 HD 3			Clap 2 DS			Snare 16 EDM			Clap 2 EK		
35	B0	B1	Kick T9 2			Kick T9 2			Kick 3 DS			Kick 5 EDM			Kick 1 EK		
36	C1	C2	Kick T9 5			Kick T9 4			Kick 1 DS		●	Kick 16 EDM			Kick 10 EK		
37	C#1	C#2	Snare T9 Rim			Snare T9 Rim			Rim Shot 1 DS			Thump EDM			Rim Shot 1 EK		
38	D1	D2	Snare T9 1			Snare T9 1			Snare 1 DS			Snare 9 EDM			Snare 9 EK		
39	D#1	D#2	Clap T9			Clap T9			Clap 1 DS			Clap 1 EDM			Clap 1 EK		
40	E1	E2	Snare T9 2			Snare T9 4			Snare 2 DS			Snare 10 EDM			Snare T9 1		
41	F1	F2	Tom T9 1			Tom T9 1			Tom T9 1			Tom B6 8P			Tom 1 EK		
42	F#1	F#2	Hi-Hat Closed T8	1		Hi-Hat Closed T9	1		Hi-Hat Closed 1 DS	1		Hi-Hat Closed EDM	1		Hi-Hat Closed 1 EK	1	
43	G1	G2	Tom T9 2			Tom T9 2			Tom T9 2			Tom B5 8P			Tom 2 EK		
44	G#1	G#2	Hi-Hat Pedal T9	1		Hi-Hat Pedal T9	1		Hi-Hat Pedal 1 DS	1		Hi-Hat Shank EDM	1		Hi-Hat Closed 2 EK	1	
45	A1	A2	Tom T9 3			Tom T9 3			Tom T9 3			Tom B4 8P			Tom 3 EK		
46	A#1	A#2	Hi-Hat Open T9	1		Hi-Hat Open T9	1		Hi-Hat Open 1 DS	1		Hi-Hat Open EDM	1		Hi-Hat Open 4 EK	1	
47	B1	B2	Tom T9 4			Tom T9 4			Tom T9 4			Tom B3 8P			Tom 4 EK		
48	C2	C3	Tom T9 5			Tom T9 5			Tom T9 5			Tom B2 8P			Tom 5 EK		
49	C#2	C#3	Crash Cymbal T9			Crash Cymbal T9			Crash Cymbal T9			Crash Cymbal T9			Crash Cymbal T9		
50	D2	D3	Tom T9 6			Conga T8 1			Tom T9 6			Tom B1 8P			Tom 6 EK		
51	D#2	D#3	Ride Cymbal T9			Ride Cymbal T9			Ride Cymbal T9			Ride Shank EDM			Ride Cymbal T9		
52	E2	E3	Crash Cymbal 4			Conga T8 2			Crash Cymbal 4			Crash Cymbal 4			Crash Cymbal 4		
53	F2	F3	Ride Cymbal Cup 2			Analog Click			Ride Cymbal Cup 2			Ride Cymbal Cup 2			Ride Cymbal Cup 2		
54	F#2	F#3	Tambourine Hit			Claves T8 1			Tambourine 82P			Tambourine Hit			Tambourine 82P		
55	G2	G3	Splash Cymbal 2			Maracas T8			Splash Cymbal 2			Splash Cymbal 2			Splash Cymbal 2		
56	G#2	G#3	Cowbell 1			Tambourine Analog CR			Cowbell 82P			Cowbell 1			Cowbell 80R		
57	A2	A3	Crash Cymbal 2			Analog Shaker			Crash Cymbal 2			Crash Cymbal 2			Crash Cymbal 2		
58	A#2	A#3	Cowbell T8			Cowbell T8			Cowbell T8			Cowbell T8			Cowbell T8		
59	B2	B3	Ride Cymbal 3			Cowbell Analog CR			Ride Cymbal 3			Ride Cymbal 3			Ride Cymbal 3		
60	C3	C4	Bongo H Open One Finger			Snare T8 1			Bongo H 82P			Bongo H Open One Finger			Bongo H 80R		
61	C#3	C#4	Bongo L Open Three Finger			Bongo T8 2			Bongo L 82P			Bongo L Open Three Finger			Bongo L 80R		
62	D3	D4	Conga H Tip			Snare T8 3			Conga Mute 82P			Conga H Tip			Conga Mute 80R		
63	D#3	D#4	Conga H Slap Open			Snare Analog CR			Conga H 82P			Conga H Slap Open			Conga H 80R		
64	E3	E4	Conga H Open 2			Snare Jungle 1			Conga L 82P			Conga H Open 2			Conga L 80R		
65	F3	F4	Timbale H			Snare Drum&Bass 2			Timbale H			Timbale H			Timbale H		
66	F#3	F#4	Timbale L			Snare Hip 1			Timbale L			Timbale L			Timbale L		
67	G3	G4	Agogo H			Snare R&B 1			Cowbell Hi Pitch 82P			Agogo H			Agogo H 80R		
68	G#3	G#4	Agogo L			Snare R&B 2			Cowbell Middle Pitch 82P			Agogo L			Agogo L 80R		
69	A3	A4	Cabasa			Snare Hip 1			Cabasa 81P			Cabasa			Cabasa 80R		
70	A#3	A#4	Maracas Slur 2			Snare Wood			Maracas Slur 2			Maracas Slur 2			Cabasa 81R		●
71	B3	B4	Vox Drum L			Snare Timbre			Vox Drum L			Vox Drum L			Vox Drum L		
72	C4	C5	Vox Drum H			Hi-Hat Closed T8 1	5		Vox Drum H			Vox Drum H			Vox Drum H		
73	C#4	C#5	Guiro Short			Hi-Hat Open T8 1	5		Guiro Short	3		Guiro Short			SFX 5 EK		
74	D4	D5	Guiro Long		●	Hi-Hat Closed T8 2	6		Guiro Long	3	●	Guiro Long		●	SFX 4 EK		●
75	D#4	D#5	Claves			Hi-Hat Open T8 2	6		Claves 83P			Claves		●	SFX 1 EK		
76	E4	E5	Wood Block H			Hi-Hat Pedal Acoustic	7		Wood Block H			Clap 2 EDM			SFX 2 EK		
77	F4	F5	Wood Block L			Hi-Hat Closed Acoustic	7		Wood Block L			Clap 3 EDM			SFX 3 EK		
78	F#4	F#5	Cuica H			Hi-Hat Open Acoustic	7		Hi-Hat Closed 4 DS			Hi-Hat Closed 3 EDM	3		Clap 8 EK		
79	G4	G5	Cuica L			Hi-Hat Closed Lo-Fi	2		Hi-Hat Closed 5 DS			Hi-Hat Open 2 EDM	3		Clap 4 EK		
80	G#4	G#5	Triangle Mute	2		Hi-Hat Open Lo-Fi	2		Triangle Mute	2		Hi-Hat Closed 1 EDM	2		Hi-Hat Open 1 EK		●
81	A4	A5	Triangle Open	2		Hi-Hat Closed Syn	8		Triangle Open	2		Hi-Hat Closed 2 EDM	2		Hi-Hat Open 2 EK		●
82	A#4	A#5	Analog Shaker			Hi-Hat Open Syn	8		Hi-Hat Open 3 DS			Kick 6 EDM			Hi-Hat Open 5 EK		●
83	B4	B5	Jingle Bells			Analog Shaker 2			Kick 6 DS			Kick 9 EDM			Kick 9 EK		
84	C5	C6	Wind Chime			Tambourine RX5 2			Kick 7 DS			Kick 10 EDM			Kick 13 EK		
85	C#5	C#6	Snare Break Roll			Tambourine 1 Hit			Kick 8 DS			Kick 11 EDM			Kick 16 EK		
86	D5	D6	Noise Burst			Electric Cowbell			Kick 10 DS			Fill Tom EDM			Kick 12 EK		
87	D#5	D#6	Vox Bell			Conga T8 3			Snare 7 DS			Fill Snare EDM			Snare 6 EK		
88	E5	E6	Snare R&B 1			Electric Triangle			Snare 8 DS			Snare 8 EDM			Snare 8 EK		
89	F5	F6	Vox Aik			Claves T8 2			Snare 9 DS			Snare 13 EDM			Snare 11 EK		
90	F#5	F#6	Udu High			Analog Shaker 3			Snare 10 DS		●	Impact Lo EDM			Snare 7 EK		
91	G5	G6	Filter Kick			Electric Clap 1			Filter Kick			Impact Hi EDM			Filter Kick		

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Voice Name			Trap Kit			Schlager Kit			Pop Drum Kit			Jazz Brush Kit Comp		
MSB-LSB-PC# (1-128)			127-0-72			127-0-73			127-0-74			127-0-76		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Kick 5 TP		●	Loop Element 1a SC			Hi-Hat Tip 00 PD			64	Surdo Mute	3
14	D-1	D0	Kick 6 TP		●	Loop Element 1b SC			Hi-Hat Edge 00 PD			64	Surdo Open	3
15	D#-1	D#0	White Noise Down 1		●	Loop Element 1c SC			Hi-Hat Tip 10 PD			64	Hi Q	
16	E-1	E0	Pink Noise Down 1		●	Loop Element 1d SC			Hi-Hat Edge 10 PD			64	Whip Slap	
17	F-1	F0	White Noise Down 2		●	Loop Element 1e SC			Hi-Hat Edge 25 PD			96	Scratch H	4
18	F#-1	F#0	Pink Noise Down 2		●	Loop Element 1f SC			Hi-Hat Edge 50 PD			96	Scratch L	4
19	G-1	G0	Finger Snap 1 TP			Loop Element 1g SC			Hi-Hat Edge 75 PD			96	Finger Snap	
20	G#-1	G#0	Finger Snap 2 TP			Loop Element 1h SC			Hi-Hat Edge 99 PD			96	Click Noise	
21	A-1	A0	SFX 1 TP		●	Loop Element 1i SC			Hi-Hat Pedal Closed PD			64	Metronome Click	
22	A#-1	A#0	SFX 2 TP		●	Loop Element 1f SC			Hi-Hat Pedal Splash			96	Metronome Bell	
23	B-1	B0	SFX 3 TP		●	Noise Up 1 SC		●	Seq Click L				Snare Brush Linear Sweep Short L/R JC	●
24	C0	C1	Kick 11 TP			Kick TB SC			Seq Click H				Snare Brush Linear Sweep Long L/R JC	●
25	C#0	C#1	Snare 4 TP			Loop Element 2a SC			Snare Brush Mute Snappy Off Edge Pressed JB				Snare Brush Snappy Off Edge Pressed JB	
26	D0	D1	Clap 1 TP			Loop Element 2b SC			Snare 5 no-Rim PD				Snare Brush Swirl Loop 1 JB	●
27	D#0	D#1	Clap 1 83P			Loop Element 2c SC			Snare 4 no-Rim PD				Snare Brush Pressed JB	
28	E0	E1	Snare 5 TP			Loop Element 2d SC			Snare 2 no-Rim PD				Snare Brush Swirl Loop 2 with Attack JC	●
29	F0	F1	Snare 6 TP			Loop Element 2h SC			Snare Roll PD			●	Snare Brush Swirl Loop 1 with Attack JC	●
30	F#0	F#1	Snare T9 3			Loop Element 2i SC			Snare 5 PD				Snare Brush Dynamic Sweep Long - Short JC	●
31	G0	G1	Snare 3 TP		●	Snare 1 SC			Snare 1 SC				Snare Brush Pressed Low Range JC	
32	G#0	G#1	Clap 2 TP			Snare 1 83P			Stick Count V0				Stick Count V0	
33	A0	A1	Kick 2 TP		●	Kick 2 81P			Kick 4 PD				Kick 5 VM	
34	A#0	A#1	Clap 3 TP			Snare 4 SC			Snare 2 Open Rim PD				Snare Brush Mute only Shaft JC	
35	B0	B1	Kick 1 TP		●	Kick 2 SC			Kick 2 PD				Kick 2 JB	
36	C1	C2	Kick 4 TP			Kick 1 SC			Kick 1 PD				Kick 3 JB	
37	C#1	C#2	Rim Shot 1 TP			Side Stick Power			Snare 1 Side-Stick PD				Snare 2 Side-Stick JS	
38	D1	D2	Snare 1 TP			Snare 2 SC			Snare 1 PD				Snare Brush Mute with Shaft JB	
39	D#1	D#2	Clap 5 TP			Snare 3 SC			Clap Power				Clap Power	
40	E1	E2	Snare 2 TP			Snare 6 SC			Snare 2 PD				Snare Brush with Shaft JB	
41	F1	F2	Tom 1 TP			Tom 1 SC			Tom PD 1				Tom JB 1	
42	F#1	F#2	Hi-Hat Closed 4 TP	1		Hi-Hat Closed 1 SC	1		Hi-Hat Edge 00 PD			1	Hi-Hat Center 00 JB	1
43	G1	G2	Tom 2 TP			Tom 2 TP			Tom 2 SC				Tom JB 2	
44	G#1	G#2	Hi-Hat Closed 5 TP	1		Hi-Hat Closed 2 SC	1		Hi-Hat Pedal Closed PD			1	Hi-Hat Pedal Closed JB	1
45	A1	A2	Tom 3 TP			Tom 3 SC			Tom PD 3				Tom JB 3	
46	A#1	A#2	Hi-Hat Open 1 TP	1		Hi-Hat Open 1 SC	1		Hi-Hat Edge 75 PD			1	Hi-Hat Edge 75 JB	1
47	B1	B2	Tom 4 TP			Tom 4 SC			Tom PD 4				Tom JB 4	
48	C2	C3	Tom 5 TP			Tom 5 SC			Tom PD 5				Tom JB 5	
49	C#2	C#3	Crash Cymbal T9			Crash Cymbal 1 SC			Crash Cymbal PD 1				Crash Cymbal JB 1	
50	D2	D3	Tom 6 TP			Tom 6 Hi SC			Tom PD 6				Tom JB 6	
51	D#2	D#3	Ride Cymbal T9			Ride Cymbal Acoustic 1			Ride Cymbal Tip PD				Ride Cymbal Tip JB	
52	E2	E3	Crash Cymbal 4			Impact 6 SC			China Cymbal PD				China Cymbal Real Brushes	
53	F2	F3	Ride Cymbal Cup 2			Crash Impact SC			Ride Cymbal Cup PD				Ride Cymbal Cup JB	
54	F#2	F#3	Tambourine Hit			Tambourine			Tambourine				Tambourine	
55	G2	G3	Splash Cymbal 2			Crash Cymbal 2 SC			Splash Cymbal PD				Splash Cymbal JB	
56	G#2	G#3	Cowbell 1 TP			Cowbell 1			Cowbell 1 JB				Cowbell 1 JB	
57	A2	A3	Crash Cymbal 2			Crash Cymbal 3 SC			Crash Cymbal PD 2				Crash Cymbal JB 2	
58	A#2	A#3	Cowbell T8			Snare 5 SC			Vibraslap				Vibraslap	
59	B2	B3	Ride Cymbal 3			Snare 7 SC			Ride Cymbal Real 2				Ride Backend JB	
60	C3	C4	Bongo H Open One Finger			Snare 8 SC			Bongo H				Bongo H	
61	C#3	C#4	Bongo L Open Three Finger			Snare 9 SC			Bongo L				Bongo L	
62	D3	D4	Conga H Tip			Snare 10 SC			Conga H Mute				Conga H Mute	
63	D#3	D#4	Conga H Slap Open			Clap 7 SC			Conga H Open				Conga H Open	
64	E3	E4	Conga H Open 2			Clap 1 SC			Conga L				Conga L	
65	F3	F4	Timbale H			Clap 2 SC			Timbale H				Timbale H	
66	F#3	F#4	Timbale L			Clap 3 SFX SC			Timbale L				Timbale L	
67	G3	G4	Agogo H			Clap 6 SC			Agogo H				Agogo H	
68	G#3	G#4	Agogo L			Clap 5 SFX SC			Agogo L				Agogo L	
69	A3	A4	Cabasa			Shaker 4 SC			Cabasa				Cabasa	
70	A#3	A#4	Maracas Stur 2			Shaker 3 SC			Maracas			●	Maracas	●
71	B3	B4	Vox Drum L			Clap 8 SC			Samba Whistle H			●	Samba Whistle H	●
72	C4	C5	Vox Drum H			Echo Shot 1 SC			Samba Whistle L			●	Samba Whistle L	●
73	C#4	C#5	Guiro Short			Echo Shot 2 SC			Guiro Short				Guiro Short	
74	D4	D5	Guiro Long		●	Echo Shot 3 SC			Guiro Long			●	Guiro Long	●
75	D#4	D#5	Cowbell 2 TP			Echo Shot 4 SC			Claves				Claves	
76	E4	E5	Wood Block H			Hi-Hat Closed 3 SC			Wood Block H				Wood Block H	
77	F4	F5	Wood Block L			Hi-Hat Closed 4 SC			Wood Block L				Wood Block L	
78	F#4	F#5	Hi-Hat Closed 1 TP			Hi-Hat Closed 5 SC			Cuica Mute				Cuica Mute	
79	G4	G5	Hi-Hat Closed 2 TP			Hi-Hat Open 2 SC			Cuica Open				Cuica Open	
80	G#4	G#5	Triangle Mute	2		Shaker 1 SC	2		Triangle Mute			2	Triangle Mute	2
81	A4	A5	Triangle Open	2		Shaker 2 SC	2		Triangle Open			2	Triangle Open	2
82	A#4	A#5	Hi-Hat Open 5 TP			Shaker 6 SC			Shaker				Shaker	
83	B4	B5	Kick 7 TP		●	Shaker 5 SC			Jingle Bells				Jingle Bells	
84	C5	C6	Kick 8 TP		●	Reverse 1 SC		●	Wind Chime				Wind Chime	
85	C#5	C#6	Kick 9 TP		●	Reverse 3 SC		●						
86	D5	D6	Kick 10 TP			Reverse Snare 1 SC		●						
87	D#5	D#6	Snare 7 TP			Long Snare SC								
88	E5	E6	Snare 8 TP			LpDr Kick SC								
89	F5	F6	Snare 9 TP			LpDr Hi-Hat 1 SC								
90	F#5	F#6	Snare 10 TP			LpDr Snare SC								
91	G5	G6	Clap 4 TP			LpDr Hi-Hat 2 SC								

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Voice Name			Studio Kit			Power Kit 1			Power Kit 2			Acoustic Kit			Rock Kit		
MSB-LSB-PC# (1-128)			127-0-87			127-0-88			127-0-89			127-0-90			127-0-91		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Surdo Mute	3		Surdo Mute	3		Surdo Mute	3		Surdo Mute	3		Surdo Mute	3	
14	D-1	D0	Surdo Open	3		Surdo Open	3		Surdo Open	3		Surdo Open	3		Surdo Open	3	
15	D#-1	D#0	Hi Q			Hi Q			Hi Q			Hi Q			Hi Q		
16	E-1	E0	Whip Slap			Whip Slap			Whip Slap			Whip Slap			Whip Slap		
17	F-1	F0	Scratch H	4		Scratch H	4		Scratch H	4		Scratch H	4		Scratch H	4	
18	F#-1	F#0	Scratch L	4		Scratch L	4		Scratch L	4		Scratch L	4		Scratch L	4	
19	G-1	G0	Finger Snap			Finger Snap			Finger Snap			Finger Snap			Finger Snap		
20	G#-1	G#0	Click Noise			Click Noise			Click Noise			Click Noise			Click Noise		
21	A-1	A0	Metronome Click			Metronome Click			Metronome Click			Metronome Click			Metronome Click		
22	A#-1	A#0	Metronome Bell			Metronome Bell			Metronome Bell			Metronome Bell			Metronome Bell		
23	B-1	B0	Seq Click L			Seq Click L			Seq Click L			Seq Click L			Seq Click L		
24	C0	C1	Seq Click H			Seq Click H			Seq Click H			Seq Click H			Seq Click H		
25	C#0	C#1	Brush Tap			Brush Tap			Brush Tap			Brush Tap			Brush Tap		
26	D0	D1	Brush Swirl		●	Brush Swirl		●	Brush Swirl		●	Brush Swirl		●	Brush Swirl		●
27	D#0	D#1	Brush Slap			Brush Slap			Brush Slap			Brush Slap			Brush Slap		
28	E0	E1	Brush Tap Swirl		●	Brush Tap Swirl		●	Brush Tap Swirl		●	Brush Tap Swirl		●	Brush Tap Swirl		●
29	F0	F1	Snare Roll		●	Snare Roll		●	Snare Roll		●	Snare Roll Acoustic		●	Snare Roll Rock		●
30	F#0	F#1	Castanet			Castanet			Castanet			Castanet			Castanet		
31	G0	G1	Snare Studio 2			Snare Soft Power 1			Snare Soft Power 2			Snare Soft Acoustic			Snare Soft Rock		
32	G#0	G#1	Sticks			Sticks			Sticks			Sticks			Sticks		
33	A0	A1	Kick Ambience H			Kick Ambient+			Kick Ambient+			Kick Soft Acoustic			Kick Soft Rock		
34	A#0	A#1	Open Rim Shot			Open Rim Power 1			Open Rim Power 2			Rim Acoustic			Rim Rock		
35	B0	B1	Kick Ambience L			Kick Power Open			Kick Power Open			Kick Mute Acoustic			Kick Rock Heavy		
36	C1	C2	Kick Studio			Kick Power Mute			Kick Power Mute			Kick Open Acoustic			Kick Rock		
37	C#1	C#2	Side Stick			Side Stick Power			Side Stick Power			Stick Acoustic			Stick Rock		
38	D1	D2	Snare Studio M			Snare Power 1			Snare Power 2			Snare Acoustic			Snare Rock		
39	D#1	D#2	Hand Clap			Hand Clap Power			Hand Clap Power			Hand Clap Power			Hand Clap Power		
40	E1	E2	Snare Studio L			Snare Rough			Snare Loose			Snare Rough Acoustic			Snare Dry Rock		
41	F1	F2	Floor Tom L			Tom Power 1			Tom Power 1			Tom Acoustic 1			Tom Rock 1		
42	F#1	F#2	Hi-Hat Closed	1		Hi-Hat Closed Power	1		Hi-Hat Closed Power+Edge	1		Hi-Hat Closed Acoustic	1		Hi-Hat Closed Rock	1	
43	G1	G2	Floor Tom H			Tom Power 2			Tom Power 2			Tom Acoustic 2			Tom Rock 2		
44	G#1	G#2	Hi-Hat Pedal	1		Hi-Hat Pedal Power	1		Hi-Hat Pedal Power	1		Hi-Hat Pedal Acoustic	1		Hi-Hat Pedal Rock	1	
45	A1	A2	Low Tom			Tom Power 3			Tom Power 3			Tom Acoustic 3			Tom Rock 3		
46	A#1	A#2	Hi-Hat Open	1		Hi-Hat Open Power	1		Hi-Hat Open Power	1		Hi-Hat Open Acoustic	1		Hi-Hat Open Rock	1	
47	B1	B2	Mid Tom L			Tom Power 4			Tom Power 4			Tom Acoustic 4			Tom Rock 4		
48	C2	C3	Mid Tom H			Tom Power 5			Tom Power 5			Tom Acoustic 5			Tom Rock 5		
49	C#2	C#3	Crash Cymbal 1			Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1		
50	D2	D3	High Tom			Tom Power 6			Tom Power 6			Tom Acoustic 6			Tom Rock 6		
51	D#2	D#3	Ride Cymbal 1			Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1		
52	E2	E3	Chinese Cymbal			China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Acoustic		
53	F2	F3	Ride Cymbal Cup			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic		
54	F#2	F#3	Tambourine			Tambourine			Tambourine			Tambourine			Tambourine		
55	G2	G3	Splash Cymbal			Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Acoustic		
56	G#2	G#3	Cowbell			Cowbell			Cowbell			Cowbell			Cowbell		
57	A2	A3	Crash Cymbal 2			Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2		
58	A#2	A#3	VibraSlap			VibraSlap			VibraSlap			VibraSlap			VibraSlap		
59	B2	B3	Ride Cymbal 2			Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2		
60	C3	C4	Bongo H			Bongo H			Bongo H			Bongo H			Bongo H		
61	C#3	C#4	Bongo L			Bongo L			Bongo L			Bongo L			Bongo L		
62	D3	D4	Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute			Conga H Mute		
63	D#3	D#4	Conga H Open			Conga H Open			Conga H Open			Conga H Open			Conga H Open		
64	E3	E4	Conga L			Conga L			Conga L			Conga L			Conga L		
65	F3	F4	Timbale H			Timbale H			Timbale H			Timbale H			Timbale H		
66	F#3	F#4	Timbale L			Timbale L			Timbale L			Timbale L			Timbale L		
67	G3	G4	Agogo H			Agogo H			Agogo H			Agogo H			Agogo H		
68	G#3	G#4	Agogo L			Agogo L			Agogo L			Agogo L			Agogo L		
69	A3	A4	Cabasa			Cabasa			Cabasa			Cabasa			Cabasa		
70	A#3	A#4	Maracas			Maracas			Maracas			Maracas			Maracas		
71	B3	B4	Samba Whistle H		●	Samba Whistle H		●	Samba Whistle H		●	Samba Whistle H		●	Samba Whistle H		●
72	C4	C5	Samba Whistle L		●	Samba Whistle L		●	Samba Whistle L		●	Samba Whistle L		●	Samba Whistle L		●
73	C#4	C#5	Guiro Short			Guiro Short			Guiro Short			Guiro Short			Guiro Short		
74	D4	D5	Guiro Long		●	Guiro Long		●	Guiro Long		●	Guiro Long		●	Guiro Long		●
75	D#4	D#5	Claves			Claves			Claves			Claves			Claves		
76	E4	E5	Wood Block H			Wood Block H			Wood Block H			Wood Block H			Wood Block H		
77	F4	F5	Wood Block L			Wood Block L			Wood Block L			Wood Block L			Wood Block L		
78	F#4	F#5	Cuica Mute			Cuica Mute			Cuica Mute			Cuica Mute			Cuica Mute		
79	G4	G5	Cuica Open			Cuica Open			Cuica Open			Cuica Open			Cuica Open		
80	G#4	G#5	Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2		Triangle Mute	2	
81	A4	A5	Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2		Triangle Open	2	
82	A#4	A#5	Shaker			Shaker			Shaker			Shaker			Shaker		
83	B4	B5	Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells			Jingle Bells		
84	C5	C6	Bell Tree			Wind Chime			Wind Chime			Wind Chime			Wind Chime		
85	C#5	C#6															
86	D5	D6															
87	D#5	D#6															
88	E5	E6															
89	F5	F6															
90	F#5	F#6															
91	G5	G6															

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Voice Name			Real Drum Kit			New SFX Kit 1			New SFX Kit 2			Noises Kit			Bass Drum Kit		
MSB-LSB-PC# (1-128)			127-0-92			126-0-3			126-0-4			126-0-9			126-0-21		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Surdo Mute	3											BD Electro		
14	D-1	D0	Surdo Open	3											BD FX Gate		
15	D#-1	D#0	Hi Q												BD Hammer		
16	E-1	E0	Whip Slap												BD Analog Power		
17	F-1	F0	Scratch H	4											BD Analog Distortion 5		
18	F#-1	F#0	Scratch L	4											BD Analog Distortion 6		
19	G-1	G0	Finger Snap												BD Analog Distortion 4		
20	G#-1	G#0	Click Noise												BD Analog Distortion 3		
21	A-1	A0	Metronome Click												BD Analog Distortion 2		
22	A#-1	A#0	Metronome Bell												BD Analog Tight		
23	B-1	B0	Seq Click L												BD Analog 94		
24	C0	C1	Seq Click H												BD Analog Blip 2		
25	C#0	C#1	Brush Tap												BD Analog Rubber 2		
26	D0	D1	Brush Tap Swirl		●										BD Analog 93		
27	D#0	D#1	Brush Slap												BD Analog 90		
28	E0	E1	Brush Tap Swirl		●										BD Analog 83		
29	F0	F1	Snare Roll Rock		●										BD Analog 82		
30	F#0	F#1	Castanet												BD Analog 92		
31	G0	G1	Snare Tight												BD Analog 91		
32	G#0	G#1	Sticks												BD Analog Deep		
33	A0	A1	Kick Genuine												BD Analog Hard 2		
34	A#0	A#1	Rim Real												BD Analog Hard 1		
35	B0	B1	Kick Real 1												BD Analog Blip 1		
36	C1	C2	Kick Real 2			Cutting Noise 1		●	Phone Call 2		●	White Noise		●	BD Analog Rubber 1		
37	C#1	C#2	Stick Real			Cutting Noise 2		●	Door Squeak 2		●	Pink Noise		●	BD Analog Loose		
38	D1	D2	Snare Real 1						Door Slam 2		●	White Noise Down 1		●	BD Synth 1		
39	D#1	D#2	Clap Power			String Slap		●	Scratch Cut		●	Pink Noise Down 1		●	BD Synth 2		
40	E1	E2	Snare Real 2						Scratch Split		●	White Noise Down 2		●	BD Analog Distortion 1		
41	F1	F2	Tom Real 1						Wind Chime		●	Pink Noise Down 2		●	Ripper		
42	F#1	F#2	Hi-Hat Closed Real	1					Telephone Ring 2		●	White Noise Up 2		●	BD Analog 70 L		
43	G1	G2	Tom Real 2									White Noise Up 1		●	BD Analog 70		
44	G#1	G#2	Hi-Hat Pedal Real	1								Pink Noise Up		●	BD Analog 80		
45	A1	A2	Tom Real 3									White Noise Up Release		●	BD Analog 80 Long		
46	A#1	A#2	Hi-Hat Open Real	1								Pink Noise Up Release		●	BD Dry		
47	B1	B2	Tom Real 4									White Noise Up LFO		●	BD Dry Hard		
48	C2	C3	Tom Real 5									Pink Noise Up LFO		●	BD Room 1		
49	C#2	C#3	Crash Cymbal Real 1												BD Soft		
50	D2	D3	Tom Real 6												BD Room 2		
51	D#2	D#3	Ride Cymbal Real 1												BD Break Lo-fi 2		
52	E2	E3	China Cymbal Real			Flute Key Click		●	Car Engine Ignition		●				BD Break Lo-fi 1		
53	F2	F3	Ride Cymbal Cup Real						Car Tires Squeal		●				BD & Hi-Hat Open		
54	F#2	F#3	Tambourine						Car Passing		●				BD Jungle 2		
55	G2	G3	Splash Cymbal Real						Car Crash		●				BD Jungle 1		
56	G#2	G#3	Cowbell						Siren 2		●				BD Jungle 3		
57	A2	A3	Crash Cymbal Real 2						Train 2		●				BD D&B 1		
58	A#2	A#3	Vibraslap						Jet Plane 2		●				BD D&B 2		
59	B2	B3	Ride Cymbal Real 2						Starship		●				BD RX5 1		
60	C3	C4	Bongo H						Burst		●				BD RX5 2		
61	C#3	C#4	Bongo L						Roller Coaster		●				BD Room 3		
62	D3	D4	Conga H Mute						Submarine		●				BD Power Gate		
63	D#3	D#4	Conga H Open												BD R&B 1		
64	E3	E4	Conga L												BD R&B 2		
65	F3	F4	Timbale H												BD Lo-fi		
66	F#3	F#4	Timbale L												BD Hip Deep		
67	G3	G4	Agogo H												BD Break Deep		
68	G#3	G#4	Agogo L			Shower 2		●	Laugh		●				BD Break Heavy		
69	A3	A4	Cabasa			Thunder 2		●	Scream 2		●				BD Break Hard		
70	A#3	A#4	Maracas			Wind 2		●	Punch 2		●				Big Drum		
71	B3	B4	Samba Whistle H		●	Stream 2		●	Heart Beat		●				Taiko Drum		
72	C4	C5	Samba Whistle L		●	Bubble 2		●	Foot Steps 2		●				Surdo Open		
73	C#4	C#5	Guiro Short			Feed		●							Feet 2		
74	D4	D5	Guiro Long		●										BD Industrial		
75	D#4	D#5	Claves												Door Slam		
76	E4	E5	Wood Block H												Punch		
77	F4	F5	Wood Block L												Heart		
78	F#4	F#5	Cuica Mute												Feet 1		
79	G4	G5	Cuica Open												BD Human		
80	G#4	G#5	Triangle Mute	2											BD Human Deep		
81	A4	A5	Triangle Open	2											Vox Buh!		
82	A#4	A#5	Shaker												Vox Muh!		
83	B4	B5	Jingle Bells														
84	C5	C6	Wind Chime			Dog		●	Machine Gun 2		●						
85	C#5	C#6				Horse		●	Laser Gun		●						
86	D5	D6				Bird Tweet		●	Explosion 2		●						
87	D#5	D#6							Firework		●						
88	E5	E6															
89	F5	F6															
90	F#5	F#6				Ghost		●									
91	G5	G6				Maou		●									

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Voice Name			Reverse Bass Drum Kit			Cuban Kit			Pop Latin Kit 1			Pop Latin Kit 2		
MSB-LSB-PC# (1-128)			126-0-22			126-0-41			126-0-44			126-0-45		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Reverse BD Electro						Cajon Low			Cajon Low		
14	D-1	D0	Reverse BD Fx Gate						Cajon Slap			Cajon Slap		
15	D#-1	D#0	Reverse BD Hammer						Cajon Tip			Cajon Tip		
16	E-1	E0	Reverse BD Analog Power						Claves High			Claves High		
17	F-1	F0							Claves Low			Claves Low		
18	F#-1	F#0	Reverse BD Analog Distortion 6						Hand Clap			Hand Clap		
19	G-1	G0												
20	G#-1	G#0	Reverse BD Analog Distortion 3						Finger Snap			Finger Snap		
21	A-1	A0	Reverse BD Analog Distortion 2						Castanet			Castanet		
22	A#-1	A#0	Reverse BD Analog Tight			Conga H Tip			Conga H Tip			Conga H Tip		
23	B-1	B0	Reverse BD Analog 94			Conga H Heel			Conga H Heel			Conga H Heel		
24	C0	C1	Reverse BD Analog Blip 2			Conga H Open			Conga H Open			Conga H Open		
25	C#0	C#1	Reverse BD Analog Rubber 2			Conga H Mute			Conga H Mute			Conga H Mute		
26	D0	D1	Reverse BD Analog 93			Conga H Slap Open			Conga H Slap Open			Conga H Slap Open		
27	D#0	D#1	Reverse BD Analog 90			Conga H Slap			Conga H Slap			Conga H Slap		
28	E0	E1	Reverse BD Analog 83			Conga H Slap Mute			Conga H Slap Mute			Conga H Slap Mute		
29	F0	F1	Reverse BD Analog 82			Conga L Tip			Conga L Tip			Conga L Tip		
30	F#0	F#1				Conga L Heel			Conga L Heel			Conga L Heel		
31	G0	G1	Reverse BD Analog 91			Conga L Open			Conga L Open			Conga L Open		
32	G#0	G#1	Reverse BD Analog Deep			Conga L Mute			Conga L Mute			Conga L Mute		
33	A0	A1				Conga L Slap Open			Conga L Slap Open			Conga L Slap Open		
34	A#0	A#1	Reverse BD Analog Hard 1			Conga L Slap			Conga L Slap			Conga L Slap		
35	B0	B1	Reverse BD Analog Blip 1			Conga L Slide		●	Conga L Slide		●	Conga L Slide		●
36	C1	C2	Reverse BD Analog Rubber 1			Bongo H Open One Finger			Bongo H Open One Finger			Bongo H Open One Finger		
37	C#1	C#2	Reverse BD Analog Loose			Bongo H Open Three Finger			Bongo H Open Three Finger			Bongo H Open Three Finger		
38	D1	D2	Reverse BD Synth 1			Bongo H Rim			Bongo H Rim			Bongo H Rim		
39	D#1	D#2	Reverse BD Synth 2			Bongo H Tip			Bongo H Tip			Bongo H Tip		
40	E1	E2	Reverse BD Analog Distortion 1			Bongo H Heel			Bongo H Heel			Bongo H Heel		
41	F1	F2	Reverse Ripper			Bongo H Slap			Bongo H Slap			Bongo H Slap		
42	F#1	F#2				Bongo L Open One Finger			Bongo L Open One Finger			Bongo L Open One Finger		
43	G1	G2	Reverse BD Analog 70			Bongo L Open Three Finger			Bongo L Open Three Finger			Bongo L Open Three Finger		
44	G#1	G#2	Reverse BD Analog 81			Bongo L Rim			Bongo L Rim			Bongo L Rim		
45	A1	A2				Bongo L Tip			Bongo L Tip			Bongo L Tip		
46	A#1	A#2	Reverse BD Dry			Bongo L Heel			Bongo L Heel			Bongo L Heel		
47	B1	B2				Bongo L Slap			Bongo L Slap			Bongo L Slap		
48	C2	C3				Timbale L			Timbale L			Timbale L		
49	C#2	C#3	Reverse BD Soft											
50	D2	D3	Reverse BD Room 2											
51	D#2	D#3	Reverse BD Break Lo-fi 2											
52	E2	E3	Reverse BD Break Lo-fi 1											
53	F2	F3	Reverse BD & Hi-Hat Open			Paila L			Paila L			Paila L		
54	F#2	F#3				Timbale H			Timbale H			Timbale H		
55	G2	G3												
56	G#2	G#3	Reverse BD Jungle 3											
57	A2	A3	Reverse BD D&B 1											
58	A#2	A#3	Reverse BD D&B 2											
59	B2	B3	Reverse BD RX5 1			Paila H			Paila H			Paila H		
60	C3	C4	Reverse BD RX5 2			Cowbell Top			Cowbell Top			Cowbell Top		
61	C#3	C#4	Reverse BD Room 3						Cowbell 1			Cowbell 1		
62	D3	D4	Reverse BD Power Gate						Cowbell 2			Cowbell 2		
63	D#3	D#4	Reverse BD R&B 1						Cowbell 3			Cowbell 3		
64	E3	E4	Reverse BD R&B 2			Guiro Short			Guiro Short			Guiro Short		
65	F3	F4	Reverse BD Lo-fi			Guiro Long			Guiro Long		●	Guiro Long		●
66	F#3	F#4							Metal Guiro Short			Metal Guiro Short		
67	G3	G4	Reverse BD Break Deep						Metal Guiro Long		●	Metal Guiro Long		●
68	G#3	G#4	Reverse BD Break Heavy			Tambourine			Tambourine			Tambourine		
69	A3	A4	Reverse BD Break Hard						Tambourim Open			Tambourim Open		
70	A#3	A#4	Reverse Big Drum						Tambourim Mute			Tambourim Mute		
71	B3	B4	Reverse Talko Drum						Tambourim Tip			Tambourim Tip		
72	C4	C5	Reverse Surdo Open			Maracas			Maracas			Maracas		
73	C#4	C#5	Reverse Feet 2			Shaker			Shaker			Shaker		
74	D4	D5	Reverse Tom Industrial			Cabasa			Cabasa			Cabasa		
75	D#4	D#5	Reverse Door Slam						Cuica Mute			Cuica Mute		
76	E4	E5	Reverse Punch						Cuica Open			Cuica Open		
77	F4	F5							Cowbell High 1			Cowbell High 1		
78	F#4	F#5	Reverse Feet 1						Cowbell High 2			Cowbell High 2		
79	G4	G5	Reverse BD Human						Shekere			Shekere		
80	G#4	G#5	Reverse BD Human Deep						Shekere Tone			Shekere Tone		
81	A4	A5	Reverse Vox Buh!						Triangle Mute			Triangle Mute		
82	A#4	A#5	Reverse Vox Muh!						Triangle Open		1	Triangle Open		1
83	B4	B5												
84	C5	C6							Wind Chime			Wind Chime		
85	C#5	C#6												
86	D5	D6												
87	D#5	D#6												
88	E5	E6												
89	F5	F6												
90	F#5	F#6												
91	G5	G6												

Same as Standard Kit 1
No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.
*2 Key Off: Keys marked "●" stop sounding the instant they are released.
*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Voice Name			Pop Perc Kit			Cymbal Kit			Turkish Kit			Vocal Beatbox		
MSB-LSB-PC# (1-128)			126-0-46			126-0-50			126-0-68			126-0-107		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off	Full Name	Alt Grp	Key Off
13	C#-1	C#0	Djembe Bass AF						Asma Davul Left Side			Kick 3 Fitubom 2 BB		
14	D-1	D0	Djembe Close AF						Asma Davul Right Side			Kick 5 Throat BB		
15	D#-1	D#0	Djembe Open AF						Asma Davul Side Body			Kick 4 Throat BB		
16	E-1	E0	Djembe Slap AF						Asma Davul Both Sides			Special 18 VScratch 1 BB		●
17	F-1	F0	Cajon Bass PP						Koltuk Davul Flam			Special 18 VScratch 2 BB		●
18	F#-1	F#0	Cajon Mid PP						Koltuk Davul Teke			Special 3 VScratch 2 BB		●
19	G-1	G0	Cajon Hi PP						Koltuk Davul Tek			Special 18 VScratch 3 BB		●
20	G#-1	G#0	Conga Lo Open BR	1					Koltuk Davul Dum			Kick 3 Fitubom 1 BB	4	
21	A-1	A0	Conga Lo Close BR	1					Bendir Teke Flam			Kick 6 Electro 2 BB	4	
22	A#-1	A#0	Conga Lo Slap Open BR	1					Bendir Teke Dead			Special 14 ZtkPauu 1 BB		●
23	B-1	B0	Conga Lo Slap Mute BR	1					Bendir Tek Dead			Special 14 ZtkPauu 2 BB		●
24	C0	C1	Conga Hi Bass BR	2					Bendir Teke			Kick 7 Throat BB		●
25	C#0	C#1	Conga Hi Heel BR	2					Bendir Tek			Special 20 Breathe 2 BB	3	●
26	D0	D1	Conga Hi Tip BR	2					Bendir Slap	2		Special 20 Breathe 1 BB	3	●
27	D#0	D#1	Conga Hi Open BR	2					Bendir Dum	2		Special 19 Breathe 1 BB	3	●
28	E0	E1	Conga Hi Slap Close BR	2					Zil Right Close	3		Special 21 Breathe 1 BB	3	●
29	F0	F1	Conga Hi Slap Open BR	2					Zil Right Open	3		Special 11 Vibrato 1 BB		●
30	F#0	F#1	Conga Hi Slap Mute BR	2					Zil Left Close	4		Snare 4 T-Style BB		
31	G0	G1	Bongo Lo Open 1 / Rim 1 AF						Zil Left Open	4		Snare 6 ISCH-Style BB		
32	G#0	G#1	Bongo Lo Open 3 AF						Tef Teke Flam	5		Snare Clap 1 BB		
33	A0	A1	Bongo Lo Close 3 AF						Tef Tek Mute	5		Kick 6 Electro 1 BB	4	●
34	A#0	A#1	Bongo Lo Slap AF						Tef Teke Damped			Snare 7 TSCH-Style BB		
35	B0	B1	Bongo Hi Heel AF						Tef Tek Mute Medium			Kick 2 Classic 1 BB	4	
36	C1	C2	Bongo Hi Tip AF			Kick A			Tef Dum Mute			Kick 1 Classic 1 BB	4	
37	C#1	C#2	Bongo Hi Open 1 / Rim 1 AF			Timbale A			Tef Cymbal	9		Snare 3 Side Stick 1 BB		
38	D1	D2	Bongo Hi Open 3 / Rim 3 AF			China Cymbal A			Tef Cymbal Mute	9		Snare 1 Classic 1 BB		●
39	D#1	D#2	Bongo Hi Mute1 AF			Crash Cymbal A			Tef Tremolo		●	Snare 5 KCH-Style BB		●
40	E1	E2	Bongo Hi Slap AF			Ride Cymbal A			Tef Shake 1			Snare 8 KUCH-Style BB		●
41	F1	F2	Cowbell 5 Mouth AF			Splash Cymbal A			Tef Shake 2			Tom 6 Classic 1 BB		●
42	F#1	F#2	Cowbell 3 Mouth AF						Tef Tek Flam			Hi-Hat 1 Z-Style BB	1	●
43	G1	G2	Chabell Open AF						Tef Full Open			Tom 5 Classic 1 BB		●
44	G#1	G#2	Cowbell RD			Crash Cymbal B1			Tef Teke Open Short			Hi-Hat 5 Tch-Style BB	1	●
45	A1	A2	Fibre Clave PP			Crash Cymbal B2			Tef Tek Open Short			Tom 4 Classic 1 BB		●
46	A#1	A#2	Plastic Wood Block AF			Ride Cymbal B			Tef Tek Open			Hi-Hat 7 Open 1 BB	1	●
47	B1	B2	African Clave AF						Tef Dum Open			Tom 3 Classic 1 BB		●
48	C2	C3	Wood Clave AF						Hollo Finger Dead			Tom 2 Classic 1 BB		●
49	C#2	C#3	Crash Cymbal AF			Crash Cymbal C			Hollo Slap			Cymbal 1 Crush Hi 1 BB		
50	D2	D3	Temp Block 1 PP			Ride Cymbal C			Hollo Dum			Tom 1 Classic 1 BB		●
51	D#2	D#3	Temp Block 3 PP			Brush Ride Cymbal C			Kasik	1		Cymbal 1 Crush Hi 2 BB		
52	E2	E3	Temp Block 5 PP			Brush Sizzle Cymbal C			Kasik Flam	1		Cymbal 4 China 1 BB		
53	F2	F3	Tambourine 1 Shake PP						Bass Darbuka Tek Dead			Cymbal 4 China 2 BB		
54	F#2	F#3	Tambourine 1 Hit PP						Bass Darbuka Tek Flam			Hi-Hat 8 Pedal 2 BB	1	●
55	G2	G3	Tambourine 2 Shake PP			Crash Cymbal D1			Bass Darbuka Teke			Cymbal 3 FXCymbal Hi BB		
56	G#2	G#3	Tambourine 2 Hit PP			Crash Cymbal D2			Bass Darbuka Teke Other Finger			Hi-Hat 6 Wood-Style BB		
57	A2	A3	Tambourine 3 Hit PP			Crash Cymbal D3			Bass Darbuka Teke Index Finger			Cymbal 2 Crash Lo 1 BB		
58	A#2	A#3	Palmas L Mute AF			Ride Cymbal D			Bass Darbuka Tek			Special 5 Scratch 1 BB		●
59	B2	B3	Palmas R Mute AF			Splash Cymbal D			Bass Darbuka Slap			Cymbal 2 Crash Lo 2 BB		
60	C3	C4	Palmas L Open AF						Bass Darbuka Slap Medium	7		Tom 6 Rim Click BB		
61	C#3	C#4	Palmas R Open AF						Bass Darbuka Dum	7		Tom 5 Rim Click BB		
62	D3	D4	Claps Lo PP			Crash Cymbal E1			Darbuka Roll Close	6	●	Tom 4 Rim Click BB		
63	D#3	D#4	Claps Hi PP			Crash Cymbal E2			Darbuka Roll Open	6	●	Tom 3 Rim Click BB		
64	E3	E4	Cabasa L BR			Ride Cymbal E			Darbuka Teke Damped Flam			Tom 2 Rim Click BB	2	
65	F3	F4	Cabasa R BR			Hi-Hat Half Open E			Darbuka Tek Dead			Special 6 Now BB	2	●
66	F#3	F#4	Shaker 1 Up BR						Darbuka Tek Damped			Special 6 Get Ready BB		●
67	G3	G4	Shaker 1 Down BR						Darbuka Teke Open Flam			Special 13 Fantare 1 BB		●
68	G#3	G#4	Shaker 1 Long BR		●				Darbuka Teke Open			Special 12 Trumpet 1 BB		●
69	A3	A4	Shaker 2 Up BR						Darbuka Teke Other Finger 1			Percussion 1 Shaker 1 BB		
70	A#3	A#4	Shaker 2 Down BR						Darbuka Teke Index Finger 1			Hi-Hat 2 S-Style BB		
71	B3	B4	Shaker 2 Long BR		●				Darbuka Tek 1			Special 1 Scratch 1 BB		●
72	C4	C5	Shaker 3 Up BR			Crash Cymbal F1			Darbuka Teke Other Finger 2			Special 2 Scratch 1 BB		●
73	C#4	C#5	Shaker 3 Down BR			Brush Crash Cymbal F1			Darbuka Teke Index Finger 2			Hi-Hat 3 NZ-Style BB		
74	D4	D5	Shaker 3 Long BR		●	Crash Cymbal F2			Darbuka Tek 2			Special 4 Scratch 1 BB		●
75	D#4	D#5	Shaker 4 Up BR			Jazz Ride Cymbal F1			Darbuka Slap Medium			Hi-Hat 4 F-Style BB		
76	E4	E5	Shaker 4 Down BR			Crash Cymbal F3			Darbuka Slap	8		Special 9 Can 2 BB		
77	F4	F5	Shaker 4 Long BR		●	Hi-Hat Splash F			Darbuka Dum	8		Special 9 Can 1 BB		
78	F#4	F#5	Shaker 5 Up PP			Ride Cymbal F1			Bongo Tek Roll		●	Tom 5 Electronic BB		
79	G4	G5	Shaker 5 Down PP			Crash Cymbal F4			Bongo Flam			Tom 4 Electronic BB		
80	G#4	G#5	Udu Bass Open PP			Ride Cymbal F2			Bongo Tek Flam			Tom 3 Electronic BB		
81	A4	A5	Udu Bass PP			Brush Crash Cymbal F2			Bongo Tek			Tom 2 Electronic BB		
82	A#4	A#5	Udu Heel PP			Jazz Ride Cymbal F2			Bongo Slap			Tom 1 Electronic BB	2	
83	B4	B5	Udu Tip PP			Crash Cymbal F5			Bongo Flam Hi			Special 16 VScratch 1 BB	2	●
84	C5	C6	Udu Body PP						Bongo Dum			Special 16 VScratch 2 BB		●
85	C#5	C#6	Udu Top PP									Special 17 VScratch 1 BB		●
86	D5	D6	Triangle Open Up BR	3								Special 17 VScratch 2 BB		●
87	D#5	D#6	Triangle Open Dn BR	3								Special 15 Peepkp 1 BB		●
88	E5	E6	Triangle Close Up BR	3								Special 15 Peepkp 2 BB		●
89	F5	F6	Triangle Close Dn BR	3								Special 7 Laughter 1 BB		●
90	F#5	F#6	Chimes Down AF											
91	G5	G6	Chimes Up AF											

Same as Standard Kit 1
No Sound



*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

CSP-295GP, CSP-295, CSP-275, CSP-255 Data List

Voice Name			Vocal Effects Kit			Gospel AdLibs		
MSB-LSB-PC# (1-128)			126-0-110			126-0-111		
Note#	MIDI Note	Keyboard Note	Full Name	Alt Grp (*1)	Key Off (*2)	Full Name	Alt Grp	Key Off
13	C#-1	C#0						
14	D-1	D0						
15	D#-1	D#0						
16	E-1	E0						
17	F-1	F0						
18	F#-1	F#0						
19	G-1	G0						
20	G#-1	G#0						
21	A-1	A0						
22	A#-1	A#0						
23	B-1	B0						
24	C0	C1						
25	C#0	C#1						
26	D0	D1						
27	D#0	D#1						
28	E0	E1						
29	F0	F1						
30	F#0	F#1						
31	G0	G1						
32	G#0	G#1						
33	A0	A1						
34	A#0	A#1						
35	B0	B1						
36	C1	C2	Male "Ha" 1		●			
37	C#1	C#2	Female "Ha" 1		●			
38	D1	D2	Male "Ha" 2		●			
39	D#1	D#2	Male "Ha" 3		●			
40	E1	E2	Male "Bh" 1		●			
41	F1	F2	Female "Bh" 1		●			
42	F#1	F#2	Male "Kh" 1		●			
43	G1	G2	Female "Kh" 1		●			
44	G#1	G#2	Male "Ph" 1		●			
45	A1	A2	Female "Ph" 1		●			
46	A#1	A#2	Male "Th" 1		●			
47	B1	B2	Female "Th" 1		●			
48	C2	C3	Male "Bh" 2		●	C'mon		●
49	C#2	C#3	Female "Bh" 2		●	Hoo!		●
50	D2	D3	Male "Kh" 2		●	Aha!		●
51	D#2	D#3	Female "Kh" 2		●	Oh Yeah		●
52	E2	E3	Male "Ph" 2		●	Yayayayah		●
53	F2	F3	Female "Ph" 2		●	Put Your Hands Together		●
54	F#2	F#3	Male "Th" 2		●	C'mon Now		●
55	G2	G3	Female "Th" 2		●	Heeey		●
56	G#2	G#3	Male "Ha" 4		●	Everybody Now		●
57	A2	A3	Female "Ha" 2		●	Clap Your Hands, Everybody C'mon		●
58	A#2	A#3	Male "Ha" 5		●	With All Your Soul		●
59	B2	B3	Male "Ha" 6		●	Stand Up On Your Feet		●
60	C3	C4	Male "Bh" 3		●	Uhh Yeah		●
61	C#3	C#4	Female "Bh" 3		●	Aaoh		●
62	D3	D4	Male "Kh" 3		●	Come On!		●
63	D#3	D#4	Female "Kh" 3		●	Yeah!		●
64	E3	E4	Male "Ph" 3		●	Alright Now!		●
65	F3	F4	Female "Ph" 3		●	One		●
66	F#3	F#4	Male "Th" 3		●	Two		●
67	G3	G4	Female "Th" 3		●	Three		●
68	G#3	G#4	Male "Bh" 4		●	Four		●
69	A3	A4	Female "Bh" 4		●	One!		●
70	A#3	A#4	Male "Kh" 4		●	Two!		●
71	B3	B4	Female "Kh" 4		●	Three!		●
72	C4	C5	Male "Ph" 4		●	Four!		●
73	C#4	C#5	Female "Ph" 4		●	Five!		●
74	D4	D5	Male "Th" 4		●	Six!		●
75	D#4	D#5	Female "Th" 4		●	Seven!		●
76	E4	E5				Eight!		●
77	F4	F5				Clap!		●
78	F#4	F#5				Gospel Clap 1		●
79	G4	G5				Gospel Clap 2		●
80	G#4	G#5						
81	A4	A5						
82	A#4	A#5						
83	B4	B5						
84	C5	C6						
85	C#5	C#6						
86	D5	D6						
87	D#5	D#6						
88	E5	E6						
89	F5	F6						
90	F#5	F#6						
91	G5	G6						

 : Same as Standard Kit 1
 : No Sound

*1 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

*2 Key Off: Keys marked "●" stop sounding the instant they are released.

*3 Revolt: Keys marked "●" sound different each time the same key is played, so that the sound is more natural.

Song List / Liste der Song / Liste des morceaux / Lista de canciones

50 Popular

Song No	Genre	Title	Composer	Lyricist	Lyric Data
1	Pop	*1 Into The Unknown	Kristen Anderson-Lopez & Robert Lopez	Kristen Anderson-Lopez & Robert Lopez	○
2		*1 10,000 Hours	Dan Smyers, Jordan Reynolds, Shay Mooney, Justin Bieber, Jason Boyd & Jessie Jo Dillon	Dan Smyers, Jordan Reynolds, Shay Mooney, Justin Bieber, Jason Boyd & Jessie Jo Dillon	○
3		Lover	Taylor Swift	Taylor Swift	○
4		*1 Señorita	Camila Cabello, Charlotte Aitchison, Jack Patterson, Shawn Mendes, Magnus Hoiberg, Benjamin Levin, Ali Tamposi & Andrew Wotman	Camila Cabello, Charlotte Aitchison, Jack Patterson, Shawn Mendes, Magnus Hoiberg, Benjamin Levin, Ali Tamposi & Andrew Wotman	○
5		Shallow	Stefani Germanotta, Mark Ronson, Andrew Wyatt & Anthony Rossomando	Stefani Germanotta, Mark Ronson, Andrew Wyatt & Anthony Rossomando	○
6		Poker Face	Stefani Germanotta & RedOne	Stefani Germanotta & RedOne	○
7		Hallelujah	Leonard Cohen	Leonard Cohen	○
8		*1 Clocks	Guy Berryman, Jon Buckland, Will Champion & Chris Martin	Guy Berryman, Jon Buckland, Will Champion & Chris Martin	○
9		*1 My Heart Will Go On (Love Theme From 'Titanic')	James Horner	Will Jennings	○
10		Wonderwall	Noel Gallagher	Noel Gallagher	○
11		Back For Good	Gary Barlow	Gary Barlow	○
12		Fields Of Gold	Sting	Sting	○
13		I Will Always Love You	Dolly Parton	Dolly Parton	○
14		Eternal Flame	Billy Steinberg, Tom Kelly & Susanna Hoffs	Billy Steinberg, Tom Kelly & Susanna Hoffs	○
15		Final Countdown	Joey Tempest	Joey Tempest	○
16		Billie Jean	Michael Jackson	Michael Jackson	○
17		Every Breath You Take	Sting	Sting	○
18		Up Where We Belong	Buffy Sainte-Marie & Jack Nitzsche	Will Jennings	○
19		Just The Way You Are	Billy Joel	Billy Joel	○
20		Wonderful Tonight	Eric Clapton	Eric Clapton	○
21		Dancing Queen	Benny Andersson, Bjorn Ulvaeus & Stig Anderson	Benny Andersson, Bjorn Ulvaeus & Stig Anderson	○
22		Candle In The Wind	Elton John & Bernie Taupin	Elton John & Bernie Taupin	○
23		Hey Jude	John Lennon & Paul McCartney	John Lennon & Paul McCartney	○
24		Can't Take My Eyes Off Of You	Bob Crewe & Bob Gaudio	Bob Crewe & Bob Gaudio	○
25		You've Lost That Lovin' Feelin'	Barry Mann, Cynthia Weil & Phil Spector	Barry Mann, Cynthia Weil & Phil Spector	○
26		Unchained Melody	Alex North	Hy Zaret	○
27		La Bamba	Ritchie Valens	Ritchie Valens	○
28	Standard	Moon River	Henry Mancini	Johnny Mercer	○
29		What A Wonderful World	George David Weiss & Bob Thiele	George David Weiss & Bob Thiele	○
30		The Girl From Ipanema (Garôta De Ipanema)	Antonio Carlos Jobim	Norman Gimbel	○
31		Spanish Eyes	Bert Kaempfert	Charles Singleton & Eddie Snyder	○
32		Autumn Leaves	Joseph Kosma	Johnny Mercer	○
33		Let There Be Love	Lionel Rand	Ian Grant	○
34		All The Things You Are	Jerome Kern	Oscar Hammerstein II	○
35		In The Mood	Joe Garland	-	○
36	Folk	Amazing Grace	Traditional	Traditional	○
37		Greensleeves	Traditional	Traditional	○
38		Scarborough Fair	Traditional	-	○
39		Danny Boy	Traditional	Traditional	○
40	Whiskey In The Jar	Traditional	Traditional	○	
41	Holiday & Events	All I Want For Christmas Is You	Mariah Carey & Walter Afanasieff	Mariah Carey & Walter Afanasieff	○
42		White Christmas	Irving Berlin	Irving Berlin	○
43		Joy To The World	Traditional	Traditional	○
44		Happy Birthday To You	Traditional	Traditional	○
45		Auld Lang Syne	Traditional	Traditional	○
46	Children's Music	Old MacDonald Had A Farm	Traditional	Traditional	○
47		Mary Had A Little Lamb	Traditional	Traditional	○
48		Frere Jacques	Traditional	Traditional	○
49		Aura Lee	Traditional	Traditional	○
50		Yankee Doodle	Traditional	Traditional	○

Songs marked with "**1" can be selected from the instrument.

○=Yes

50 Classics

Category		Song Name	Composer
Arrangements	*1	Canon D dur	J. Pachelbel
		Air On the G Strings	J. S. Bach
	*1	Jesus, Joy of Man's Desiring	J. S. Bach
	*1	Twinkle, Twinkle, Little Star	Traditional
		Piano Sonate op.31-2 "Tempest" 3rd mov.	L. v. Beethoven
		Ode to Joy	L. v. Beethoven
		Wiegenlied op.98-2	F. P. Schubert
		Grande Valse Brillante	F. F. Chopin
		Polonaise op.53 "Héroïque"	F. F. Chopin
		La Campanella	F. Liszt
	*1	Salut d'amour op.12	E. Elgar
		From the New World	A. Dvořák
		Sicilienne	G. U. Fauré
		Clair de lune	C. A. Debussy
	Jupiter [The Planets]	G. Holst	
Duets		Menuett [Eine kleine Nachtmusik K.525]	W. A. Mozart
		Menuett G dur	L. v. Beethoven
		Marcia alla Turca	L. v. Beethoven
		Piano Concerto No.1 op.11 2nd mov.	F. F. Chopin
		The Nutcracker Medley	P. I. Tchaikovsky
Original Compositions		Prelude [Wohitemperierte Klavier I No.1]	J. S. Bach
		Menuett G dur BWV Anh.114	J. S. Bach
		Piano Sonate No.15 K.545 1st mov.	W. A. Mozart
		Turkish March	W. A. Mozart
		Piano Sonate op.13 "Pathétique" 2nd mov.	L. v. Beethoven
	*1	Für Elise	L. v. Beethoven
		Piano Sonate op.27-2 "Mondschein" 1st mov.	L. v. Beethoven
		Impromptu op.90-2	F. P. Schubert
		Frühlingslied op.62-6	J. L. F. Mendelssohn
		Fantaisie-Impromptu	F. F. Chopin
		Etude op.10-3 "Chanson de l'adieu"	F. F. Chopin
		Etude op.10-12 "Revolutionary"	F. F. Chopin
		Valse op.64-1 "Petit chien"	F. F. Chopin
		Nocturne op.9-2	F. F. Chopin
		Nocturne KK4a-16/BI 49 [Posth.]	F. F. Chopin
		Träumerei	R. Schumann
		Barcarolle	P. I. Tchaikovsky
		La prière d'une Vierge	T. Badarzewska
		Liebesträume No.3	F. Liszt
		Blumenlied	G. Lange
		Humoresque	A. Dvořák
		Arietta	E. H. Grieg
		Tango [España]	I. Albéniz
		The Entertainer	S. Joplin
		Maple Leaf Rag	S. Joplin
		La Fille aux Cheveux de Lin	C. A. Debussy
		Arabesque No.1	C. A. Debussy
	Cakewalk	C. A. Debussy	
	Je te veux	E. Satie	
	Gymnopédies No.1	E. Satie	

Songs marked with "*" can be selected from the instrument.

Lesson

Album Title	Song Title
Vorschule im Klavierspiel Op.101	Beyer 1 [3hands]
	Beyer 2 [3hands]
	Beyer 3 [4hands]
	Beyer 4 [4hands]
	Beyer 5 [4hands]
	Beyer 6 [4hands]
	Beyer 7 [4hands]
	Beyer 8 [4hands]
	Beyer 9 [4hands]
	Beyer 10 [4hands]
	Beyer 11 [4hands]
	Beyer 12
	Beyer 13
	Beyer 14
	Beyer 15
	Beyer 16
	Beyer 17
	Beyer 18
	Beyer 19
	Beyer 20
	Beyer 21
	Beyer 22
	Beyer 23
	Beyer 24
	Beyer 25
	Beyer 26
	Beyer 27
	Beyer 28
	Beyer 29
	Beyer 30
	Beyer 31
	Beyer 32 [4hands]
	Beyer 33 [4hands]
	Beyer 34 [4hands]
	Beyer 35
	Beyer 36
	Beyer 37
	Beyer 38
	Beyer 39
	Beyer 40
	Beyer 41 [4hands]
	Beyer 42 [4hands]
	Beyer 43 [4hands]
	Beyer 44 [4hands]
	Beyer 45
	Beyer 46
	Beyer 47
	Beyer 48
	Beyer 49
	Beyer 50
	Beyer 51
	Beyer 52
	Beyer 53
	Beyer 54
	Beyer 55
	Beyer 56
	Beyer 57
	Beyer 58
	Beyer 59
	Beyer 60
	Beyer 61
	Beyer 62
	Beyer 63 [4hands]
	Beyer 64 [4hands]
	Beyer 65
	Beyer 66

Album Title	Song Title	
Vorschule im Klavierspiel Op.101	Beyer 67	
	Beyer 68	
	Beyer 69	
	Beyer 70	
	Beyer 71	
	Beyer 72	
	Beyer 73	
	Beyer 74	
	Beyer 75	
	Beyer 76	
	Beyer 77	
	Beyer 78	
	Beyer 79	
	Beyer 80	
	Beyer 81	
	Beyer 82	
	Beyer 83	
	Beyer 84	
	Beyer 85	
	Beyer 86 [4hands]	
	Beyer 87 [4hands]	
	Beyer 88	
	Beyer 89	
	Beyer 90	
	Beyer 91	
	Beyer 92	
	Beyer 93	
	Beyer 94	
	Beyer 95	
	Beyer 96	
	Beyer 97	
	Beyer 98	
	Beyer 99	
	Beyer 100	
	Beyer 101	
	Beyer 102	
	Beyer 103	
	Beyer 104	
	Beyer 105	
	Beyer 106	
	25 Etudes faciles et progressives Op.100	1 La candeur
		2 Arabesque
		3 Pastorale
		4 Petite réunion
		5 Innocence
		6 Progrès
		7 Courant limpide
		8 La gracieuse
		9 La chasse
		10 Tendre fleur
		11 La bergeronnette
		12 Adieu
		13 Consolation
		14 La styrienne
		15 Ballade
		16 Douce plainte
		17 Babillarde
		18 Inquiétude
		19 Ave Maria
		20 Tarentelle
		21 Harmonie des anges
		22 Barcarolle
		23 Retour
		24 L'hirondelle
		25 La chevaleresque

Album Title	Song Title
100 Übungsstücke Op.139	Czerny100 1
	Czerny100 2
	Czerny100 3
	Czerny100 4
	Czerny100 5
	Czerny100 6
	Czerny100 7
	Czerny100 8
	Czerny100 9
	Czerny100 10
	Czerny100 11
	Czerny100 12
	Czerny100 13
	Czerny100 14
	Czerny100 15
	Czerny100 16
	Czerny100 17
	Czerny100 18
	Czerny100 19
	Czerny100 20
	Czerny100 21
	Czerny100 22
	Czerny100 23
	Czerny100 24
	Czerny100 25
	Czerny100 26
	Czerny100 27
	Czerny100 28
	Czerny100 29
	Czerny100 30
	Czerny100 31
	Czerny100 32
	Czerny100 33
	Czerny100 34
	Czerny100 35
	Czerny100 36
	Czerny100 37
	Czerny100 38
	Czerny100 39
	Czerny100 40
	Czerny100 41
	Czerny100 42
	Czerny100 43
	Czerny100 44
	Czerny100 45
	Czerny100 46
	Czerny100 47
	Czerny100 48
	Czerny100 49
	Czerny100 50
	Czerny100 51
	Czerny100 52
	Czerny100 53
	Czerny100 54
	Czerny100 55
	Czerny100 56
	Czerny100 57
	Czerny100 58
	Czerny100 59
	Czerny100 60
	Czerny100 61
	Czerny100 62
	Czerny100 63
	Czerny100 64
	Czerny100 65
	Czerny100 66

Lesson

Album Title	Song Title
100 Übungsstücke Op.139	Czerny100 67
	Czerny100 68
	Czerny100 69
	Czerny100 70
	Czerny100 71
	Czerny100 72
	Czerny100 73
	Czerny100 74
	Czerny100 75
	Czerny100 76
	Czerny100 77
	Czerny100 78
	Czerny100 79
	Czerny100 80
	Czerny100 81
	Czerny100 82
	Czerny100 83
	Czerny100 84
	Czerny100 85
	Czerny100 86
	Czerny100 87
	Czerny100 88
	Czerny100 89
	Czerny100 90
	Czerny100 91
	Czerny100 92
	Czerny100 93
	Czerny100 94
	Czerny100 95
	Czerny100 96
	Czerny100 97
	Czerny100 98
	Czerny100 99
Czerny100 100	
30 Etudes de mécanisme Op.849	Czerny30 1
	Czerny30 2
	Czerny30 3
	Czerny30 4
	Czerny30 5
	Czerny30 6
	Czerny30 7
	Czerny30 8
	Czerny30 9
	Czerny30 10
	Czerny30 11
	Czerny30 12
	Czerny30 13
	Czerny30 14
	Czerny30 15
	Czerny30 16
	Czerny30 17
	Czerny30 18
	Czerny30 19
	Czerny30 20
	Czerny30 21
	Czerny30 22
	Czerny30 23
	Czerny30 24
	Czerny30 25
	Czerny30 26
	Czerny30 27
	Czerny30 28
	Czerny30 29
	Czerny30 30

Album Title	Song Title
The Virtuoso Pianist	Hanon 1
	Hanon 2
	Hanon 3
	Hanon 4
	Hanon 5
	Hanon 6
	Hanon 7
	Hanon 8
	Hanon 9
	Hanon 10
	Hanon 11
	Hanon 12
	Hanon 13
	Hanon 14
	Hanon 15
	Hanon 16
	Hanon 17
	Hanon 18
	Hanon 19
	Hanon 20
	Hanon 1 Var.1
	Hanon 1 Var.2
Hanon 1 Var.3	
Hanon 1 Var.4	
Hanon 1 Var.5	
Hanon 1 Var.6	
Hanon 1 Var.7	
Hanon 1 Var.8	
Hanon 1 Var.9	
Hanon 1 Var.10	
Hanon 1 Var.11	
Hanon 1 Var.12	
Hanon 1 Var.13	
Hanon 1 Var.14	
Hanon 1 Var.15	
Hanon 1 Var.16	
Hanon 1 Var.17	
Hanon 1 Var.18	
Hanon 1 Var.19	
Hanon 1 Var.20	
Hanon 1 Var.21	
Hanon 1 Var.22	

Style List / Liste der Styles / Liste des styles / Lista de estilos

CSP-295GP, CSP-295

Category	Sub Category	Style Name	
Pop&Rock	Pop	Sky Pop	
		Boy Band Pop	
		Reggaeton 1	
		Reggaeton 2	
		90s Guitar Pop	
		Brit Pop Swing	
		90s Pop Shuffle	
		Chart Piano Shuffle	
		Crazy Pop	
		Funk Pop Rock	
		Wonder 8Beat	
		Up-tempo 8Beat	
		80s Boy Band	
		80s Guitar Pop	
		80s 8Beat	
		Pop Rock Shuffle	
		Contemp Gtr Pop	
		West Coast Beat	
		*1 Standard 8Beat	
		Cool 8Beat	
		00s Boy Band	
		80s American Pop	
		Live 8Beat	
		Pop Evergreen	
		Classic 8Beat	
		Easy Pop	
		Unplugged Pop	
		Piano 8Beat	
		Rock	80s Classic Rock
			80s Power Rock
			80s Edgy Rock
			80s Rock Diva
			6-8 Rock
			80s Rock Beat
			80s Synth Rock
			Stadium Rock
			90s Scots Soft Rock
			Brit Rock Pop
			Standard Rock
	Acoustic Rock		
	Slow Rock		
	70s Pop &Rock		Swedish Monster Pop
			Swedish 8Beat Pop
			70s Pop Duo 1
			70s Pop Duo 2
			70s Glam Piano
			70s Euro Pop
			70s Kids Pop
		70s Euro River Pop	
		Swedish Pop Shuffle	
		70s Piano Rock	
		Glam Piano Rock	
		70s Hard Rock	
		70s Shuffle Rock	
		70s Straight Rock	
		Vintage Guitar Pop	
		70s Swing Piano	
		70s Brit Skiffle	
		70s Baroque Pop	
		70s Swing Pop	
		70s Cool Ballad	
		70s Piano Hit	
		70s US Pop Duo	
		60s Pop &Rock	60s Pop Ballad
	60s Soft Brit Pop		
	60s Blue Eyed Soul		
	60s Shadowed Pop		
60s Vintage Rumba			
*1 60s Big Hit			
60s 8Beat			
60s Rising Pop			
60s Underground			
60s Piano Pop			
60s Chart Swing			
60s Vintage Rock			
60s Rock & Roll			
60s Pop Rock			

Category	Sub Category	Style Name	
Pop&Rock	60s Pop&Rock	Captain Sax 6-8	
		Bubblegum Pop	
		Surf Rock	
		Beach Rock	
		60s Wheels	
		60s Vintage Pop	
		50s Rock&Roll	Rock & Roll
			50s Rock & Roll
			Rock & Roll Jive
			Rock & Roll Shuffle
			Oldies Rock & Roll
			Skiffle
			Piano Boogie
			Vintage R&R
			Twist
	Piano R&R		
	Piano Boogie Woogie		
	Pop &Rock Ballad		Songwriter Ballad
			Unplugged Ballad
			6-8 Guitar Ballad
			12-8 Pop Ballad
		Orch Rock Ballad 1	
		Orch Rock Ballad 2	
		90s Rock Ballad	
		Soulful Ballad	
		Irish Pop Ballad	
		Smooth Pop Ballad	
		80s Analog Ballad	
		80s Diva Ballad	
		16Beat Ballad	
		Piano Ballad	
		90s 8Beat Ballad	
	Boy Band Ballad		
	Modern Pop Ballad		
	80s Piano Ballad		
	70s 8Beat Ballad		
	70s Piano Pop Bld		
	70s Chart Ballad		
	Vocal Pop Ballad		
	Standard Piano Bld		
	Easy 8Beat		
	6-8 Soul Ballad		
	*1 6-8 Ballad Rock		
	90s Piano Ballad		
	90s Smooth Ballad		
	80s Smooth Ballad		
	*1 Smooth Ballad		
	Mod 6-8 Piano Bld		
	Light Ballad		
	Epic Ballad		
	MOR 16Beat		
	Easy Acoustic Ballad		
	Pop Waltz		
	8Beat Piano Ballad		
	Worship	Christian Rock	
		Gospel Worship	
		Worship Slow	
		Worship Medium	
		Worship Fast	
		Worship 6-8	
		Worship Irish Rock	
		Worship Power Bld	
		Soul	Mr. Soul
			Soul Shuffle
	70s Soul Ballad		
	Soul Supreme		
	Detroit Pop		
Motor City			
Sexy Soul			
Lovely Shuffle			
70s US Funk			
Frankly Soul			
Kool Shuffle			
70s Chart Soul			
Live Soul Band			
*1 Funky Shuffle			
70s Cool Shuffle			

Category	Sub Category	Style Name	
Pop&Rock	Disco	Funk Disco	
		70s Disco Funk	
		70s Disco 1	
		70s Disco 2	
		Philly Disco	
		Disco Chocolate	
		80s Disco Beat	
		90s Disco	
		Saturday Night	
		Pop Legend	
		Synth Pop	
		Dance	Party Anthem
			Slow'n' Swingin'
			Chart EDM
			Street Beatbox
			Big Room
			US Club Dance
			Club Dance 1
			Club Dance 2
			Retro Dance
	Club House		
	Dream Dance		
	Global DJs		
	Electronica		
	Funky House		
	Modern R&B		Cool R&B
		Modern Hip Hop	
		R&B Soul Ballad	
		Soul Ballad	
		Hip Hop	
	Chill Out	Chillout 1	
		Chillout 2	
		Chill Performer	
		Cloudy Bay	
		Night Walk	
		Play 4 Sofa	
		Angel Sun	
		Chillout Cafe	
	Trance	6-8 Classic Synth	
		Euro Trance	
		Trance Pop	
	Country &Blues	Modern Country	Country Star
			Bluegrass Rock
			Country Songwriter
			Nashville Pop
			Nashville Rock
			Californian Country
			Country 8Beat 1
			Country 8Beat 2
			Country 8Beat 3
			Country Pop
			Easy Country Pop
			70s Easy Pop
			Country Hits
			Country Strummin'
			Country Rock
		Country Blues	
		Modern Pickin'	
		Country Straits	
		Top Chart Country	
		Folk Song Duo	
		Trad Country	60s Country Pop
			Hoedown
			Bluegrass
	Country Shuffle		
	Country Swing		
	70s Country Swing		
Country Waltz			
Country Singalong			
Pickin' Swing			
Country Ballad	Country 2-4		
	Standard Swing		
	Country Swing Ballad		
	Slow Country Pop		
	Country Ballad 1		
	Country Ballad 2		
	Country Pop Ballad		

Styles marked with "**1" can be selected from the instrument.

CSP-295GP, CSP-295

Category	Sub Category	Style Name	
Country & Blues	Blues	Texas Blues	
		King Blues	
		The Blues	
		Slow Blues	
		Blues Rock	
		Blues Shuffle	
		R&B Shuffle	
		Blueberry Blues	
		Piano Blues 1	
		Piano Blues 2	
		Gospel	Amazing Gospel
			Hollywood Gospel
	Gospel Swing		
	Gospel Ballad		
	Southern Gospel		
	Gospel Brothers		
	Gospel Sisters		
	Standards & Jazz	Jazz Combo	Acoustic Jazz
			Cool Piano Jazz
Instrumental Jazz			
Jazz Guitar Club			
Cool Jazz Club			
Slow Jazz Ballad			
Fast Jazz			
Trad Piano Jazz			
Trad Piano Ballad			
Manhattan Swing			
French Jazz			
*1 Swing Medium			
Piano Swing 1			
Piano Swing 2			
Jazz Ballad			
2Beat Swing			
Big Band			Big Band Jazz
			Classic Big Band
			Modern Big Band
			Big Band Blues
			Orch Big Band 1
			Orch Big Band 2
			Big Band Fast 1
			Big Band Fast 2
		Big Band Ballad	
		Big Band Medium	
		Swingin' Big Band	
		Big Band Shuffle	
		40s Swing Ballad	
		Jump Jive	
		Afro Cuban	
		Orchestra Swing	Easy Swing 1
			Easy Swing 2
			Dreamy Ballad
Cool Jazz Ballad			
Orchestral Swing 1			
Orchestral Swing 2			
Easy Listening			
Midnight Swing			
Jazz Waltz		*1 Cool Jazz Waltz	
		Slow Jazz Waltz	
		Jazz Waltz Fast	
		*1 Easy Waltz	
		MOR Waltz	
		Five Four	
Dixie & Trad Jazz		Jazz Waltz	
		Ragtime	
		Dixieland	
		Charleston	
		Saloon Piano	
		Piano Rag 1	
		Piano Rag 2	
		Stride 1	
Stride 2			
Fusion		70s Scat Legend	
		Jazz Fusion	
		Fusion Shuffle	
		Jazz Funk	

Category	Sub Category	Style Name	
Entertainment	Movie&Show	Boxing Legend	
		Gunslinger	
		Wild West	
		Secret Service	
		Sci-Fi March	
		Movie Horns	
		70s US Teens Musical	
		00s US Musical Swing	
		On Broadway	
		*1 Mod Broadway Ballad	
		Ethereal Movie	
		Movie Classic	
		Movie Soundtrack	
		Choir Soundtrack	
		Animation Fantasy	
		Cartoon Ballad	
		Icy Ballad	
		Movie Panther	
		70s TV Theme	
		Movie Disco	
		Movie Ballad	
		80s Movie Ballad	
		Broadway Ballad	
		Guitar Serenade	
		Movie Swing 1	
		Movie Swing 2	
		It's Showtime	
		Tap Dance Swing	
		Musical	
		Easy Listening	Party A Gogo
			Easy Ballad
			Orchestral 6-8
			Orchestral 12-8
	Tijuana		
	6-8 Slow Rock		
	Romantic Ballad		
	Classic Piano Bld		
	Singalong Dance Band		
	Singalong Piano		
	Pub Piano		
	70s French Hit		
	Romantic Waltz		
	Ballroom		Final Waltz
		Vocal Waltz	
		English Waltz	
		Slow Waltz	
		Vocal Foxtrot	
		Quickstep	
		Slow Foxtrot	
		Cha-Cha	
		Samba	
		Pasodoble	
	Organ	Beguine	
		Tango	
		Jive	
		Foxtrot	
		Swing Fox	
		Standard Waltz	
		Standard Rumba	
		Piano Rumba	
		Piano Beguine	
		Piano Cha-Cha	
		Euro Pop Organ	
		Organ Swing	
	Organ Bossa		
	Organ Samba		
	Organ Cha-Cha		
Organ Rumba			
Organ Quickstep			
Elec Organ Ballad			
Jazz Organ Combo			
Jazz Organ Groove			
60s Organ Ballad			
Theatre Foxtrot			
Theatre Quickstep			
Theatre March			
Organ Hymn			

Category	Sub Category	Style Name		
Entertainment	Holiday	Xmas Showcase		
		Christmas Ballad		
		Christmas Swing 1		
		Christmas Swing 2		
		Christmas Waltz		
		Xmas Schlager		
		Schlager	Disco Fox 2017	
			Dream Schlager	
			Fantasy Fox	
			Oktober Rock Hit	
			Schlager Fox	
			Young Fox	
			Young Ballad	
			Hello Shuffle	
	Modern Schlager			
	Schlager Rock			
	Schlager Pop			
	Schlager Beat			
	Schlager Alp			
	Schlager Rumba			
	Schlager 6-8			
	Schlager Fever			
	Party Polka			
	Schlager Polka			
	Alpen Ballad 1			
	Alpen Ballad 2			
	Schlager Palace			
	Polka Pop			
	Schlager Shuffle			
	Schlager Samba			
	Disco Fox			
	Disco Fox Rock			
	German Rock			
	Schlager Waltz			
	Mallorca Party			
	Mallorca Disco			
	Party Arena			
	Soft Schlager			
	Apres Ski Hit			
	Synth Pop Duo			
	8Beat Adria			
	Scand Bugg			
	Scand Shuffle			
	Scand Slow Rock			
	Scand Country			
	Latin&World		Brazil	*1 Brazilian Bossa
				Cool Bossa
				Bossa Slow
		Bossa Fast		
		Bossa Brazil		
		Bossa Nova		
		Lounge Bossa		
		Jazz Samba		
		Samba Fast		
		Piano Samba		
		Piano Bossa		
		Cuba		Rumba Bolero
				Guitar Rumba
				Guajira
				Guaguanco
				Salsa
				Cuban Son
				Mexico
			Mexican Dance	
			Bolero Lento	
			Caribbean	Live Merengue
		Pop Cumbia		
Bachata				
Sheriff Reggae				
Happy Reggae				
Rumba Island				
European		Flamenco		
		Tango Flamencos		
		Pop Cha-Cha		
		Sirtaki		
		Tarantella		
		Spanish Paso		

Styles marked with "**1" can be selected from the instrument.

CSP-295GP, CSP-295

Category	Sub Category	Style Name	
Latin&World	European	Italian Mazurka	
		Latin Soul	
	Latin Pop	Rock Cha-Cha	
		Latin Party Pop	
		Pop Latin	
		Pop Latin Ballad	
		Pop Bossa	
		Celtic	Celtic Dance 3-4
	Celtic	Celtic Dance	
		Irish Dance	
		Irish Hymn	
		Scottish Jig	
		Scottish Reel	
		Scottish Polka	
		Scottish Strathspey	
		World	Hawaiian
		World	Turkish Euro
			J-Pop Hit 1
	J-Pop Hit 2		
	Classic	Viennese Waltz	
		Orch Pop Classics	
		Moonlight 6-8	
		Proms March	
		Orchestral March	
		Orchestral Polka	
		Orchestral Bolero	
		String Adagio	
		Baroque Air	
		Green Fantasia	
		Classical Menuet	
		Classical Serenade	
		Romantic Ballet	
		Choral Symphony	
		Ethereal Voices	
		Nocturne	
		Traditional 1	
		Traditional 2	
		Traditional 3	
		Arpeggio 1	
		Arpeggio 2	
		Arpeggio 3	
		Trad Waltz	Oberkrainer Waltz 1
			Oberkrainer Waltz 2
			French Musette
			French Waltz
			Scottish Waltz
			Italian Waltz
			Scand Waltz
			Bohemian Waltz
			German Waltz
			Waltz
			Piano Slow Waltz
	March&Polka		US March
			6-8 March
		Brass Band	
		Zither Polka	
		German March 1	
		German March 2	
		Oberkrainer Polka 1	
		Oberkrainer Polka 2	
		Alpen Land	
		Piano March 1	
		Piano March 2	
		6-8 Piano March	
		4 Stroke	

CSP-255, CSP-275

Category	Sub Category	Style Name		
Pop&Rock	Pop	Sky Pop		
		Boy Band Pop		
		Reggaeton 1		
		Reggaeton 2		
		90s Guitar Pop		
		Brit Pop Swing		
		90s Pop Shuffle		
		Chart Piano Shuffle		
		Crazy Pop		
		Funk Pop Rock		
		Wonder 8Beat		
		Up-tempo 8Beat		
		80s Boy Band		
		80s Guitar Pop		
		80s 8Beat		
		Contemp Gtr Pop		
		West Coast Beat		
		*1 Standard 8Beat		
		Cool 8Beat		
		00s Boy Band		
		80s American Pop		
		Live 8Beat		
		Pop Evergreen		
		Classic 8Beat		
		Easy Pop		
		Unplugged Pop		
		Piano 8Beat		
		Rock	80s Classic Rock	
			80s Power Rock	
			80s Edgy Rock	
			80s Rock Diva	
			6-8 Rock	
			80s Rock Beat	
			80s Synth Rock	
			Stadium Rock	
			Brit Rock Pop	
			Standard Rock	
			Slow Rock	
			70s Pop&Rock	Swedish Monster Pop
				Swedish 8Beat Pop
		70s Pop Duo 1		
		70s Pop Duo 2		
		70s Glam Piano		
		70s Euro Pop		
		70s Kids Pop		
		70s Euro River Pop		
		Swedish Pop Shuffle		
	70s Piano Rock			
	60s Pop&Rock	Glam Piano Rock		
		70s Hard Rock		
		70s Shuffle Rock		
		70s Straight Rock		
		Vintage Guitar Pop		
		70s Swing Piano		
		70s Piano Hit		
		70s US Pop Duo		
		*1 60s Pop Ballad		
		60s Soft Brit Pop		
	60s Blue Eyed Soul			
	60s Shadowed Pop			
	60s Vintage Rumba			
	*1 60s Big Hit			
	60s 8Beat			
	60s Rising Pop			
	60s Underground			
	60s Piano Pop			
	60s Chart Swing			
	60s Vintage Rock			
	60s Rock & Roll			
	60s Pop Rock			
	Captain Sax 6-8			
	Bubblegum Pop			
	60s Vintage Pop			
	50s Rock&Roll	Rock & Roll		
		50s Rock & Roll		
		Rock & Roll Jive		
		Rock & Roll Shuffle		

Category	Sub Category	Style Name	
Pop&Rock	50s Rock&Roll	Oldies Rock & Roll	
		Skiffle	
		Piano Boogie	
		Vintage R&R	
		Twist	
		Piano R&R	
		Piano Boogie Woogie	
		Pop&Rock Ballad	Songwriter Ballad
			Unplugged Ballad
			6-8 Guitar Ballad
			12-8 Pop Ballad
			Orch Rock Ballad 1
			Orch Rock Ballad 2
			Smooth Pop Ballad
			80s Analog Ballad
			80s Diva Ballad
			16Beat Ballad
			Piano Ballad
			90s 8Beat Ballad
			Boy Band Ballad
	Modern Pop Ballad		
	80s Piano Ballad		
	70s 8Beat Ballad		
	70s Piano Pop Bld		
	70s Chart Ballad		
	Standard Piano Bld		
	Easy 8Beat		
	6-8 Soul Ballad		
	*1 6-8 Ballad Rock		
	90s Piano Ballad		
	90s Smooth Ballad		
	80s Smooth Ballad		
	*1 Smooth Ballad		
	Mod 6-8 Piano Bld		
	Light Ballad		
	Epic Ballad		
	MOR 16Beat		
	Easy Acoustic Ballad		
	Pop Waltz		
	8Beat Piano Ballad		
	Worship	Christian Rock	
		Gospel Worship	
		Worship Slow	
		Worship Medium	
		Worship Fast	
		Worship 6-8	
		Worship Irish Rock	
		Worship Power Bld	
		Soul	Mr. Soul
			Soul Shuffle
	70s Soul Ballad		
	Soul Supreme		
	Detroit Pop		
	Motor City		
	Sexy Soul		
	Lovely Shuffle		
	70s US Funk		
	Frankly Soul		
	Kool Shuffle		
	70s Chart Soul		
	Live Soul Band		
	*1 Funky Shuffle		
	70s Cool Shuffle		
	Disco	Funk Disco	
		70s Disco Funk	
		70s Disco 1	
		70s Disco 2	
		Philly Disco	
		Disco Chocolate	
		80s Disco Beat	
		90s Disco	
		Saturday Night	
		Pop Legend	
	Synth Pop		
	Dance	Party Anthem	
		Slow'n' Swingin'	
		Chart EDM	

Styles marked with "**1" can be selected from the instrument.

CSP-255, CSP-275

Category	Sub Category	Style Name	
Pop&Rock	Dance	Street Beatbox	
		Big Room	
		US Club Dance	
		Club Dance 1	
		Club Dance 2	
		Retro Dance	
		Club House	
		Dream Dance	
		Global DJs	
		Electronica	
		Funky House	
		Modern R&B	Cool R&B
			Modern Hip Hop
			R&B Soul Ballad
	Soul Ballad		
	Hip Hop		
	Chill Out	Chillout 1	
		Chillout 2	
		Chill Performer	
		Cloudy Bay	
		Night Walk	
		Play 4 Sofa	
		Angel Sun	
		Chillout Cafe	
	Trance	6-8 Classic Synth	
		Euro Trance	
		Trance Pop	
	Country & Blues	Modern Country	Country Star
			Bluegrass Rock
			Country Songwriter
			Nashville Pop
			Nashville Rock
			Country 8Beat 1
			Country 8Beat 2
			Country 8Beat 3
			Country Pop
			70s Easy Pop
			Country Hits
Country Strummin'			
Country Rock			
Country Blues			
Modern Pickin'			
Country Straits			
Top Chart Country			
Folk Song Duo			
Trad Country		60s Country Pop	
		Hoedown	
		Bluegrass	
		Country Shuffle	
		Country Swing	
		70s Country Swing	
		Country Waltz	
		Country Singalong	
		Pickin' Swing	
		Country 2-4	
Standard Swing			
Country Ballad		Country Swing Ballad	
		Country Ballad 1	
		Country Ballad 2	
Blues	Country Pop Ballad		
	Texas Blues		
	King Blues		
	The Blues		
	Slow Blues		
	Blues Rock		
	Blues Shuffle		
	R&B Shuffle		
	Blueberry Blues		
	Piano Blues 1		
	Piano Blues 2		
	Gospel	Amazing Gospel	
		Hollywood Gospel	
Gospel Ballad			
Southern Gospel			
Gospel Brothers			
Gospel Sisters			

Category	Sub Category	Style Name	
Standards & Jazz	Jazz Combo	Acoustic Jazz	
		Cool Piano Jazz	
		Instrumental Jazz	
		Jazz Guitar Club	
		Cool Jazz Club	
		Slow Jazz Ballad	
		Fast Jazz	
		Trad Piano Jazz	
		Trad Piano Ballad	
		Manhattan Swing	
		French Jazz	
		*1 Swing Medium	
		Piano Swing 1	
		Piano Swing 2	
		Jazz Ballad	
		2Beat Swing	
		Big Band	Big Band Jazz
			Classic Big Band
			Modern Big Band
			Big Band Blues
			Orch Big Band 1
			Orch Big Band 2
			Big Band Fast 1
			Big Band Fast 2
			Big Band Ballad
			Big Band Medium
	Swingin' Big Band		
	Big Band Shuffle		
	40s Swing Ballad		
	Jump Jive		
	Orchestra Swing	Afro Cuban	
		Easy Swing 1	
		Easy Swing 2	
		Dreamy Ballad	
		Cool Jazz Ballad	
		Orchestral Swing 1	
		Orchestral Swing 2	
		Easy Listening	
		Midnight Swing	
		Jazz Waltz	
	Jazz Waltz	*1 Cool Jazz Waltz	
		Slow Jazz Waltz	
		Jazz Waltz Fast	
	Dixie & Trad Jazz	*1 Easy Waltz	
		MOR Waltz	
		Five Four	
		Jazz Waltz	
		Ragtime	
		Dixieland	
		Charleston	
Saloon Piano			
Piano Rag 1			
Piano Rag 2			
Fusion	Stride 1		
	Stride 2		
	70s Scat Legend		
	Jazz Fusion		
Entertainment	Movie&Show	Fusion Shuffle	
		Jazz Funk	
		Boxing Legend	
		Gunslinger	
		Wild West	
		Secret Service	
		Sci-Fi March	
		Movie Horns	
	70s US Teens Musical		
	00s US Musical Swing		
	On Broadway		
	*1 Mod Broadway Ballad		
	Ethereal Movie		
	Movie Classic		
	Movie Soundtrack		
	Choir Soundtrack		
Animation Fantasy			
Cartoon Ballad			
Icy Ballad			
Movie Panther			
70s TV Theme			

Category	Sub Category	Style Name	
Entertainment	Movie&Show	Movie Disco	
		Movie Ballad	
		80s Movie Ballad	
		Broadway Ballad	
		Guitar Serenade	
		Movie Swing 1	
		Movie Swing 2	
		It's Showtime	
		Tap Dance Swing	
		Musical	
		Easy Listening	Party A Gogo
			Easy Ballad
			Orchestral 6-8
			Orchestral 12-8
	Tijuana		
	6-8 Slow Rock		
	Romantic Ballad		
	Classic Piano Bld		
	Singalong Dance Band		
	Singalong Piano		
	Ballroom	Pub Piano	
		70s French Hit	
		Final Waltz	
		Vocal Waltz	
		English Waltz	
		Slow Waltz	
		Vocal Foxtrot	
		Quickstep	
		Slow Foxtrot	
		Cha-Cha	
		Samba	
		Pasodoble	
		Beguine	
		Tango	
		Jive	
		Foxtrot	
	Swing Fox		
	Standard Waltz		
	Standard Rumba		
	Piano Rumba		
	Piano Beguine		
	Piano Cha-Cha		
	Organ	Euro Pop Organ	
		Organ Swing	
		Organ Bossa	
		Organ Samba	
		Organ Cha-Cha	
		Organ Rumba	
		Organ Quickstep	
		Elec Organ Ballad	
Jazz Organ Combo			
Jazz Organ Groove			
60s Organ Ballad			
Theatre Quickstep			
Holiday	Xmas Showcase		
	Christmas Ballad		
	Christmas Swing 1		
	Christmas Swing 2		
	Christmas Waltz		
	Xmas Schlager		
Schlager	Disco Fox 2017		
	Dream Schlager		
	Fantasy Fox		
	Oktober Rock Hit		
	Schlager Fox		
	Schlager Pop		
	Schlager Beat		
	Schlager Alp		
	Schlager Rumba		
	Schlager 6-8		
	Schlager Fever		
	Party Polka		
	Schlager Polka		
	Alpen Ballad 1		
Alpen Ballad 2			
Schlager Palace			
Polka Pop			

Styles marked with "**1" can be selected from the instrument.

CSP-255, CSP-275


Category	Sub Category	Style Name		
Entertainment	Schlager	Schlager Shuffle		
		Schlager Samba		
		Disco Fox		
		Disco Fox Rock		
		German Rock		
		Schlager Waltz		
		Mallorca Party		
		Party Arena		
		Soft Schlager		
		Apres Ski Hit		
		Synth Pop Duo		
		8Beat Adria		
		Scand Bugg		
		Scand Shuffle		
		Scand Slow Rock		
		Scand Country		
		Latin&World	Brazil	*1 Brazilian Bossa
				Cool Bossa
				Bossa Slow
				Bossa Fast
Bossa Brazil				
Bossa Nova				
Lounge Bossa				
Jazz Samba				
Samba Fast				
Piano Samba				
Piano Bossa				
Cuba	Rumba Bolero			
	Guitar Rumba			
	Guajira			
	Guaguanco			
	Salsa			
Mexico	Mariachi Waltz			
	Mexican Dance			
	Bolero Lento			
Caribbean	Live Merengue			
	Pop Cumbia			
	Bachata			
	Sheriff Reggae			
	Happy Reggae			
	Rumba Island			
European	Flamenco			
	Tango Flamencos			
	Pop Cha-Cha			
	Sirtaki			
	Tarantella			
	Spanish Paso			
Latin Pop	Italian Mazurka			
	Latin Soul			
	Rock Cha-Cha			
	Latin Party Pop			
	Pop Latin			
Celtic	Pop Latin Ballad			
	Pop Bossa			
	Celtic Dance 3-4			
	Celtic Dance			
	Irish Dance			
	Irish Hymn			
	Scottish Jig			
	Scottish Reel			
Scottish Polka				
Scottish Strathspey				
World	Hawaiian			
	Turkish Euro			
	J-Pop Hit 1			
	J-Pop Hit 2			
Classic	Viennese Waltz			
	Orch Pop Classics			
	Moonlight 6-8			
	Proms March			
	Orchestral March			
	Orchestral Polka			
	Orchestral Bolero			
	String Adagio			
	Baroque Air			
	Green Fantasia			

Styles marked with "**1" can be selected from the instrument.

Category	Sub Category	Style Name	
Latin&World	Classic	Classical Menuet	
		Classical Serenade	
		Romantic Ballet	
		Choral Symphony	
		Ethereal Voices	
		Nocturne	
		Traditional 1	
		Traditional 2	
		Traditional 3	
		Arpeggio 1	
		Arpeggio 2	
		Arpeggio 3	
		Trad Waltz	Oberkrainer Waltz 1
			Oberkrainer Waltz 2
			French Musette
	French Waltz		
	Scottish Waltz		
	Italian Waltz		
	Scand Waltz		
	Bohemian Waltz		
	German Waltz		
	Waltz		
	Piano Slow Waltz		
	March&Polka		US March
			6-8 March
			Brass Band
			Zither Polka
		German March 1	
		German March 2	
		Oberkrainer Polka 1	
Oberkrainer Polka 2			
Alpen Land			
Piano March 1			
Piano March 2			
6-8 Piano March			
4 Stroke			

Chord Types for Style Playback / Akkordtypen für die Style-Wiedergabe / Types d'accords pour la reproduction de style / Tipos de acordes para reproducción de estilos

This section shows how to specify the indicated chords (in the key of C) when the chord detection area is set to "Lower."



Chord Name [Abbreviation]	Normal Voicing	Display for root "C"
1+8	1+8	C1+8
1+5	1+5	C1+5
Major [M]	1+3+5	C
Sixth [6]	1+(3)+5+6	C6
Major seventh [M7]	1+3+(5)+7	CM7
Major seventh flatted fifth [M7 b 5]	1+3+ b 5+7	CM7(b 5)
Major seventh add sharp eleventh [M7(# 11)]	1+(2)+3+ # 4+5+7	CM7(# 11)
Add ninth [(add9)]	1+2+3+5	Cadd9
Major seventh ninth [M7_9]	1+2+3+(5)+7	CM7(9)
Sixth ninth [6_9]	1+2+3+(5)+6	C6(9)
Flatted fifth [(b 5)]	1+3+ b 5	C b 5
Augmented [aug]	1+3+ # 5	Caug
Seventh augmented [7aug]	1+3+ # 5+ b 7	C7aug
Major seventh augmented [M7aug]	1+(3)+ # 5+7	CM7aug
Minor [m]	1+ b 3+5	Cm
Minor sixth [m6]	1+ b 3+5+6	Cm6
Minor seventh [m7]	1+ b 3+(5)+ b 7	Cm7
Minor seventh flatted fifth [m7 b 5]	1+ b 3+ b 5+ b 7	Cm7(b 5)
Minor add ninth [m(add9)]	1+2+ b 3+5	Cm add9
Minor seventh ninth [m7(9)]	1+2+ b 3+(5)+ b 7	Cm7(9)
Minor seventh eleventh [m7(11)]	1+(2)+ b 3+4+5+(b 7)	Cm7(11)
Minor major seventh flatted fifth [mM7 b 5]	1+ b 3+ b 5+7	CmM7(b 5)
Minor major seventh [mM7]	1+ b 3+(5)+7	CmM7
Minor major seventh ninth [mM7(9)]	1+2+ b 3+(5)+7	CmM7(9)
Diminished [dim]	1+ b 3+ b 5	Cdim
Diminished seventh [dim7]	1+ b 3+ b 5+6	Cdim7
Seventh [7]	1+3+(5)+ b 7	C7
Seventh suspended fourth [7sus4]	1+4+5+ b 7	C7sus4
Seventh ninth [7(9)]	1+2+3+(5)+ b 7	C7(9)
Seventh add sharp eleventh [7(# 11)]	1+(2)+3+ # 4+5+ b 7	C7(# 11)
Seventh add thirteenth [7(13)]	1+3+(5)+6+ b 7	C7(13)
Seventh flatted fifth [7 b 5]	1+3+ b 5+ b 7	C7(b 5)
Seventh flatted ninth [7(b 9)]	1+ b 2+3+(5)+ b 7	C7(b 9)
Seventh add flatted thirteenth [7(b 13)]	1+3+5+ b 6+ b 7	C7(b 13)
Seventh sharp ninth [7(# 9)]	1+ # 2+3+(5)+ b 7	C7(# 9)
Suspended fourth [sus4]	1+4+5	Csus4
One plus two plus five [sus2]	1+2+5	Csus2
cancel	1+ b 2+2	Cancel

* Notes in parentheses can be omitted.

Effect Type List / Liste der Effektypen / Liste des types d'effet / Lista de tipos de efecto

Reverb Block

Category	Type Name	Description	MSB	LSB	
Reverb	Real Large Hall +	Real reverb simulating the acoustics of a large sized hall with rich middle range.	1	35	
	Real Medium Hall +	Real reverb simulating the acoustics of a medium sized hall with rich middle range.	1	36	
	Real Small Hall +	Real reverb simulating the acoustics of a small sized hall with rich middle range.	1	37	
	Real Large Hall	Real reverb simulating the acoustics of a large sized hall.	1	32	
	Real Medium Hall	Real reverb simulating the acoustics of a medium sized hall.	1	33	
	Real Bright Hall	Real reverb simulating the acoustics of a bright sounding hall.	1	34	
	Basic Hall	Reverb simulating the acoustics of a hall. Standard setting.	1	21	
	Light Hall	Reverb simulating the acoustics of a hall. Light setting.	1	22	
	Ballad Hall	Reverb simulating the acoustics of a hall. For ballad type music.	1	19	
	Piano Hall	Reverb simulating the acoustics of a hall. For piano sound.	1	20	
	Hall 1	Reverb simulating the acoustics of a hall.	1	0	
	Hall 2		1	16	
	Hall 3		1	17	
	Hall 4		1	18	
	Hall 5		1	1	
	Vocal Hall 1	Reverb suitable for vocals.	1	27	
	Vocal Hall 2		1	28	
	Piano Recital Hall	Reverb simulating the acoustics of a medium sized recital hall. For piano sound.	1	24	
	Piano Concert Hall	Reverb simulating the acoustics of a large sized hall. For piano sound.	1	4	
	Piano Cathedral	Reverb simulating the acoustics of a cathedral. For piano sound.	1	5	
	Real Room +	Real reverb simulating the acoustics of a room with rich middle range.	2	34	
	Real Room	Real reverb simulating the acoustics of a room.	2	32	
	Real Power Room	Real reverb simulating the acoustics of a room with powerful room reflections.	2	33	
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20	
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21	
	Piano Chamber	Reverb simulating the acoustics of a chamber. For piano sound.	2	24	
	Stage 1	Reverb suitable for a solo instrument.	3	16	
	Piano Club	Reverb simulating the acoustics of a club. For piano sound.	3	24	
	Real Large Plate +	Real reverb simulating a large plate reverb unit with rich middle range.	4	35	
	Real Medium Plate +	Real reverb simulating a medium sized plate reverb unit with rich middle range.	4	36	
	Real Large Plate	Real reverb simulating a large plate reverb unit.	4	32	
	Real Medium Plate	Real reverb simulating a medium sized plate reverb unit.	4	33	
	Real Rattle Plate	Real reverb simulating a plate reverb unit with spring rattle.	4	34	
	Large Plate +	Reverb simulating a large plate reverb unit with rich middle range	4	18	
	Plate 1	Reverb simulating a plate reverb unit.	4	16	
	Piano Plate	Reverb simulating a plate reverb unit. For piano sound.	4	24	
	Legacy	Hall M	Reverb simulating the acoustics of a hall.	1	6
		Hall L		1	7
		Atmosphere Hall	A unique long reverb with atmosphere.	1	23
		Large Hall	Reverb simulating the acoustics of a hall.	1	2
Medium Hall			1	3	
Percussion Room		Reverb simulating the acoustics of a room. For percussion sounds.	2	22	
Room 1		Reverb simulating the acoustics of a room.	2	16	
Room 2			2	17	
Room 3			2	18	
Room 4			2	19	
Room 5			2	0	
Room 6			2	1	
Room 7			2	2	
Room S			2	5	
Room M			2	6	
Room L			2	7	
Warm Room		Reverb simulating the acoustics of a warm room.	2	3	
White Room		A unique short reverb with a bit of initial delay.	16	0	
Woody Room		Reverb simulating the acoustics of a wood-built room.	2	4	
Stage 2		Reverb suitable for a solo instrument.	3	17	
Stage 3			3	0	
Stage 4			3	1	
Plate 2		Reverb simulating a plate reverb unit.	4	17	
Plate 3			4	0	
GM Plate			4	7	
Rich Plate		Reverb simulating a rich plate reverb unit.	4	1	
Tunnel		Simulates a cylindrical space expanding to left and right.	17	0	
Canyon		A hypothetical acoustic space which extends without limit.	18	0	
Basement		A bit of initial delay followed by reverb with a unique resonance.	19	0	
---		No Effect	No effect.	0	0

Vocal Harmony Parameter List / Liste der Vokalharmonie-Parameter / Liste des paramètres liés à l'harmonie vocale / Lista de parámetros de armonía vocal

Vocal Harmony Type List

Type Name	MSB	LSB	Vocal Harmony	Vocal Effect	Description
DuetHarmony	12	49	On	Off	Standard setting for lead vocal plus 1 harmony part with vibrato. Useful for many music genres.
StandardHarmony	12	50	On	Off	Standard setting for lead vocal plus 2 or 3 harmony parts with vibrato. Useful for many music genres.
EasyHarmony	12	51	On	On	Standard setting for lead vocal plus 2 simple harmony parts with vibrato. Useful for many music genres.
LightHarmony	12	52	On	Off	A light sound with 2 or 3 harmony parts on the lead vocal pitch.
StudioSingers	12	57	On	On	Lead vocal with harmony with suitable EQ and less reverb, good for studio productions.
QuartetHarmony	12	53	On	Off	Standard setting for lead vocal plus 3 harmony parts with vibrato. Useful for many music genres.
BigHarmony	12	54	On	Off	3 harmony parts overlap the lead vocals, makes a powerful harmony. Useful for many music genres.
BigAcapella	12	55	On	Off	Characteristic acapella sound of lead vocal + 3 voice open harmony (2 voice harmony + bass part).
BigChoir	12	56	On	On	A powerful sound with 2 or 3 harmony parts on the lead vocal pitch.
VocoderSchlager	12	58	On	Off	Vocoder sound for harmony in Schlager music.
StandardDuet	12	0	On	Off	Standard setting for lead vocal plus 1 harmony part. Useful for many music genres.
StandardTrio	12	1	On	Off	Standard setting for lead vocal plus 2 harmony parts. Useful for many music genres.
StandardQuartet	12	2	On	Off	Standard setting for lead vocal plus 3 harmony parts. Useful for many music genres.
StudioVocals	12	33	On	On	Good for studio productions with suitable EQ setting and less Reverb.
JazzyQuartet	12	3	On	Off	Good for Bass, Tenor and Alto singers; for Jazz repertoire. You will hear additional 6th notes.
SchlagerTrio	12	4	On	On	Good for standard Schlager repertoire with simple harmony chords.
DestinyPop	12	5	On	On	Good for female singers with lead vocal plus 2 harmony parts above; for female Pop and R&B repertoire.
VocalDoubler	12	34	Off	On	Use this preset to overdub your singing in real time. Turn the "Harmony" button on in the Vocal Harmony display, and it add harmony parts with Vocal Doubler effect.
VocoderVH	12	6	On	Off	Standard vocoder setting; ideal for controlling harmony notes with "Upper" part.
VocoderMono	12	7	On	Off	Standard vocoder setting; ideal for controlling with "Upper" part. You can play mono (single-note) melodies.
Rock&Roll	12	35	Off	On	Good for Rock&Roll songs from the 50's and 60's with typical delay sound. Turn the "Harmony" button on in the Vocal Harmony display, and it add harmony parts with Blues chords.
TempoCross	12	36	Off	On	Tempo Cross Delay on lead vocal. Turn the "Harmony" on the Vocal Harmony display on to add harmony parts; good for Pop songs or special show effects.
HeavyVoice	12	37	Off	On	Good for Rock and Pop with overdriven vocal. Turn the "Harmony" button on in the Vocal Harmony display, and it add Harmony with 1 octave down.
TelephoneChoir	12	38	On	On	Typical Lo-fi vocal ensemble; use as old fashioned ensemble sound or exciting effect in Rock, Pop and Jazz.
LikeThe80s	12	39	On	On	Good for 80's Pop with typical reverb image.
Gramophone	12	40	On	On	Typical 30's vocal ensemble; use as old fashioned gramophone sound.
PokerPhaser	12	41	On	On	Good for modern Pop songs using phaser effect for lead vocal.
DetuneVoice	12	8	On	Off	Lead vocal plus two additional detuned harmony parts for exciting detuned sound.
PerfectFourth	12	9	On	On	Quartet singing only perfect fourths; parallel movement of all parts.
SingCMajorScale	12	10	On	Off	Sing C major scale and the harmony parts will create suitable chord notes based on the C major scale. You can edit the key root and type by "Harmony Assign" setting on the Vocal Harmony display.
BalladChoir	12	11	On	On	Good for Ballad backing vocals with long reverb time.
ChurchChoir	12	12	On	On	Good for standard church songs and Christmas songs with long reverb time; recommended for Bass, Tenor and Alto voice.
GregorianChoir	12	13	On	On	Good for rubato Gregorian-chant-type monophonic songs with large reverb; parallel movement of all parts.
GospelChoir	12	14	On	On	Good for Gospel songs with long reverb on harmony parts and dominant 7th feel.
CosmicChoir	12	42	On	On	Extreme phasing vocals; useful for exciting effects in Dance and Modern Music.
AlpenGirls	12	15	On	On	Good for male singer with 2 female harmony parts above lead vocal.
CountryRock	12	16	On	On	Typical Country Rock quartet; recommended range is tenor/alto.
R&B Diva	12	17	On	On	Good for female alto singer for R&B repertoire; also usable with Tenor lead vocal.
ClosedPopChicks	12	18	On	On	Good for female singers with two harmony parts below. Change volume of Harm.3 for an additional (3rd) part below.
QueenOfPop	12	43	Off	On	Good for Pop and R&B songs using Tempo Delay. Turn the "Harmony" button on in the Vocal Harmony display, and it add 2nd Voice.
Bob->Mary	12	19	On	On	Male singer can sound like Female voice with long romantic reverb. Use "Balance" on the Vocal Harmony display to add a male duet partner.
Mary->Bob	12	20	On	Off	Female singer can sound like Male voice with short reverb. Use "Balance" on the Vocal Harmony display to add a female duet partner.
FlangingVocals	12	44	Off	On	Useful for modern Pop, Rock and Dance music.
JazzySingers	12	21	On	On	Good for Bass and Tenor Singers. Harmony parts add 3 female Jazz singers.
QuartetOnStage	12	22	On	On	Good for Rock and Pop Music. Harmony parts make up a quartet.
DelayedHarmony	12	45	On	On	Useful in several genres with a tempo-synced delay choir as background.
KidsChoir	12	23	On	Off	Want to be a child again? Use this preset type and sing with your friends. ...
ChorusChoir	12	46	On	On	The chorus effect adds a rich and exciting characteristics to your voice and the harmony parts.
BohemianVocoder	12	47	On	On	Tempo flanging Vocoder Type; good for Rock or Pop songs and Intros.
RobotVoice	12	48	On	On	Do you want to sound like a robot? This is the setting. Use Harm.3 for variation.
ChordalXG	90	0	On	Off	CHORDAL type setting of previous Vocal Harmony system.
DetuneXG	91	0	On	Off	DETUNE type setting of previous Vocal Harmony system.
ChromaticXG	92	0	On	Off	CHROMATIC type setting of previous Vocal Harmony system.
VocoderXG	89	0	On	Off	VOCODER type setting of previous Vocal Harmony system.
Thru	64	0	Off	Off	Bypass without any harmonies and effects.

Vocal Effect Type List

Type Name	Description	MSB	LSB
Romantic Reverb	Long reverb for vocal part. Romantic image.	1	0
80s Pop Reverb	Long reverb for vocal part. 80's pop image.	1	16
Room	Reverb simulating the acoustics of a room.	2	0
Concert Stage	Reverb simulating the concert stage.	3	0
Plate	Reverb simulating a plate reverb unit.	4	0
Vocal Doubler	Immediate delay with center focused feeling.	5	16
Stereo Spread	Immediate delay with spread feeling.	5	17
Delay	Produces simple delayed sounds: L,R, and C (center).	5	0
Short Delay	Produces short delayed sound with narrow image.	5	1
Rock & Roll Delay	Produces slap back echo sound. Good for Rock&Roll music.	5	18
Cross Delay	The feedback of the two delayed sounds is crossed.	8	0
Tempo Delay	Tempo-synchronized delay.	21	0
Tempo Cross Delay	Tempo-synchronized cross delay.	22	0
Chorus	Conventional chorus program with rich, warm chorusing.	66	0
EQ Hi-Fi	Equalizer effect that boosts both high and low frequencies.	76	16
EQ TEL	Equalizer effect that cuts both high and low frequencies.	76	0
Gramophone	Produces Lo-Fi sound with gramophone image.	94	0
Robot	Produces Lo-Fi sound with robotic image.	94	16
Overdriven	Produces overdriven sound. Good for rock and dance music.	98	0
Scream & Shout	Produces heavy distorted sound.	98	16
Tempo Flanger	Tempo-synchronized flanger.	107	0
Tempo Phaser	Tempo-synchronized phaser.	108	0
Tempo Auto Pan	Tempo-synchronized auto pan.	121	0
No Effect	No effect.	0	0

Parameter Chart / Parametertabelle / Tableau des paramètres / Gráfico de parâmetros

Screen		Parameter	Backup *1	Backup/Restore File *2	Registration Memory		Comment	
					Regist	Group		
Piano Room	Main	Piano Voice	x	x	○	Voice		
		Reverb Type	x	x	○	Common		
		Lid Position	○*	○*	○	Voice	*Saved for each Piano Voice.	
	Piano Room Setting	Lid Position	Lid Position	○*	○*	○	Voice	*Saved for each Piano Voice.
		Brightness	Brightness	○*	○*	○	Voice	*Saved for each Piano Voice.
		Touch Curve	Touch Curve	○	○	x		
			Fixed Velocity	○	○	x		
		Environment	Reverb Type	x	x	○	Common	
			Reverb Depth	○*	○*	○	Voice	*Saved for each Piano Voice.
		Master Tune	Master Tune	○	○	x		
		VRM	VRM On/Off	○*	○*	○	Voice	*Saved for each Piano Voice.
		Damper Resonance	Damper Resonance	○*	○*	○	Voice	*Saved for each Piano Voice.
		Damper Noise	Damper Noise	○*	○*	○	Voice	*Saved for each Piano Voice.
		String Resonance	String Resonance	○*	○*	○	Voice	*Saved for each Piano Voice.
		Duplex Scale Resonance	Duplex Scale Resonance	○*	○*	○	Voice	*Saved for each Piano Voice.
		Body Resonance	Body Resonance	○*	○*	○	Voice	*Saved for each Piano Voice.
		Grand Expression	Grand Expression	○*	○*	○	Voice	*Saved for each Piano Voice.
		Half Pedal Point	Half Pedal Point	○	○	x		
		Each Key Setting	Tune	○*	○*	x		*Saved for each Piano Voice.
Volume	○*		○*	x		*Saved for each Piano Voice.		
Voice	Main	Main Voice	x	x	○	Voice		
		Layer On/Off	x	x	○	Voice		
		Layer Voice	x	x	○	Voice		
		Left On/Off	x	x	○	Voice		
		Left Voice	x	x	○	Voice		
		Split Point	○	○	○	Voice, Style		
	Voice Select	Favorites	○	○	x			
	Voice Setting	Octave	Octave	x	x	○	Voice	
			Mixer	Part On/Off	x	x	○	Voice
		Pan		x	x	○	Voice	
		Reverb Type		x	x	○	Common	
		Reverb Depth	x	x	○	Voice		
	Volume	x	x	○	Voice			
	Style	Main	Style	x	x	○	Style	
			Syncho Start On/Off	x	x	○	Style	
			Volume	x	x	○	Style	
			Tempo	x	x	○	Style	
			Part On/Off	x	x	○	Style	
			Section	x	x	○	Style	
Style Select		Favorites	○	○	x			
Style Setting		Fingering	Chord Detection Area	○	○	○	Style	
			Split Point	○	○	○	Voice, Style	
			Sound for the Left-hand section	○	○	○	Style	
		Style	Intro On/Off	○	○	x		
			Ending On/Off	○	○	x		
			Dynamics Control	x	x	○	Style	
			Auto Section Change On/Off	x	x	○	Style	
			Auto Section Change Timing	x	x	○	Style	
			Auto Section Change Sensitivity	x	x	○	Style	
			Tempo	○	○	x		
		Mixer	Part On/Off	x	x	○	Style	
			Pan	x	x	○	Style	
			Reverb Type	x	x	○	Common	
			Reverb Depth	x	x	○	Style	
Volume	x	x	○	Style				
Song	Main	Song	x	x	○	Song		
		AB Repeat	x	x	○	Song		
		Guide On/Off	x	x	○	Song		
		MIDI Song Volume	x	x	○	Song		
		Audio Song Volume	x	x	○*	Song	*Available only when connected to a Wi-Fi network.	

Screen		Parameter	Backup *1	Backup/Restore File *2	Registration Memory		Comment	
					Regist	Group		
Song	Main	MIDI Song Tempo	x	x	○	Song		
		Audio Song Tempo	x	x	○	Song		
		MIDI Song Transpose	x	x	○	Song		
		Audio Song Transpose	x	x	○	Song		
		Part On/Off*	x	x	○	Song	*Available only when selecting a MIDI Song.	
		Chord Chart	○*	○*	x		*Saved for each Audio Song, but not MIDI Songs.	
	Song Select	Favorites	○	○*	x		*Songs in "Music Library" category are not backed up.	
		Song Repeat	x	x	x			
		User Songs	○	○	x			
	Setting	Arrangement	Accompaniment Score Pattern*	○	○	○	Song	*Available only when selecting an Audio Song. Saved for each Audio Song.
			Backing*	x	x	○	Song	*Available only when selecting an Audio Song.
			Melody Suppressor*	x	x	○	Song	*Available only when selecting an Audio Song.
			Style*	x	x	○	Style	*Available only when selecting an Audio Song.
			Part On/Off*	x	x	○	Style	*Available only when selecting an Audio Song.
		Playback	Stream Lights On/Off	○	○	x		
			Stream Lights Speed	○	○	x		
			Guide Type*	○	○	x		*Available only when selecting a MIDI Song.
			Quick Start On/Off*	○	○	x		*Available only when selecting a MIDI Song.
			MIDI Part Channel - Auto Set On/Off*	x	x	○	Song	*Available only when selecting a MIDI Song.
			MIDI Part Channel - Right*	x	x	○	Song	*Available only when selecting a MIDI Song.
			MIDI Part Channel - Left*	x	x	○	Song	*Available only when selecting a MIDI Song.
		Score	Size	○	○	x		
			Part	x	x	○	Song	
			Grand Staff View of the Right Part	x	x	○	Song	
			Chord On/Off	○	○	x		*Available only when selecting a MIDI Song.
			Lyric On/Off*	○	○	x		*Available only when selecting a MIDI Song.
		Chord	Quantize*	x	x	○	Song	*Available only when selecting a MIDI Song.
			Lyric On/Off*	○	○	x		*Available only when selecting a MIDI Song.
		Lyric	Chord Simplification	○	○	x		*Available only when selecting an Audio Song.
			Chord On/Off*	○	○	x		*Available only when selecting a MIDI Song.
		Mixer	Language*	○	○	x		*Available only when selecting a MIDI Song.
			Part On/Off	x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.
			Pan	x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.
Reverb Type			x	x	○	Common		
Reverb Depth			x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.	
		Volume	x	x	○	Song, Style*	**"Song" is available when selecting a MIDI Song. "Style" is available when selecting an Audio Song.	
Recording	Recording Method	x	x	○	Song			
	Rec Part On/Off*	x	x	x		*Available only for MIDI Recording		
	Rec Channel*	x	x	x		*Available only for MIDI Recording		
Registration Memory	Registration Memory	○	○	x				
Metronome	Tempo	x	x	○	Others			
	Metronome Beat	x	x	x				
	Bell On/Off	○	○	x				
	Volume	○	○	x				

Screen	Parameter	Backup *1	Backup/Restore File *2	Registration Memory		Comment		
				Regist	Group			
Balance	Style Volume	x	x	○	Style			
	Main Voice Volume	x	x	○	Voice			
	Layer Voice Volume	x	x	○	Voice			
	Left Voice Volume	x	x	○	Voice			
	MIDI Song Volume	x	x	○	Song			
	Audio Song Volume*	x	x	○	Song	*Available only when connected to a Wi-Fi network.		
	Mic Volume	x	x	○	Others			
	Aux In Volume	○	○	○	Others			
Utility	Transpose	Keyboard/Style Transpose	x	x	○	Others		
		MIDI Song Transpose	x	x	○	Song		
		Audio Song Transpose	x	x	○	Song		
	Tuning	Master Tune	○	○	x			
		Scale Tune Type	x	x	○	Others		
		Scale Tune Base Note	x	x	○	Others		
	Keyboard	Touch Curve	○	○	x			
		Fixed Velocity	○	○	x			
	Pedal	Main	Right Pedal Function	x	x	○	Others	
			Center Pedal Function	x	x	○	Others	
			Left Pedal Function	x	x	○	Others	
			AUX Pedal Function	x	x	○	Others	
			AUX Pedal Polarity	○	○	x		
			Switch with Main Voice (Center & Left)	○	○	x		
		Setting	Part On/Off	x	x	○	Others	
			Half Pedal Point	○	○	x		
			Soft Pedal Depth	x	x	○	Others	
			Glide Up/Down	x	x	○	Others	
			Glide Range	x	x	○	Others	
			Glide On Speed	x	x	○	Others	
			Glide Off Speed	x	x	○	Others	
			Pitch Bend Up/Down	x	x	○	Others	
	Pitch Bend Range	x	x	○	Others			
	Mic	Mic On/Off	x	x	○	Others		
		Mic Volume	x	x	○	Others		
		Mic Setting	x	x	○	Others		
		Mic Reverb Depth	x	x	○	Others		
		Mic Noise Gate On/Off	x	x	○	Others		
		Vocal Harmony Type	x	x	○	Others		
		Vocal Harmony On/Off	x	x	○	Others		
		Vocal Effect On/Off	x	x	○	Others		
		Lead Vocal Volume	x	x	○	Others		
		Harmony Volume	x	x	○	Others		
Master EQ	Main	Type	x	x	○	Others		
		Frequency	x	x	○	Others		
		Gain	x	x	○	Others		
		Q	x	x	○	Others		
	Master EQ Select	User Settings	○	○	x			
Sound Setting	Speaker	○	○	x				
	Binaural On/Off	○	○	x				
	IAC On/Off	○	○	x				
	IAC Depth	○	○	x				
	AUX In Noise Gate On/Off	○	○	x				
System	Language	○	x	x				
	Privacy - Allow Data To Be Sent On/Off	○	○	x				
	Audio Rec Format	○	○	x				
	Auto Power Off	○	○	x				
Instrument	Wi-Fi Setting	Host Name	x	x	x			
		Channel	x	x	x			
Demo	Demo Setting	Repeat	○	○	x			
		Auto Start	○	○	x			

*1 These parameters are saved even after quitting the application.
*2 These parameters can be backed up/restored on the Utility Menu.

○: Yes
x: No

